



Installation Manual

DIAPHRAGM WELL TANK


- **Safety Instructions**
- **Installation**
- **Warranty**



VERTICAL SERIES:
14-20-32-36-52-65-86-96-119 GALLON



IN-LINE SERIES:
2-5 & 7 GALLON




HORIZONTAL SERIES:
7-14 & 20 GALLON



Certified to
NSF/ANSI 61-G

NO LEAD

NO LEAD: The weighted average of the wetted surface of this no lead product contacted by consumable water contains less than one quarter of one percent (0.25%) lead.



KEEP THIS MANUAL FOR FUTURE REFERENCE WHENEVER MAINTENANCE ADJUSTMENT OR SERVICE IS REQUIRED.
Water Systems • 4302 RALEIGH STREET • CHARLOTTE, NC 28213



Questions, problems, missing parts? Before returning to the point of sale, call our Technical Assistance Team at 1800-549-6233, 7:00 a.m.-7:00 p.m., CST, Monday-Friday

CONTENTS

SAFE INSTALLATION, USE, AND SERVICE.....	2	Draining for servicing or for Winter.....	5
IMPORTANT INSTRUCTIONS BEFORE INSTALLATION.	3	Tools Needed for All Pump Installations	5
FEATURES AND OPERATING CYCLES.....	4	TYPICAL SUBMERSIBLE PUMP INSTALLATION.....	6
TANK SPECIFICATIONS	4	TYPICAL JET PUMP INSTALLATION.....	6
Piping	5	Setting the Tank Pressure	7
DIAPHRAGM TANK INSTALLATION	5	Other Tank Installations.....	7
General Materials*.....	5	WARRANTY	8

SAFE INSTALLATION, USE, AND SERVICE

The proper installation, use, and servicing of this well tank is extremely important to your safety and the safety of others.

Many safety-related messages and instructions have been provided in this manual and on your own water heater to warn you and others of a potential injury hazard. Read and obey all safety messages and instructions throughout this manual. It is very important that the meaning of each safety message is understood by you and others who install, use, or service this water heater.

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
 DANGER	DANGER indicates an imminently hazardous situation which, if not avoided, will result in injury or death.
 WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in injury or death.
 CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, could result in property damage.

All safety messages tell you about the type of hazard, what can happen if you do not follow the safety message, and how to avoid the risk of injury.

IMPORTANT INSTRUCTIONS BEFORE INSTALLATION


⚠ WARNING

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS BODILY INJURY AND/OR PROPERTY DAMAGE.

1. All piping and electrical wiring must adhere to state and local codes. Check with appropriate community agencies, or contact your local electrical and pump professionals.
2. Install tank as close as possible to the pump pressure switch to reduce friction loss and elevation difference between the tank, water supply main, and switch.
3. After installation, be sure the pressure switch is set low enough to shut the pump off. If all valves are closed and the pressure switch setting is too high, the pump will run continuously without water flow causing overheating and damage to the pump.
4. A pressure relief valve must be installed in the piping adjacent to the Well Tank.
5. The following may cause severe damage to tank and/or piping and will void warranty.
 - Failure to protect tank against below-freezing temperatures.
 - Pumping chemicals or corrosive liquids.
 - Pumping gasoline or other flammable liquids.
 - Operation at pressures greater than rated pressure on data plate with no relief valve.
 - Pumping liquids hotter than 120°F.

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause DEATH, SERIOUS BODILY INJURY, OR PROPERTY DAMAGE. Refer to this manual for further assistance.



⚠ WARNING

Explosion Hazard

- Over-pressurized water can cause water tank to explode.
- Properly sized pressure relief valve must be installed in piping adjacent to pump tank.
- Failure to follow these instructions could result in death or serious injury.

This Well Tank is designed and intended for cold (ambient temperature) water storage at a maximum pressure of 100-150 PSIG, depending on your tank model, any use other than with cold water, or at a sustained or instantaneous pressure in excess of 100-150 PSIG depending on your tank model is UNSAFE. A pressure relief valve of adequate size must be incorporated in the system. The relief valve must be selected to pass the full capacity of the pump when the pressure in this tank is 100 PSIG or more. Consult pump manufacturer for pump capacity at relief pressure. The manufacturer of this tank does not accept any liability or other responsibility for personal injury or property damage resulting from improper use, installation, or operation of this tank, or of the system of which it is a part.

⚠ WARNING

Failure to follow these instructions can cause the tank to explode and result in DEATH, SERIOUS BODILY INJURY, OR PROPERTY DAMAGE.

Depending on your tank model, install a 150 P.S.I. or less pressure relief valve directly into a fitting of the plumbing. Position the valve downward and provide piping so that any discharge will exit only within 6 inches above, or at any distance below the structural floor. Be certain that no contact is made with any live electrical part. The discharge opening must not be blocked or reduced in size under any circumstances. Excessive length, over 15 feet, or in use of more than two elbows can cause restriction and reduce the discharge capacity of the valve.

No valve or other obstruction is to be placed between the relief valve and the tank nor in the discharge line. Do not connect piping directly to discharge drain unless a 6" air gap is provided. To prevent bodily injury or hazard to life, the relief valve must be able to discharge large quantities of water should circumstances demand. If the discharge pipe is not connected to a drain or other suitable means, the water flow may cause property damage.

The Discharge Pipe:

- Must not be smaller in size than the outlet pipe size of the valve, or have any reducing couplings or other restrictions.
- Must not be plugged or blocked.
- Must be installed so as to allow complete drainage of both the pressure relief valve, and the discharge pipe.
- Must not have any valve between the relief valve and tank.

⚠ WARNING

The complete pump, tank, pressure relief valve, pressure switch and piping system MUST be protected against below freezing temperature. Failure to do so could cause the tank to explode and result in DEATH, SERIOUS BODILY INJURY, OR PROPERTY DAMAGE.

The well tanks are designed for operation on water systems with working pressure not to exceed 100-150 PSIG, depending on your tank model. Pressure exceeding this could become hazardous, and will void any and all guarantees, either written, or implied.

IMPORTANT

It will be necessary to expel all air from piping after new installations, repriming and after pumps have been disassembled for repair. To purge the air, first open a faucet the greatest distance from the pump. With the pump being allowed to run, wait until a steady stream of water is coming from the faucet. At this time, close the faucet for several short intervals.

If, after this, air in the lines still occurs, check on the suction side of the pump for piping leaks.

When standard type tanks are replaced with this tank, all air charging devices, bleeder orifices, and air volume controls must be removed.

The pump tank has been shipped with a factory precharge as indicated on Table 1. If your pump start-up pressure is different from the factory precharge, adjust the tank pressure with the tank empty to your pump start-up pressure. This can be accomplished by simply bleeding air from valve in the top of the tank with an accurate pressure gauge. Using the same standard air charging valve in the top tank, a tire pump can be used to raise the tank pressure. Raise the pressure slowly, checking it periodically with an accurate tire pressure gauge, until the desired pressure is reached.

FEATURES AND OPERATING CYCLES






	<ol style="list-style-type: none"> 1. SHELL constructed of light-weight drawn steel with powdercoat finish that provides extra corrosion-resistance. 2. STRONG AND FLEXIBLE BUTYL DIAPHRAGM assures dependable tank service even with pressures up to 150 PSI. 3. DIAPHRAGM SEAL consists of locking retainer ring for positive separation of air and water. 4. LINING protects inner shell against rust in water reservoir.
 <p>START-UP CYCLE</p> <p>The diaphragm is pressed against the bottom of the air chamber</p>	 <p>FILL CYCLE</p> <p>Water is pumped into the reservoir, which forces the diaphragm upward into the air chamber.</p>
 <p>HOLD CYCLE</p> <p>Pump attains cut-off pressure. Diaphragm reaches uppermost position. Reservoir is filled to capacity.</p>	 <p>DELIVERY CYCLE</p> <p>Pump remains off while pressure in air chamber forces diaphragm downward to deliver water.</p>

Figure 1. Example of How a 30-50 PSI System Works

TANK SPECIFICATIONS




Figure 2. Rough-In Dimensions

Table 1. Rough-In Dimensions

Capacidad en galones	Disminución en galones			Dimensiones en centímetros				Conexión de descarga	Peso en kilos
	20 a 40 PSI	30 a 50 PSI	40 a 60 PSI	A	B	C	D		
(In-Line)									
2	0.7	0.6	---	10-3/16	---	8-1/4	---	3/4 NPTM	5.0
5	1.6	1.4	---	14-3/4	---	11	---	3/4 NPTM	9.0
7	2.5	2.1	---	21-1/16	---	11	---	3/4 NPTM	14.0
(Free-Standing)									
14	5.2	4.3	3.7	24-3/4	2-1/4	15-3/8	---	1" NPTF	25.5
20	7.4	6.2	5.4	32-3/4	2-1/4	15-3/8	---	1" NPTF	30.0
32	11.5	9.6	8.4	45-1/2	2-1/4	15-3/8	---	1" NPTF	40.0
36	13.3	11.1	9.7	32-3/8	2-1/4	20	---	1" NPTF	45.0
52	19.2	16.1	14	38-5/8	2-1/4	23-3/8	---	1-1/4" NPTF	77.0
65	23.9	20	17.5	46.6	2-1/4	23-3/8	---	1-1/4" NPTF	87.0
86	31.8	26.7	23.2	59	2-1/4	23-3/8	---	1-1/4" NPTF	105.0
96	35.5	29.8	25.9	63-3/8	2-1/4	23-3/8	---	1-1/4" NPTF	111.0
119	44	37	32	61-1/4	2-1/2	26	---	1-1/4" NPTF	165.0
(Horizontal)									
7	2.5	2.1	---	12-7/8	21-1/8	11	12-1/2	3/4 NPTM	16.0
14	5.2	4.3	3.7	17-3/8	21-3/4	15-3/8	12-1/2	1" NPTM	25.5
20	7.4	6.2	5.4	17-3/8	27-1/8	15-3/8	12-1/2	1" NPTM	30.0

PIPING

PVC pipe is shown in the illustrations, but copper or galvanized steel pipe may be used if desired. All piping must be clean and free of all foreign matter. ALL JOINTS AND CONNECTIONS IN THE SYSTEM MUST BE AIRTIGHT. A pin-hole leak will prevent proper operation of system (this is the most common problem). Use thread compound on all threads unless specified otherwise.

DRAINING FOR SERVICING OR FOR WINTER

The system should be drained before it is disconnected for servicing, or if it is inoperative for an extended period of time, or if it is in danger of freezing. To Drain:

- Follow the instructions in your pump installation manual to drain the pump.
- Open tank drain cock to drain tank.
- Drain all piping to a point 3 feet below ground level.

DIAPHRAGM TANK INSTALLATION

GENERAL MATERIALS*

All diaphragm tanks are recommended for clear water applications. Vertical tanks are the most commonly used tanks. However, horizontal tanks and in-line tanks may be used where space is more critical. See Tank Specifications for tank capacity.

- One can PVC cement (read instructions carefully)
- One can thread compound (read instructions carefully)
- One gate valve
- One 1/2" relief valve
- Enough rigid PVC pipe and couplings to reach from pump to pressure tank to service line.
- One male PVC adapter
- One tank cross
- Two 3/8" plugs
- One 1/2" boiler drain
- One 1/2" street tee

TOOLS NEEDED FOR ALL PUMP INSTALLATIONS

Pipe wrench, crescent wrench, 24-tooth hacksaw, round file or knife.

REMINDER: All joints and connections must be airtight. A single pin-hole leak will prevent the proper operation of the system. Use thread compound on all threaded connections unless specified otherwise.

* list is for 1" piping installation, if you are installing 1-1/4" pipe change sizes accordingly.

TYPICAL SUBMERSIBLE PUMP INSTALLATION

Do the following for a submursable pump installation:

1. Complete pump assembly and electrical connections as specified in pump installation manual. Place tank in desired location and level it.
2. Thread tank tee into pressure tank so that the two 1/4" holes in the tee face upward. Thread street tee into front of tank tee.




Figure 3. Tank Tee Threaded into Pressure Tank

3. Thread 3/4" male PVC adapter into the inlet side of tank tee.




Figure 4. 3/4" Adaptor Threaded in Tank Tee

4. Thread pressure relief valve into top of street tee. Thread 1/2" boiler drain into front of street tee. Cut and cement as many sections and couplings of PVC pipe needed to connect 3/4" male PVC adapter to pump discharge.




Figure 5. Pressure Relief Valve Threaded into Street Tee

The complete installation should look like Figure 6 shown below:




Figure 6. Submersible Pump With Vertical Tank

TYPICAL JET PUMP INSTALLATION

Do the following to forl a typical jet pump installation:

1. Thread 10" X 1" nipple into pressure tank. Thread tank cross into nipple so that the two 1/4" holes in tank cross face upward. Thread street tee into front of tank cross. Thread pressure relief valve into top of street tee and thread 3/4" boiler drain into front of street tee.




Figure 7. Street Tee Fittings

2. Thread 1" male PVC adapter into the inlet side of tank cross.




Figure 8. PVC Adapter

3. Thread one end of 1/4" X 3" brass nipple into bottom of pressure switch. Thread other end into left 1/4" hole of tank cross. Thread pressure gauge into right 1/4" hole of tank cross. Cut and cement as many sections and couplings of PVC pipe needed to connect the 1" male PVC adapter to pump discharge.




Figure 9. Installed Pressure Switch and Pressure Guage

The complete installation should look like Figure 10 shown below:




Figure 10. Base Mounted Jet Pump With Vertical Tank




Figure 11. Jet Pump Installations

NOTE: NO PRESSURE RELIEF VALVE SHOWN (but is required) ON JET PUMP WITH IN-LINE DRAWING AND JET PUMP MOUNTED ON VERTICAL TANK DRAWING.

SETTING THE TANK PRESSURE

The tank pressure must be set 2 PSI lower than the pump cut-on pressure. Check tank pressure with a standard air gauge at the top of the tank as needed.

OTHER TANK INSTALLATIONS

Where space is a critical factor, the in-line tank may be used or the pump may be mounted on either the horizontal or vertical tanks. Various installations are shown. Also, to increase tank capacity up to even industrial levels, multiple tanks may be installed on the same line. See Figure 12. Consult your local pump professional for your particular installation.




Figure 12. Multi-Tank Installation

WARRANTY

FIVE YEAR LIMITED WARRANTY ON WELL TANKS

The "COMPANY" warrants this Well Tank in case of a leak within five (5) years from the date of purchase or in the absence of a Bill of Sale verifying said date, from the date indicated on the model and rating plate affixed to this tank. In case of a defect, malfunction, or failure to conform to this warranty, the Company will repair or replace this tank. No labor, installation, or freight (if any) charges are included in this warranty. You must pay these costs.

Prior to return of the well tank or part to the manufacturer for inspection, the Company will, if requested, ship a replacement pump tank or part C.O.D. and later provide such reimbursement as subsequent inspection indicates is due under these warranties.

EXCLUSIONS AND LIMITATIONS OF THESE LIMITED WARRANTIES

1. The limited warranties provided herein are in lieu of any and all warranties, expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose; provided, however, that implied warranties are not disclaimed during the five-year period from date of purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.
2. The company shall have no liability hereunder, either direct or contingent, for incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
3. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.
4. These warranties shall be void and shall have no effect:
 - a. If the design or structure of the tank is, or is attempted to be, modified or altered in any way, including, but not limited to, by attaching non-Company approved appliances or equipment.
 - b. If the tank is not properly installed in accordance with all local ordinances and regulations pertinent to tanks and the installation and instruction manual provided with this tank.
 - c. If the pump tank is installed outdoors. This tank is intended for indoor installation only.
 - d. If the tank is not equipped with new pressure protective equipment required by local codes, but not less than a pressure relief valve certified by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment or materials, as meeting the requirements for Relief Valves. This valve must be marked with a maximum set pressure not to exceed the marked hydrostatic working pressure of the tank.
 - e. If the tank is not operated within the factory calibrated limits.
 - f. If leaks in the tank, or defects in other parts, arise as the result of improper use, negligence in operation, accident, or from inability of the tank or any of its parts to function because of repairs, adjustments, or replacements improperly made outside the Company's factory, or because of fire, floods or lightning.
 - g. If the model and rating plate has been defaced or discarded and you do not have a Bill of Sale to verify the purchase date.
 - h. If (1) installed in an area where leakage of the tank or connections would result in damage to the area adjacent to the tank or (2) where such a location is unavoidable, a suitable drain pan is not installed under the tank.
 - i. If the tank is used for any purpose other than a pump tank for potable water well applications.
 - j. If the tank is used with pools, whirlpools, or hot tubs, or with any equipment or system that uses heavily chlorinated or otherwise nonpotable water.
 - k. If leaks in the tank or defects in other parts occur as a result of the tank being exposed to a highly corrosive atmospheric condition.
 - l. If leaks in the tank or defects in other parts occur as a result of the tank containing and/or being operated with desalinated (de ionized) water.
 - m. If leaks in the tank or defects in other parts arise as a result of sizing that does not comply with the manufacturer's currently published sizing guides or sizing recommended by the manufacturer.
 - n. If this pump tank or any part has been under water.
 - o. If a new certified pressure relief valve is not installed and properly maintained.
 - p. If the tank is not installed in the United States, its territories or possessions, and Canada;
5. Replacements and/or repairs furnished under these warranties do not carry a new warranty, only the unexpired portion of the original warranty.
6. The terms of this warranty may not be varied by any person, whether or not purporting to represent or to act on behalf of the Company.
7. In order to obtain service under these warranties you must promptly notify the installing contractor or dealer, giving the nature of the problem and the model and serial number of the tank. If for any reason the installer or dealer cannot be located or fails to provide satisfactory warranty service, you should write the Company with the above information.

8. CLAIM PROCEDURE

Any claim under the warranty should be initiated with the dealer who sold the unit, or with any other dealer handling the warrantor's products. If this is not practicable, the owner should contact:

A. O. Smith
500 Tennessee Waltz Parkway
Ashland City, TN 37015
Phone: 1-800-527-1953
www.hotwater.com

a. The warrantor will only honor replacement with identical or similar tank which are manufactured or distributed by the warrantor.

b. Dealer replacements are made subject to in-warranty validation by warrantor.

c. PROOF-OF-PURCHASE AND PROOF-OF-INSTALLATION DATE ARE REQUIRED TO SUPPORT WARRANTY CLAIM FROM ORIGINAL OWNER. THIS FORM DOES NOT CONSTITUTE PROOF-OF-PURCHASE OR PROOF-OF-INSTALLATION.

9. DISCLAIMERS

NO EXPRESSED WARRANTY HAS BEEN OR WILL BE MADE ON BEHALF OF THE WARRANTOR WITH RESPECT TO THE MERCHANTABILITY OF THE TANK OR THE INSTALLATION, OPERATION, REPAIR OR REPLACEMENT OF THE TANK. THE WARRANTOR SHALL NOT BE RESPONSIBLE FOR WATER DAMAGE, LOSS OF USE OF THE UNIT, INCONVENIENCE, LOSS OR DAMAGE TO PERSONAL PROPERTY, OR OTHER CONSEQUENTIAL DAMAGE. THE WARRANTOR SHALL NOT BE LIABLE BY VIRTUE OF THIS WARRANTY OR OTHERWISE FOR DAMAGE TO ANY PERSONS OR PROPERTY, WHETHER DIRECT OR INDIRECT, AND WHETHER ARISING IN CONTRACT OR IN TORT. Should governmental regulations or industry standards prohibit the Manufacturer from furnishing a comparable model replacement under this warranty, the Owner will be furnished with the closest comparable tank meeting the then current governmental regulations and industry standards. A supplementary fee may be assessed to cover the additional cost associated with the changes made to meet applicable regulations and standards.

IMPORTANT INFORMATION

Model Number _____ Serial Number _____


INSTALLATION INFORMATION

Date Installed _____ Company's Name _____

Street or P.O. Box _____ City, State, and Zip Code _____

Phone Number _____ Plumber's Name _____

Figura 5. Multiples Tendues Verticales



Cuando el espacio es un factor esencial, se puede usar el tanque en linea o se puede montar la bomba en los tanques horizontales en linea. Consulte al profesional local experto en bombas para su instalacion particular.

INSTALACIONES DE OTROS TANQUES

La presión del tanque se debe ajustar 2 PSI más baja que la presión de encendido. Revise la presión del tanque con manómetro de aire estandar en la parte superior del tanque, según sea necesario.

AJUSTE DE LA PRESIÓN DEL TANQUE

Note: NO SE MUESTRA (puedo ser requerido) UNA VÍVULADA DE CHORRO MONADA EN TANQUE VERITCAL.

Figura 6. Instalaciones de bombas de chorros







Figura 4. Bomba De Chorro Montada En Base Con Languide Vertical




La instalación completa deberá lucir de un modo similar a lo descrito en la Figura 4 que se muestra abajo.

Eurosude un extremo de la bobilla de bronce de 1/4 pulg. x 3 pulg. en la parte inferior del presostato. Eurosude otro extremo para conectar el adaptador macho de PVC de 1 pulg. a la descarga de la bomba.






1. Enrosque la boquilla de 10 pulg. x 1 pulg. en el tanque de presión.
2. Enrosque el adaptador macho de PVC de 1 pulg. en el lado de entrada de la conexión en cruz del tanque.




1. Enrosque la boquilla de 10 pulg. x 1 pulg. en el tanque de presión.
2. Enrosque la conexión en la parte superior de la caldera de 3/4 pulg. en la parte de la conexión en la cruz del tanque. Enrosque la válvula de alivio de presión en la conexión en T de la calibre y enrosque el dranaje de la caldera de 3/4 pulg. en la parte de la conexión en T de la calibre.

INSTALACION TIPICA DE LA BOMBA DE CHORRO

Figura 3. Bomba Sumergible Con Tanque Vertical




- La instalación completa luciría de un modo similar a lo descrito en la Figura 3 que se muestra abajo.



1. Realice el ensamblaje de la bomba y las conexiones eléctricas segun se especifica en el manual de instalación de la bomba.
2. Coloque el tanque en la ubicación deseada.
3. Enrosque la conexión en T del tanque en el tanque de presión de PVC que sean necesarias para conectar las tuberías.
4. Enrosque la válvula de alivio de presión en la parte superior de la conexión en T de la calle. Enrosque el dranaje de caldera de 1/2 pulg. en la parte delantera de la conexión en T de la calle.

1. Enrosque el adaptador macho de PVC de 3/4 pulg. en el lado de entrada de la conexión en T del tanque.



2. Enrosque la conexión en la parte superior de la conexión en T de la calle en la conexión en T de la calle en la parte de la conexión en T del tanque.
3. Enrosque la conexión en la parte superior de la conexión en T de la calle en la conexión en T del tanque.

INSTALACION TIPICA DE LA BOMBA SUMERGIBLE

* La lista es para instalación de tuberías de 1 pulg., si instala tuberías de 1-1/4 pulg. cambie los tamaños segúin corresponda.

* Sistema. Use compuesto para rosas en todas las conexiones rosadas, a menos que se especifique lo contrario.

AVISOS: Todas las juntas y conexiones deben ser herméticas. Una fuga de microagujero evitará el funcionamiento adecuado del

Llave para tuberías, llave ajustable, llave de 24 dientes, llave redonda o cuchillo.

- Una válvula de compuerta
- Una válvula de compuerta cuadrada (véase instrucciones cuidadosamente)
- Una llave de compuesto para rosas (véase instrucciones cuidadosamente)
- Una llave de cierre de 1/2 pulg.

HERMAMENTAS NECESARIAS PARA TODAS LAS INSTA-LACIONES DE BOMBAS

- Todos los tamaños de diámetro se recomienda para aplicaciones de impulsión de agua. Los tamaños verticales son los tamaños más usados. Sin embargo, los tamaños horizontales y los tamaños en linea se pueden usar donde el espacio es más esencial. Consulte las especificaciones del tanque para ver la capacidad del tanque.
- Una conexión en T de la bomba para drenaje.
 - Una conexión en cruz del tanque.
 - Una conexión macho de PVC.
 - Un adaptador macho de PVC a las tuberías.
 - Suficiente tubería de PVC rígida y conexiones para alcanzar desde la bomba al tanque de presión para dar mantenimiento a las tuberías.
 - Una llave para tuberías, llave ajustable, llave de 24 dientes, llave redonda o cuchillo.

MATERIALES GENERALES*

INSTALACIÓN DEL TANQUE DE DIAPRAGMA

- En las ilustraciones se muestra la tubería de PVC, pero también se puede usar tubería de cobre o acero galvanizado, si se deseaa. Todas las tuberías deben estar limpia y libres de materiales extraídos. **TODAS LAS JUNTAS Y CONEXIONES EN EL SISTEMA DEBEN SER HERMÉTICAS.** Una de microagujero evita el funcionamiento adecuado del sistema (este es el problema más común). Use compuesto para rosas en todas las rosas, a menos que se especifique lo contrario.
- Abrir la llave para drenaje del tanque para drenarlo.
 - Instalación de la bomba para drenarla.
 - Siga las instrucciones que se presentan en el manual de congelarse. Pasos para drenar:
 - Si el sistema se deba desconectarlo por mantenimiento, o si está sin funcionar durante un período extenso o si corre el riesgo de congelarse, abra la llave para drenar el tanque.
 - Drene todas las tuberías a un punto de 0,9 m (3 pies) bajo el nivel del suelo.


DRENAJE PARA DAR MANTENIMIENTO O PARA LA TEM-

TUBERÍAS

POBADA INVERNAL




Capacidad en galones	Dimensiones aproximadas									
	PSI	30 a 50	40 a 60	A	B	C	D	E	Peso en kilos (lb)	Carga en libras
2	0.7	0.6	...	25.9 (10-3/16)	...	21.0 (8-1/4)	3/4 pulg. NPTF	2.3 (5.0)	4.1 (9.0)	2.1 (4.6)
5	1.6	1.4	...	37.5 (14-3/4)	...	27.9 (11)	3/4 pulg. NPTM	6.4 (14.0)	11.6 (25.5)	5.0 (11.4)
7	2.5	2.1	...	32.7 (12-7/8)	27.9 (11)	31.8 (12-1/2)	3/4 pulg. NPTF	7.3 (16.0)	14.1 (31.8)	7.4 (165.0)
14	5.2	4.3	3.7	44.1 (17-3/8)	55.2 (21-3/4)	39.1 (15-3/8)	31.8 (12-1/2)	1 pulg. NPTM	11.6 (25.5)	11.6 (25.5)
20	7.4	6.2	5.4	44.1 (17-3/8)	68.9 (27-1/8)	39.1 (15-3/8)	31.8 (12-1/2)	1 pulg. NPTM	13.6 (30.0)	13.6 (30.0)

Figura 2. Dimensiones aproximadas



ESPECIFICACIONES DEL TANQUE

Figura 1. Ejemplo de cómo funciona un sistema de 30 a 50 PSI

1. FUNDAMENTAL	2. DIAFRAGMA DE BULTO RESISTENTE Y FLEXIBLE	3. SELLO DE DIAFRAGMA	4. REVESTIMIENTO	5. CICLO DE SUMINISTRO	6. CICLO DE MANTENIMIENTO	7. CICLO DE LLENADO	8. CICLO DE ENCENDIDO
1. FUNDAMENTAL fabricada de acuerdo al peso ligero con acabado de pintura en polvo que proporciona resistencia a la corrosión adicional.	2. DIAFRAGMA DE BULTO RESISTENTE Y FLEXIBLE asegura un servicio confiable del tanque incluido con presiones de hasta 150 PSI.	3. SELLO DE DIAFRAGMA consta de anillo de retención de bloqueo para una separación segura de aire y agua.	4. REVESTIMIENTO protege la funda interna del óxido en el depósito de agua.				

CARACTERÍSTICAS Y CICLOS DE FUNCIONAMIENTO

El tanque para bombas se encola con una precarga de fibra de vidrio y se indica en la Tabla 1. Si la presión de arranque de la bomba es disintinta a la de la precarga de fibra, ajuste la presión del tanque con el tanque vacío a la de la precarga de fibra, ajuste la presión del tanque con el tanque lleno de aire de la bomba. Esto se logra reajustando la presión del tanque de acuerdo con la Tabla 1. Si la presión de arranque de la bomba es disintinta a la de la precarga de fibra, ajuste la presión del tanque con el tanque lleno de aire de la bomba. Esto se logra reajustando la presión del tanque de acuerdo con la Tabla 1.

utilizar todos los dispositivos de carga de aire, artificiales de purga y controles de volumen de aire.

Si hay fugas en las tuberías en el lado de aspiración de la bomba, revise si después de esto, sigue habiendo aire en las tuberías, revise SÍ.

Se debiera expulsar todo el aire de las tuberías después de realizar numerosas instalaciones, al volver a cogerlas y después de desensamblar las bombas para reutilizarlas en otras. Para proteger el aire, se deben lastrar las bombas hasta que no se utilicen de nuevo.

IMPORTANTE

Los tándemes están diseñados para sufuncionamiento en sistemas de agua con presión de radiofijo que no sobrepase las 100 PSIG o 150 PSIG, según el modelo del tanque. La presión que excede este límite puede ser peligrosa, y aunque algunas o todas las garantías ya sean esenciales o impicitas.

SE DEBE brindar protección contra temperaturas inferiores a 0°C y se debe provocar la muerte, lesiones físicas graves o daños a la propiedad.

ADVERTENCIA


- La tubería de descarga:
 - no debe ser menor que el tamaño de la tubería de salida
 - de la valvula, ni tener alguna conexión de reducción u otras restituciones;
 - no se debe obstruir ni bloquear;
 - se debe instalar de manera que permita el drenaje completo, tanto de la valvula de alivio de presión como de la tubería de descarga;
 - tanto la tubería de descarga como la de escape deben tener una longitud mínima de 10 veces el diámetro de la tubería.

Según el modelo del tanque, instalar una válvula de presión de 125 PSI o menos directamente a un conector de la instalación de agua. Coloque la válvula hacia abajo solo 15,2 cm (6 pulg.) por sobre el punto de descarga para garantizar que la tubería de modo que se detenga en el centro de la tubería de descarga. Asegúrese de que no entre en contacto con ninguna parte eléctrica activa. La abertura de descarga no debe bloquear ni reducir su tamaño hasta ninguna circunstancia. Una llave ligada excesiva, superior a 4,6 m (15 pies), o el uso de más de dos codos pueden causar una restricción que reduce la capacidad de descarga de la válvula.


No seguir estas instrucciones puede causar la MURTE, LESIONES explosivas, lo que puede provocar la DANOS A LA PROPIEDAD.

ADVERTENCIA

INSTRUCCIONES IMPORTANTES ANTES DE LA INSTALACION



ADVERTENCIA




3. Después de la instalación, asegúrese de que el presostato de bomba para reducir la pérdida de fricción y la diferencia de elevación entre el tanque, el conducto de suministro de agua y el interruptor.

2. Instale el tanque lo más cerca posible del presostato de bomba para reducir la pérdida de fricción y la diferencia de elevación entre el tanque, el conducto de suministro de agua y el interruptor.

1. Todas las tuberías y accesorios eléctricos deben cumplir los códigos estatales y locales. Consulte con las agencias comunitarias correspondientes o comuníquese con profesionales locales expertos en sistemas eléctricos y bombas.



Por lo general, todos los mensajes de seguridad le informarán sobre el tipo de peligro, sobre lo que puede suceder si no sigue el mensaje de seguridad y sobre cómo evitar el riesgo de lesiones.

<p>PRECAUCIÓN, sin el símbolo de alerta de seguridad, indica una situación de riesgo potencial que, de no evitarse, podría provocar lesiones menores o moderadas.</p>	<p>PRECAUCIÓN, sin el símbolo de alerta de seguridad, indica una situación de riesgo potencial que, de no evitarse, provocaría daños a la propiedad.</p>
<p>ADVERTENCIA indica una situación de riesgo potencial que, de no evitarse, provocaría lesiones o la muerte.</p>	<p>ADVERTENCIA indica una situación de riesgo potencial que, de no evitarse, provocaría lesiones o la muerte.</p>
<p>PELIGRO indica una situación de riesgo imminente que, de no evitarse, provocaría lesiones o la muerte.</p>	<p>PELIGRO indica una situación de riesgo para avisarle que existe riesgo de posibles lesiones personales. Respete todos los mensajes de seguridad que tengan este símbolo para evitar surdir posibles lesiones o la muerte.</p>
 <p>Este es el símbolo de alerta de seguridad. Se usa para avisarle que existe riesgo de posibles lesiones personales. Respete todos los mensajes de seguridad que tengan este símbolo para evitar surdir posibles lesiones o la muerte.</p>	

En el manual y en el tanque para bombas se proporcionan variaciones de los mensajes y se detallan las situaciones en las que se deben implementar. Los mensajes se basan en la información que se obtiene de los sensores de seguridad y se activan cuando se detecta una situación de riesgo.

INSTALACION, USO Y MANTENIMIENTO SEGUROS

INSTALACION, USO Y MANTENIMIENTO SEGUROS.....	2
INSTALACIONES IMPORTANTES ANTES DE LA	
INSTALACION	3
CARACTERISTICAS Y CICLOS DE FUNCIONAMIENTO	4
ESPECIFICACIONES DEL TANQUE	4
Tuberias	5
Drenaje para dar mantenimiento o para la temporada	5
invernal	5
Aljiste de la presión del tanque	7
Instalaciones de otros tanques	7
GARANTIA	8


CONTENIDO

de Asistencia Técnica al 1800-549-6233, de 7:00 a.m. a 7:00 p.m., CST, de lunes a viernes.
Preguntas, problemas, partes fallantes? Antes de regresar al punto de venta, llame a nuestro Equipo





Water Systems • 4302 RALEIGH STREET • CHARLOTTE, NC 28213

GUARDE ESTE MANUAL PARA FUTURAS CONSULTAS CADA VEZ QUE SE REQUIERA REALIZAR AJUSTES O DAR MANTENIMIENTO A LA UNIDAD.



PLOMO SIN

SIN PLOMO: El promedio ponderado de la superficie humedada de este producto sin plomo es menor de un por ciento de plomo (0,25%).



14-20-32-36-52-65-86-96-119 GALLONES
SERIE VERTICAL:

- **Garantía**
- **Instalación**
- **Instrucciones de seguridad**

MANUAL DE INSTALACIÓN

TANQUE DE DIÁFRAGMA