

# READ THIS FIRST



## Model G1021X2

### \*\*\*IMPORTANT UPDATE\*\*\*

For Machines Mfd. Since 07/22  
and Owner's Manual Revised 04/21

For questions or help with this product contact Tech Support at (570) 546-9663 or [techsupport@grizzly.com](mailto:techsupport@grizzly.com)


The following changes were recently made since the owner's manual was printed:

- Switch box and switch pedestal have been modified.
- An additional step has been included in **Assembly**.

Aside from this information, all other content in the owner's manual applies and **MUST** be read and understood for your own safety. **IMPORTANT: Keep this update with the owner's manual for future reference.**

For questions or help, contact our Tech Support at (570) 546-9663 or [techsupport@grizzly.com](mailto:techsupport@grizzly.com).

## Revised Parts



## Revised Parts List

| REF   | PART #       | DESCRIPTION              |
|-------|--------------|--------------------------|
| 145V2 | P1021X2145V2 | SWITCH BOX V2.07.22      |
| 193V3 | P1021X2193V3 | SWITCH PEDESTAL V3.07.22 |

## Revised Assembly

Please follow the **Assembly** instructions in your **Owner's Manual**, beginning on **Page 19**. Due to changes to the switch box and switch pedestal, the G1021X2 now requires an additional step.

- 10. G1021X2 Only:** Remove (2) M5-.8 x 10 hex bolts from base of switch box, and rotate box 90 degrees so control panel faces front of machine. Re-install switch box to switch pedestal using hex bolts.



COPYRIGHT © FEBRUARY, 2022 BY GRIZZLY INDUSTRIAL, INC.  
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**  
#SS22230 PRINTED IN TAIWAN

\*\*\*Keep for Future Reference\*\*\*

# *Grizzly* **Industrial, Inc.**®

## MODEL G1021X2/G1021Z

### 15" PLANERS

### OWNER'S MANUAL

*(For models manufactured since 11/20)*



COPYRIGHT © SEPTEMBER, 2018 BY GRIZZLY INDUSTRIAL, INC. REVISED APRIL, 2021 (JL)  
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE  
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

#WK19745 PRINTED IN TAIWAN

V5.04.21

 **WARNING!**

**This manual provides critical safety instructions on the proper setup, operation, maintenance, and service of this machine/tool. Save this document, refer to it often, and use it to instruct other operators.**

**Failure to read, understand and follow the instructions in this manual may result in fire or serious personal injury—including amputation, electrocution, or death.**

**The owner of this machine/tool is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, cutting/sanding/grinding tool integrity, and the usage of personal protective equipment.**

**The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.**

 **WARNING!**

**Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:**

- **Lead from lead-based paints.**
- **Crystalline silica from bricks, cement and other masonry products.**
- **Arsenic and chromium from chemically-treated lumber.**

**Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.**

# Table of Contents

|  |           |  |           |
|--|-----------|--|-----------|
| <b>INTRODUCTION</b> .....                  | <b>2</b>  | <b>SECTION 5: ACCESSORIES</b> .....      | <b>32</b> |
| Contact Info.....                          | 2         | <b>SECTION 6: MAINTENANCE</b> .....      | <b>35</b> |
| Machine Description .....                  | 2         | Schedule.....                            | 35        |
| Manual Accuracy .....                      | 2         | Cleaning & Protecting .....              | 35        |
| Identification.....                        | 3         | Lubrication .....                        | 35        |
| Controls & Components.....                 | 4         | <b>SECTION 7: SERVICE</b> .....          | <b>38</b> |
| Internal Components.....                   | 5         | Troubleshooting .....                    | 38        |
| G1021X2 Machine Data Sheet.....            | 6         | Tensioning/Replacing V-Belts.....        | 41        |
| G1021Z Machine Data Sheet .....            | 8         | Pulley Alignment .....                   | 42        |
| <b>SECTION 1: SAFETY</b> .....             | <b>10</b> | Feed Rollers & Chip Breaker Heights..... | 43        |
| Safety Instructions for Machinery .....    | 10        | Adjusting Roller Spring Tension .....    | 46        |
| Additional Safety for Planers .....        | 12        | Positioning Chip Deflector .....         | 47        |
| <b>SECTION 2: POWER SUPPLY</b> .....       | <b>13</b> | Calibrating Table Elevation Scale.....   | 47        |
| <b>SECTION 3: SETUP</b> .....              | <b>15</b> | Checking Anti-Kickback Fingers .....     | 48        |
| Needed for Setup.....                      | 15        | Tensioning Table Height Chain .....      | 48        |
| Unpacking .....                            | 15        | Adjusting Table Parallelism .....        | 49        |
| Inventory .....                            | 16        | <b>SECTION 8: WIRING</b> .....           | <b>51</b> |
| Cleanup.....                               | 17        | Wiring Safety Instructions .....         | 51        |
| Site Considerations.....                   | 18        | G1021X2 Wiring Diagram.....              | 52        |
| Lifting & Placing.....                     | 19        | G1021X2 Electrical Components.....       | 53        |
| Assembly .....                             | 19        | G1021Z Wiring Diagram .....              | 54        |
| Dust Collection.....                       | 20        | G1021Z Electrical Components.....        | 55        |
| Checking Gearbox Oil Level.....            | 21        | <b>SECTION 9: PARTS</b> .....            | <b>56</b> |
| Test Run .....                             | 21        | G1021X2 Main.....                        | 56        |
| Recommended Adjustments.....               | 22        | G1021X2 Stand & Motor.....               | 59        |
| <b>SECTION 4: OPERATIONS</b> .....         | <b>23</b> | G1021X2 Table & Base.....                | 61        |
| Operation Overview .....                   | 23        | G1021X2 Labels & Cosmetics.....          | 63        |
| Workpiece Inspection.....                  | 24        | G1021Z Main .....                        | 64        |
| Wood Types.....                            | 24        | G1021Z Stand & Motor.....                | 67        |
| Planing Tips .....                         | 25        | G1021Z Table & Base .....                | 68        |
| Cutting Problems .....                     | 25        | G1021Z Labels & Cosmetics .....          | 70        |
| Depth of Cut.....                          | 26        | <b>WARRANTY &amp; RETURNS</b> .....      | <b>71</b> |
| Bed Roller Height.....                     | 27        |  |           |
| Setting Feed Rate.....                     | 28        |  |           |
| Adjusting/Replacing Knives .....           | 28        |  |           |
| Rotating/Replacing Cutterhead Inserts..... | 31        |  |           |

# INTRODUCTION

## Contact Info

We stand behind our machines! If you have questions or need help, contact us with the information below. Before contacting, make sure you get the **serial number** and **manufacture date** from the machine ID label. This will help us help you faster.

Grizzly Technical Support  
1815 W. Battlefield  
Springfield, MO 65807  
Phone: (570) 546-9663  
Email: techsupport@grizzly.com

We want your feedback on this manual. What did you like about it? Where could it be improved? Please take a few minutes to give us feedback.

Grizzly Documentation Manager  
P.O. Box 2069  
Bellingham, WA 98227-2069  
Email: manuals@grizzly.com

## Machine Description

Models G1021X2 and G1021Z are CSA-certified, 3 HP, 15" planers with the following differences:

- **Model G1021X2** has a helical cutterhead and a pedestal-mounted control panel with magnetic ON/OFF switch.
- **Model G1021Z** has a 3-knife cutterhead and a magnetic ON/OFF switch mounted to the cabinet stand.

## Manual Accuracy

We are proud to provide a high-quality owner's manual with your new machine!

We made every effort to be exact with the instructions, specifications, drawings, and photographs in this manual. Sometimes we make mistakes, but our policy of continuous improvement also means that **sometimes the machine you receive is slightly different than shown in the manual.**

If you find this to be the case, and the difference between the manual and machine leaves you confused or unsure about something, check our website for an updated version. We post current manuals and manual updates for free on our website at [www.grizzly.com](http://www.grizzly.com).



Alternatively, you can call our Technical Support for help. Before calling, make sure you write down the **Manufacture Date** and **Serial Number** from the machine ID label (see below). This information is required for us to provide proper tech support, and it helps us determine if updated documentation is available for your machine.

| Grizzly Industrial                 |                  | MODEL GXXXX<br>MACHINE NAME  |
|------------------------------------|------------------|--|
| SPECIFICATIONS                     |                  | ▲ WARNING!   |
| Motor:                             |                  | To reduce risk of serious injury when using this machine:  |
| Specification:                     | Manufacture Date | 1. Read manual before operation.   |
| Specification:                     |                  | 2. Wear safety glasses and respirator.   |
| Specification:                     |                  | 3. Make sure power is connected to grounded circuit before starting.                                 |
| Specification:                     |                  | 4. Make sure the motor has stopped and disconnect power before adjustments, maintenance, or service. |
| Weight:                            |                  | 5. DO NOT expose to rain or dampness.  |
|                                    | Date             | 6. DO NOT modify this machine in any way.  |
|                                    |                  | 7.   |
|                                    |                  | 8.   |
|                                    |                  | 9. Serial Number   |
|                                    |                  | 10. Maintain machine carefully to prevent accidents.   |
| Manufactured for Grizzly in Taiwan |                  |  |



# Identification

Become familiar with the names and locations of the controls and features shown below to better understand the instructions in this manual.



## **! WARNING**

To reduce your risk of serious injury, read this entire manual **BEFORE** using machine.






# Controls & Components



Refer to **Figures 1–3** and the following descriptions to become familiar with the basic controls and components of this machine. Understanding these items and how they work will help you understand the rest of the manual and stay safe when operating this machine.



**Figure 1.** Table elevation and feed controls.

**A. Control Panel for Magnetic Switch (G1021X2):**

- Green **START** button turns motor **ON** when pressed.
- Power indicator light illuminates when motor turned **ON**.
- Red **STOP** button turns motor **OFF** when pressed; for safety purposes, this button will remain depressed and prevent restarting until reset. Reset by rotating clockwise until it pops out.

**B. Table Height Handwheel:** Raises and lowers table to accommodate different workpiece thicknesses. One complete revolution moves the table approximately 2mm (0.08").

**C. Table Locks:** Secure table height position.

**D. Depth Limiter:** Limits depth of cut to a maximum of 1/8" at full width.

**E. Feed Rate Control Knob:** Selects 28 FPM feed rate when pushed in and 16 FPM feed rate when pulled out.

**F. Magnetic ON/OFF Switch (G1021Z):**

- Green start button turns motor **ON** when pressed.
- Red Stop button turns motor **OFF** when pressed; for safety purposes, this button will remain depressed and prevent restarting until reset. Reset by rotating clockwise until it pops out.




**Figure 2.** Example of return rollers and dust port.

**G. Return Rollers:** Assist sliding workpiece back to operator following planing operation.

**H. Dust Port:** Connects to a dust collection system to extract shavings and dust during operation. Dust port size 4".



# Internal Components



**Figure 3.** Workpiece path and major planing components (side cutaway view).

- A. Anti-Kickback Fingers:** Provide additional safety for the operator.
- B. Serrated Infeed Roller:** Pulls the workpiece toward the cutterhead.
- C. Chip Breaker:** Breaks off chips created by the cutterhead to prevent tear out and diverts the chips to the dust port.
- D. Cutterhead:** Holds the knives/inserts that remove material from the workpiece.
- E. Chip Deflector:** Directs chips into the dust port.
- F. Outfeed Roller:** Pulls the workpiece through the planer.
- G. Planer Table:** Provides a smooth and level path for the workpiece as it moves through the planer.

## **WARNING**

Like all machinery there is potential danger when operating this machine. Accidents are frequently caused by lack of familiarity or failure to pay attention. Use this machine with respect and caution to decrease the risk of operator injury. If normal safety precautions are overlooked or ignored, serious personal injury may occur.







# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

## MODEL G1021X2 15" 3 HP EXTREME SERIES PLANER W/ HELICAL CUTTERHEAD

### Product Dimensions:

Weight..... 476 lbs.  
Width (side-to-side) x Depth (front-to-back) x Height..... 37 x 48 x 44 in.  
Footprint (Length x Width)..... 22-1/2 x 21-1/2 in.

### Shipping Dimensions:

Type..... Wood Crate  
Content..... Machine  
Weight..... 553 lbs.  
Length x Width x Height..... 29 x 36 x 52 in.  
Must Ship Upright..... Yes

### Electrical:

Power Requirement..... 230V, Single-Phase, 60 Hz  
Full-Load Current Rating..... 12A  
Minimum Circuit Size..... 20A  
Connection Type..... Cord & Plug  
Power Cord Included..... Yes  
Power Cord Length..... 10 ft.  
Power Cord Gauge..... 12 AWG  
Plug Included..... Yes  
Included Plug Type..... 6-20  
Switch Type..... Magnetic Switch w/Thermal Overload Protection

### Motors:

#### Main

Horsepower..... 3 HP  
Phase..... Single-Phase  
Amps..... 12A  
Speed..... 3450 RPM  
Type..... TEFC Capacitor-Start Induction  
Power Transfer ..... Triple V-Belt Drive  
Bearings..... Shielded & Permanently Lubricated  
Centrifugal Switch/Contacts Type..... External



**Main Specifications:**

**Main Specifications**

|   |            |
|---|------------|
| Planer Size.....                              | 15 in.     |
| Max. Cut Width.....                           | 15 in.     |
| Max. Cut Height.....                          | 6 in.      |
| Min. Stock Length.....                        | 6 in.      |
| Min. Stock Thickness.....                     | 3/16 in.   |
| Max. Stock Thickness.....                     | 6-1/8 in.  |
| Number of Cuts Per Inch.....                  | 104, 83    |
| Number of Cuts Per Minute.....                | 20,000     |
| Cutterhead Speed.....                         | 5000 RPM   |
| Planing Feed Rate.....                        | 16, 28 FPM |
| Max. Cut Depth Planing Full Width.....        | 3/32 in.   |
| Max. Cut Depth Planing 6-Inch Wide Board..... | 1/8 in.    |

**Cutterhead Info**

|                                   |         |
|-----------------------------------|---------|
| Cutterhead Type.....              | Helical |
| Cutterhead Diameter .....         | 3 in.   |
| Number of Cutter Rows.....        | 4       |
| Number of Indexable Cutters.....  | 52      |
| Cutter Insert Size Length.....    | 15mm    |
| Cutter Insert Size Width.....     | 15mm    |
| Cutter Insert Size Thickness..... | 2.5mm   |

**Table Info**

|                               |             |
|-------------------------------|-------------|
| Table/Headstock Movement..... | 6 in.       |
| Table Bed Size Length.....    | 48 in.      |
| Table Bed Size Width.....     | 15 in.      |
| Table Bed Size Thickness..... | 2 in.       |
| Number of Bed Rollers.....    | 2           |
| Floor-to-Table Height.....    | 29 – 35 in. |
| Table Wings Size Length.....  | 14 in.      |
| Table Wings Size Width.....   | 15-1/16 in. |

**Construction**

|                          |                            |
|--------------------------|----------------------------|
| Table.....               | Precision-Ground Cast Iron |
| Body.....                | Cast Iron                  |
| Stand.....               | Steel                      |
| Cutterhead Assembly..... | Steel                      |
| Infeed Roller.....       | Serrated Steel             |
| Outfeed Roller.....      | Smooth Steel               |
| Paint Type/Finish.....   | Powder Coated              |

**Other**

|                            |               |
|----------------------------|---------------|
| Table/Headstock Locks..... | Yes           |
| Measurement Scale.....     | Inch & Metric |
| Number of Dust Ports.....  | 1             |
| Dust Port Size.....        | 4 in.         |
| Mobile Base.....           | D2057A        |

**Other Specifications:**

|  |                         |
|--|-------------------------|
| Country of Origin .....  | Taiwan                  |
| Warranty .....   | 1 Year                  |
| Approximate Assembly & Setup Time .....                              | 1 Hour                  |
| Serial Number Location .....   | ID Label on Upper Cover |
| ISO 9001 Factory .....   | Yes                     |
| Certified by a Nationally Recognized Testing Laboratory (NRTL) ..... | Yes                     |





# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

## MODEL G1021Z 15" 3 HP PLANER W/ CABINET STAND

### Product Dimensions:

Weight..... 474 lbs.  
 Width (side-to-side) x Depth (front-to-back) x Height..... 32 x 48 x 44 in.  
 Footprint (Length x Width)..... 21-1/2 x 21 in.

### Shipping Dimensions:

Type..... Wood Crate  
 Content..... Machine  
 Weight..... 552 lbs.  
 Length x Width x Height..... 30 x 27 x 51 in.  
 Must Ship Upright..... Yes

### Electrical:

Power Requirement..... 230V, Single-Phase, 60 Hz  
 Full-Load Current Rating..... 12A  
 Minimum Circuit Size..... 20A  
 Connection Type..... Cord & Plug  
 Power Cord Included..... Yes  
 Power Cord Length..... 10 ft.  
 Power Cord Gauge..... 12 AWG  
 Plug Included..... Yes  
 Included Plug Type..... 6-20  
 Switch Type..... Magnetic Switch w/Thermal Overload Protection

### Motors:

#### Main

Horsepower..... 3 HP  
 Phase..... Single-Phase  
 Amps..... 12A  
 Speed..... 3450 RPM  
 Type..... TEFC Capacitor-Start Induction  
 Power Transfer ..... Triple V-Belt Drive  
 Bearings..... Shielded & Permanently Lubricated  
 Centrifugal Switch/Contacts Type..... External

### Main Specifications:

#### Main Specifications

Planer Size..... 15 in.  
 Max. Cut Width..... 15 in.  
 Max. Cut Height..... 6 in.  
 Min. Stock Length..... 6 in.  
 Min. Stock Thickness..... 3/16 in.  
 Max. Stock Thickness..... 6 in.  
 Number of Cuts Per Inch..... 78, 63  
 Number of Cuts Per Minute..... 15,000  
 Cutterhead Speed..... 5000 RPM  
 Planing Feed Rate..... 16, 28 FPM  
 Max. Cut Depth Planing Full Width..... 3/32 in.  
 Max. Cut Depth Planing 6-Inch Wide Board..... 1/8 in.



**Cutterhead Info**

|                           |                          |
|---------------------------|--------------------------|
| Cutterhead Type.....      | 3 Knife                  |
| Cutterhead Diameter ..... | 3 in.                    |
| Number of Knives.....     | 3                        |
| Knife Type.....           | HSS, Single-Sided, Solid |
| Knife Size Length.....    | 15 in.                   |
| Knife Size Width.....     | 1 in.                    |
| Knife Size Thickness..... | 1/8 in.                  |
| Knife Adjustment.....     | Springs or Jack Screws   |

**Table Info**

|                               |             |
|-------------------------------|-------------|
| Table/Headstock Movement..... | 6 in.       |
| Table Bed Size Length.....    | 20 in.      |
| Table Bed Size Width.....     | 15 in.      |
| Table Bed Size Thickness..... | 2 in.       |
| Number of Bed Rollers.....    | 2           |
| Floor-to-Table Height.....    | 29 – 35 in. |
| Table Wings Size Length.....  | 14 in.      |
| Table Wings Size Width.....   | 15-1/16 in. |

**Construction**

|                          |                            |
|--------------------------|----------------------------|
| Table.....               | Precision-Ground Cast Iron |
| Body.....                | Cast Iron                  |
| Stand.....               | Steel                      |
| Cutterhead Assembly..... | Steel                      |
| Infeed Roller.....       | Serrated Steel             |
| Outfeed Roller.....      | Smooth Steel               |
| Paint Type/Finish.....   | Powder Coated              |

**Other**

|                            |               |
|----------------------------|---------------|
| Table/Headstock Locks..... | Yes           |
| Measurement Scale.....     | Inch & Metric |
| Number of Dust Ports.....  | 1             |
| Dust Port Size.....        | 4 in.         |
| Mobile Base.....           | T28000        |

**Other Specifications:**

|  |                         |
|--|-------------------------|
| Country of Origin .....  | Taiwan                  |
| Warranty .....   | 1 Year                  |
| Approximate Assembly & Setup Time .....                              | 1 Hour                  |
| Serial Number Location .....   | ID Label on Upper Cover |
| ISO 9001 Factory .....   | Yes                     |
| Certified by a Nationally Recognized Testing Laboratory (NRTL) ..... | Yes                     |

**Features:**

- Extra-Large Ball Bearing Return Rollers
- Large Side-Mounted Handwheel
- Cabinet Style Stand
- Internally Mounted 3HP Motor
- Triple Belt Drive Inside Housing
- Magnetic Switch with Prominent Off Switch
- All Ball Bearing Construction
- 4 Heavy-Duty Support Columns
- Anti-Kickback Fingers
- Drive Gears Run in Oil Bath
- Precision-Ground Cast-Iron Table & Extension Wings
- Includes Knife-Setting Jig
- Powder Coated Finish



# SECTION 1: SAFETY

## For Your Own Safety, Read Instruction Manual Before Operating This Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures. Always use common sense and good judgment.

**⚠ DANGER** Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.

**⚠ WARNING** Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

**⚠ CAUTION** Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

**NOTICE** Alerts the user to useful information about proper operation of the machine to avoid machine damage.

## Safety Instructions for Machinery

### ⚠ WARNING

**OWNER'S MANUAL.** Read and understand this owner's manual **BEFORE** using machine.

**TRAINED OPERATORS ONLY.** Untrained operators have a higher risk of being hurt or killed. Only allow trained/supervised people to use this machine. When machine is not being used, disconnect power, remove switch keys, or lock-out machine to prevent unauthorized use—especially around children. Make your workshop kid proof!

**DANGEROUS ENVIRONMENTS.** Do not use machinery in areas that are wet, cluttered, or have poor lighting. Operating machinery in these areas greatly increases the risk of accidents and injury.

**MENTAL ALERTNESS REQUIRED.** Full mental alertness is required for safe operation of machinery. Never operate under the influence of drugs or alcohol, when tired, or when distracted.

**ELECTRICAL EQUIPMENT INJURY RISKS.** You can be shocked, burned, or killed by touching live electrical components or improperly grounded machinery. To reduce this risk, only allow qualified service personnel to do electrical installation or repair work, and always disconnect power before accessing or exposing electrical equipment.

**DISCONNECT POWER FIRST.** Always disconnect machine from power supply **BEFORE** making adjustments, changing tooling, or servicing machine. This prevents an injury risk from unintended startup or contact with live electrical components.

**EYE PROTECTION.** Always wear ANSI-approved safety glasses or a face shield when operating or observing machinery to reduce the risk of eye injury or blindness from flying particles. Everyday eyeglasses are **NOT** approved safety glasses.



# WARNING

**WEARING PROPER APPAREL.** Do not wear clothing, apparel or jewelry that can become entangled in moving parts. Always tie back or cover long hair. Wear non-slip footwear to reduce risk of slipping and losing control or accidentally contacting cutting tool or moving parts.

**HAZARDOUS DUST.** Dust created by machinery operations may cause cancer, birth defects, or long-term respiratory damage. Be aware of dust hazards associated with each workpiece material. Always wear a NIOSH-approved respirator to reduce your risk.

**HEARING PROTECTION.** Always wear hearing protection when operating or observing loud machinery. Extended exposure to this noise without hearing protection can cause permanent hearing loss.

**REMOVE ADJUSTING TOOLS.** Tools left on machinery can become dangerous projectiles upon startup. Never leave chuck keys, wrenches, or any other tools on machine. Always verify removal before starting!

**USE CORRECT TOOL FOR THE JOB.** Only use this tool for its intended purpose—do not force it or an attachment to do a job for which it was not designed. Never make unapproved modifications—modifying tool or using it differently than intended may result in malfunction or mechanical failure that can lead to personal injury or death!

**AWKWARD POSITIONS.** Keep proper footing and balance at all times when operating machine. Do not overreach! Avoid awkward hand positions that make workpiece control difficult or increase the risk of accidental injury.

**CHILDREN & BYSTANDERS.** Keep children and bystanders at a safe distance from the work area. Stop using machine if they become a distraction.

**GUARDS & COVERS.** Guards and covers reduce accidental contact with moving parts or flying debris. Make sure they are properly installed, undamaged, and working correctly BEFORE operating machine.

**FORCING MACHINERY.** Do not force machine. It will do the job safer and better at the rate for which it was designed.

**NEVER STAND ON MACHINE.** Serious injury may occur if machine is tipped or if the cutting tool is unintentionally contacted.

**STABLE MACHINE.** Unexpected movement during operation greatly increases risk of injury or loss of control. Before starting, verify machine is stable and mobile base (if used) is locked.

**USE RECOMMENDED ACCESSORIES.** Consult this owner's manual or the manufacturer for recommended accessories. Using improper accessories will increase the risk of serious injury.

**UNATTENDED OPERATION.** To reduce the risk of accidental injury, turn machine **OFF** and ensure all moving parts completely stop before walking away. Never leave machine running while unattended.

**MAINTAIN WITH CARE.** Follow all maintenance instructions and lubrication schedules to keep machine in good working condition. A machine that is improperly maintained could malfunction, leading to serious personal injury or death.

**DAMAGED PARTS.** Regularly inspect machine for damaged, loose, or mis-adjusted parts—or any condition that could affect safe operation. Immediately repair/replace BEFORE operating machine. For your own safety, DO NOT operate machine with damaged parts!

**MAINTAIN POWER CORDS.** When disconnecting cord-connected machines from power, grab and pull the plug—NOT the cord. Pulling the cord may damage the wires inside. Do not handle cord/plug with wet hands. Avoid cord damage by keeping it away from heated surfaces, high traffic areas, harsh chemicals, and wet/damp locations.

**EXPERIENCING DIFFICULTIES.** If at any time you experience difficulties performing the intended operation, stop using the machine! Contact our Technical Support at (570) 546-9663.





# Additional Safety for Planers

## WARNING

**Amputation, serious cuts, entanglement, or death can occur from contact with rotating cutterhead or other moving parts! Flying chips can cause eye injuries or blindness. Workpieces or knives thrown by cutterhead can strike nearby operator or bystanders with deadly force. To reduce the risk of these hazards, operator and bystanders MUST completely heed hazards and warnings below.**

**KICKBACK.** Know how to reduce risk of kickback and kickback-related injuries. “Kickback” occurs during operation when the workpiece is ejected back through infeed side of machine at a high rate of speed. Kickback is commonly caused by poor workpiece selection, unsafe feeding techniques, or improper machine setup/maintenance. Kickback injuries typically occur as follows: (1) operator/bystanders are struck by workpiece, resulting in impact injuries (i.e., blindness, broken bones, bruises, death); (2) operator’s hands are pulled into blade from outfeed side, resulting in amputation or severe lacerations.

**AVOID CONTACT WITH MOVING PARTS.** Never remove guards/covers or reach inside planer during operation or while connected to power. You could be seriously injured if you accidentally touch spinning cutterhead or get entangled in moving parts. If a workpiece becomes stuck or sawdust removal is necessary, turn planer **OFF**, allow cutterhead to stop, disconnect power before clearing.

**DULL/DAMAGED KNIVES/INSERTS.** Only use sharp, undamaged knives/inserts. Dull or damaged knives/inserts increase the risk of kickback.

**INSPECTING STOCK.** To reduce the risk of kickback injuries or machine damage, thoroughly inspect and prepare the workpiece before cutting. Verify workpiece is free of nails, staples, loose knots, or foreign material. Workpieces with minor warping should be jointed first or planed with the cupped side facing the table.

**BODY PLACEMENT.** Stand to one side of planer during entire operation to avoid getting hit if kickback occurs.

**GRAIN DIRECTION.** Planing across grain is hard on planer and may cause kickback. Plane in same direction or at a slight angle with wood grain.

**PLANING CORRECT MATERIAL.** Only plane natural wood stock with this planer. DO NOT plane MDF, OSB, plywood, laminates or other synthetic materials that can break up inside the planer and be ejected towards the operator.

**LOOKING INSIDE PLANER.** Wood chips fly around inside the planer at a high rate of speed during operation. To avoid injury from flying material, DO NOT look inside planer during operation.

**CUTTING LIMITATIONS.** To reduce the risk of kickback hazards or damage to the machine, do not exceed the maximum depth of cut or minimum board length and thickness found in the **Data Sheet**. Only feed one board at a time.

**INFEED ROLLER CLEARANCE.** The infeed roller is designed to pull material into the spinning cutterhead. To reduce the risk of entanglement, keep hands, clothing, jewelry, and long hair away from the infeed roller during operation.

**FEED WORKPIECE PROPERLY.** To reduce the risk of kickback, never start planer with workpiece touching cutterhead. Allow cutterhead to reach full speed before feeding, and do not change feed speed during cutting operation.

**WORKPIECE SUPPORT.** To reduce the risk of kickback, always make sure workpiece can move completely across table without rocking or tipping. Use auxiliary support stands for long stock.


**SECURE KNIVES/INSERTS.** Loose knives or improperly set inserts can become dangerous projectiles or cause machine damage. Always verify knives/inserts are secure and properly adjusted before operation.



# SECTION 2: POWER SUPPLY

## Availability

Before installing the machine, consider the availability and proximity of the required power supply circuit. If an existing circuit does not meet the requirements for this machine, a new circuit must be installed. To minimize the risk of electrocution, fire, or equipment damage, installation work and electrical wiring must be done by an electrician or qualified service personnel in accordance with all applicable codes and standards.



## Full-Load Current Rating

The full-load current rating is the amperage a machine draws at 100% of the rated output power. On machines with multiple motors, this is the amperage drawn by the largest motor or sum of all motors and electrical devices that might operate at one time during normal operations.

### Full-Load Current Rating ..... 12 Amps

The full-load current is not the maximum amount of amps that the machine will draw. If the machine is overloaded, it will draw additional amps beyond the full-load rating.

If the machine is overloaded for a sufficient length of time, damage, overheating, or fire may result—especially if connected to an undersized circuit. To reduce the risk of these hazards, avoid overloading the machine during operation and make sure it is connected to a power supply circuit that meets the specified circuit requirements.

## Circuit Requirements for 240V

This machine is prewired to operate on a power supply circuit that has a verified ground and meets the following requirements:

**Nominal Voltage ..... 208V, 220V, 230V, 240V**  
**Cycle ..... 60 Hz**  
**Phase ..... 1-Phase**  
**Power Supply Circuit ..... 20 Amps**  
**Plug/Receptacle ..... NEMA 6-20**  
**Cord ..... “S”-Type, 3-Wire, 14 AWG, 300 VAC**

A power supply circuit includes all electrical equipment between the breaker box or fuse panel in the building and the machine. The power supply circuit used for this machine must be sized to safely handle the full-load current drawn from the machine for an extended period of time. (If this machine is connected to a circuit protected by fuses, use a time delay fuse marked D.)



**Note:** *Circuit requirements in this manual apply to a dedicated circuit—where only one machine will be running on the circuit at a time. If machine will be connected to a shared circuit where multiple machines may be running at the same time, consult an electrician or qualified service personnel to ensure circuit is properly sized for safe operation.*



## Grounding Instructions

This machine **MUST** be grounded. In the event of certain malfunctions or breakdowns, grounding reduces the risk of electric shock by providing a path of least resistance for electric current.

The power cord and plug specified under “Circuit Requirements for 220V” on the previous page has an equipment-grounding wire and a grounding prong. The plug must only be inserted into a matching receptacle (outlet) that is properly installed and grounded in accordance with all local codes and ordinances (see figure below).





Figure 4. Typical 6-20 plug and receptacle.

## **!WARNING**

**Serious injury could occur if you connect machine to power before completing setup process. DO NOT connect to power until instructed later in this manual.**

## **!CAUTION**



**No adapter should be used with plug. If plug does not fit available receptacle, or if machine must be reconnected for use on a different type of circuit, reconnection must be performed by an electrician or qualified service personnel, and it must comply with all local codes and ordinances.**

## **!WARNING**

**Serious injury could occur if you connect machine to power before completing setup process. DO NOT connect to power until instructed later in this manual.**

Improper connection of the equipment-grounding wire can result in a risk of electric shock. The wire with green insulation (with or without yellow stripes) is the equipment-grounding wire. If repair or replacement of the power cord or plug is necessary, do not connect the equipment-grounding wire to a live (current carrying) terminal.

Check with a qualified electrician or service personnel if you do not understand these grounding requirements, or if you are in doubt about whether the tool is properly grounded. If you ever notice that a cord or plug is damaged or worn, disconnect it from power, and immediately replace it with a new one.

## Extension Cords

We do not recommend using an extension cord with this machine. If you must use an extension cord, only use it if absolutely necessary and only on a temporary basis.


Extension cords cause voltage drop, which can damage electrical components and shorten motor life. Voltage drop increases as the extension cord size gets longer and the gauge size gets smaller (higher gauge numbers indicate smaller sizes).

Any extension cord used with this machine must be in good condition and contain a ground wire and matching plug/receptacle. Additionally, it must meet the following size requirements:

**Minimum Gauge Size .....12 AWG  
Maximum Length (Shorter is Better).....50 ft.**




# SECTION 3: SETUP



**!WARNING**  
 This machine presents serious injury hazards to untrained users. Read through this entire manual to become familiar with the controls and operations before starting the machine!



**!WARNING**  
 Wear safety glasses during the entire setup process!



**!WARNING**  
**HEAVY LIFT!**  
 Straining or crushing injury may occur from improperly lifting machine or some of its parts. To reduce this risk, get help from other people and use a forklift (or other lifting equipment) rated for weight of this machine.

## Needed for Setup

The following items are needed, but not included, for the setup/assembly of this machine.

| Description                                   | Qty          |
|---|--------------|
| • Additional People .....                     | 1            |
| • Safety Glasses .....                        | 1 Per Person |
| • Forklift (rated for at least 750 lbs.)..... | 1            |
| • Cleaner/Degreaser ( <b>Page 17</b> ) ....   | As Needed    |
| • Disposable Shop Rags.....                   | As Needed    |
| • Phillips Screwdriver #2 .....               | 1            |
| • Flat Head Screwdriver .....                 | 1            |
| • Wrench or Socket 12mm, 14mm .....           | 1 Ea.        |
| • Hex Wrenches 3, 4, 5, 6, 8mm .....          | 1 Ea.        |
| • Straightedge 4' .....                       | 1            |
| • Dust-Collection System .....                | 1            |
| • 4" Dust Hose (length as needed) .....       | 1            |
| • 4" Hose Clamps .....                        | 2            |
| • Gearbox Oil .....                           | As Needed    |

## Unpacking

This machine was carefully packaged for safe transport. When unpacking, separate all enclosed items from packaging materials and inspect them for shipping damage. ***If items are damaged, please call us immediately at (570) 546-9663.***

**IMPORTANT:** Save all packaging materials until you are completely satisfied with the machine and have resolved any issues between Grizzly or the shipping agent. ***You MUST have the original packaging to file a freight claim. It is also extremely helpful if you need to return your machine later.***



# Inventory

The following is a list of items shipped with your machine. Before beginning setup, lay these items out and inventory them.

If any non-proprietary parts are missing (e.g. a nut or a washer), we will gladly replace them; or for the sake of expediency, replacements can be obtained at your local hardware store.

## NOTICE

If you cannot find an item on this list, carefully check around/inside the machine and packaging materials. Often, these items get lost in packaging materials while unpacking or they are pre-installed at the factory.

| Box 1 (Figure 5)                    | Qty |
|-------------------------------------|-----|
| A. Planer Unit (Not Shown).....     | 1   |
| B. Cast-Iron Extension Tables ..... | 2   |
| C. Table Elevation Handwheel .....  | 1   |
| D. Dust Port .....                  | 1   |

### Tools and Hardware (Figure 6)

|  |       |
|--|-------|
| E. Hex Wrenches 3, 4, 6mm .....                | 1 Ea. |
| F. Hex Bolts M8-1.25 x 25 (Ext. Tables) .....  | 6     |
| G. Set Screws M8-1.25 x 12 (Ext. Tables) ..... | 6     |
| H. Flange Bolts M6-1 x 12 (Dust Port).....     | 6     |
| I. LOW/HIGH Direction Label (Handwheel)...     | 1     |
| J. Hex Nut M10-1.25 (Handwheel).....           | 1     |
| K. Key 4 x 4 x 10 (Handwheel).....             | 1     |
| L. Flat Washers 8mm (Ext. Tables).....         | 6     |
| M. Flat Washers 10mm (Handwheel).....          | 1     |
| N. Handwheel Handle (Handwheel) .....          | 1     |
| O. Open-End Wrenches 10/13, 12/14mm..          | 1 Ea. |

### G1021X2 Only (Figure 7)

|  |    |
|--|----|
| P. T-Handle Torx Drivers T-25 .....              | 2  |
| Q. Flat Head Torx Screws #10-32 x 1/2" .....     | 10 |
| R. Indexable Carbide Inserts 15 x 15 x 2.5 ..... | 5  |

### G1021Z Only (Figure 8)

|                            |   |
|----------------------------|---|
| S. Knife-Setting Jig ..... | 1 |
| —E-Clips 9mm .....         | 4 |
| —Jig Feet .....            | 2 |
| —Jig Shaft.....            | 1 |




Figure 5. Box inventory.




Figure 6. Tools and hardware.




Figure 7. Tools and hardware (G1021X2 only).




Figure 8. Tools and hardware (G1021Z only).





# Cleanup

The unpainted surfaces of your machine are coated with a heavy-duty rust preventative that prevents corrosion during shipment and storage. This rust preventative works extremely well, but it will take a little time to clean.

Be patient and do a thorough job cleaning your machine. The time you spend doing this now will give you a better appreciation for the proper care of your machine's unpainted surfaces.




There are many ways to remove this rust preventative, but the following steps work well in a wide variety of situations. Always follow the manufacturer's instructions with any cleaning product you use and make sure you work in a well-ventilated area to minimize exposure to toxic fumes.

## Before cleaning, gather the following:

- Disposable rags
- Cleaner/degreaser (WD•40 works well)
- Safety glasses & disposable gloves
- Plastic paint scraper (optional)

## Basic steps for removing rust preventative:

1. Put on safety glasses.
2. Coat the rust preventative with a liberal amount of cleaner/degreaser, then let it soak for 5–10 minutes.
3. Wipe off the surfaces. If your cleaner/degreaser is effective, the rust preventative will wipe off easily. If you have a plastic paint scraper, scrape off as much as you can first, then wipe off the rest with the rag.
4. Repeat **Steps 2–3** as necessary until clean, then coat all unpainted surfaces with a quality metal protectant to prevent rust.



## T23692—Orange Power Degreaser

A great product for removing the waxy shipping grease from the **non-painted** parts of the machine during clean up.



Figure 9. T23692 Orange Power Degreaser.





# Site Considerations

## Weight Load

Refer to the **Machine Data Sheet** for the weight of your machine. Make sure that the surface upon which the machine is placed will bear the weight of the machine, additional equipment that may be installed on the machine, and the heaviest workpiece that will be used. Additionally, consider the weight of the operator and any dynamic loading that may occur when operating the machine.

## Space Allocation

Consider the largest size of workpiece that will be processed through this machine and provide enough space around the machine for adequate operator material handling or the installation of auxiliary equipment. With permanent installations, leave enough space around the machine to open or remove doors/covers as required by the maintenance and service described in this manual. **See below for required space allocation.**



## Physical Environment


The physical environment where the machine is operated is important for safe operation and longevity of machine components. For best results, operate this machine in a dry environment that is free from excessive moisture, hazardous chemicals, airborne abrasives, or extreme conditions. Extreme conditions for this type of machinery are generally those where the ambient temperature range exceeds 41°–104°F; the relative humidity range exceeds 20%–95% (non-condensing); or the environment is subject to vibration, shocks, or bumps.

## Electrical Installation

Place this machine near an existing power source. Make sure all power cords are protected from traffic, material handling, moisture, chemicals, or other hazards. Make sure to leave enough space around machine to disconnect power supply or apply a lockout/tagout device, if required.

## Lighting


Lighting around the machine must be adequate enough that operations can be performed safely. Shadows, glare, or strobe effects that may distract or impede the operator must be eliminated.



**Figure 10.** Minimum working clearances for Models G1021Z and G1021X2.




# Lifting & Placing



The planer is equipped with four lifting bars that extend in order to lift and place the planer.

To lift and place the planer, extend the lifting bars and use a forklift to lift the machine off the pallet, as shown in **Figure 11**, then set the planer down in a suitable location and return the lifting bars to their original position.

**Tip:** When positioning lift forks, place shop rags or cardboard between forks and cabinet stand to avoid scratching paint.




**Figure 11.** Example of lifting planer with forklift.

# Assembly

The machine must be fully assembled before it can be operated. Before beginning the assembly process, refer to **Needed for Setup** and gather all listed items. To ensure the assembly process goes smoothly, first clean any parts that are covered or coated in heavy-duty rust preventative (if applicable).

## To assemble planer:

1. Attach each cast-iron extension table to planer table with (3) M8-1.25 x 25 hex bolts and (3) 8mm flat washers. Do not fully tighten hex bolts at this time.
2. Thread (3) M8-1.25 x 12 set screws into each extension table at locations shown in **Figure 12**.



**Figure 12.** Extension table mounting locations.


3. Using a straightedge as a guide, rotate set screws until extension tables are in plane with main table, then fully tighten hex bolts installed during **Step 1** on **Page 19**.

**Note:** Bed rollers will give you a false reading with your straightedge if they are raised above table. Move them down or work around them when leveling extension wings (refer to **Bed Roller Height** on **Page 27** for details).

4. Insert key into keyway on handwheel shaft on top of planer.
5. Line up notch in handwheel bore with key, then slide handwheel onto shaft.




- Slide LOW/HIGH direction label onto handwheel shaft, and secure handwheel with 10mm flat washer and M10-1.25 hex nut (see **Figure 13**).
- Thread handwheel handle into handwheel (see **Figure 13**), and tighten with wrench.



**Figure 13.** Table elevation handwheel installed.

- Attach dust port to planer with (6) M6-1 x 12 flange bolts (see **Figure 14**).



**Figure 14.** Dust port installed.

- G1021Z Only:** Assemble knife-setting jig using knife-setting shaft, feet, and 9mm E-clips, as shown in **Figure 15**.



**Figure 15.** Knife-setting jig assembled.

## Dust Collection

### ⚠ CAUTION


This machine creates a lot of wood chips/dust during operation. Breathing airborne dust on a regular basis can result in permanent respiratory illness. Reduce your risk by wearing a respirator and capturing the dust with a dust-collection system.

#### Minimum CFM at Dust Port: 400 CFM

Do not confuse this CFM recommendation with the rating of the dust collector. To determine the CFM at the dust port, you must consider these variables: (1) CFM rating of the dust collector, (2) hose type and length between the dust collector and the machine, (3) number of branches or wyes, and (4) amount of other open lines throughout the system. Explaining how to calculate these variables is beyond the scope of this manual. Consult an expert or purchase a good dust-collection "how-to" book.

To connect the machine to a dust-collection system, fit a 4" dust hose over the dust port, and secure in place with a hose clamp (see **Figure 16**). Tug the hose to make sure it does not come off.

**Note:** A tight fit is necessary for proper performance.



**Figure 16.** Example of dust hose connected to dust port.




# Checking Gearbox Oil Level

Before starting your machine for the first time, check the gearbox oil level. The proper oil level is just even with the bottom of the fill plug hole. The gearbox uses ISO 320, SAE 140 gear oil, or SAE 85W-140 multi-weight gear oil. DO NOT mix oil types.

**Note:** For easier access to the fill plug, remove the drive chain cover (see **Figure 17**).

## To check gearbox oil level:

1. Remove gearbox fill plug (see **Figure 17**).



**Figure 17.** Location of gearbox fill plug.

2. Dip short end of a clean 6mm hex wrench inside fill hole, and then remove it.

— If the end of the hex wrench *is* coated with oil, then the gearbox oil level is okay. Replace the fill plug and continue setup.

— If the end of the hex wrench *is not* coated with oil, then you need to add more oil. Refer to **Gearbox Oil** on **Page 37** for instructions on how to do this.

**Note:** We recommend that you replace the gearbox oil after the first 20 hours of operation. This is a normal break-in procedure and will help maximize the service life of the machine by flushing away any particles from the break-in and manufacturing process.

# Test Run

Once assembly is complete, test run the machine to ensure it is properly connected to power and safety components are functioning correctly.

If you find an unusual problem during the test run, immediately stop the machine, disconnect it from power, and fix the problem **BEFORE** operating the machine again. The **Troubleshooting** table in the **SERVICE** section of this manual can help.

The Test Run consists of verifying the following:  
1) The motor powers up and runs correctly, and  
2) the STOP/reset button safety feature functions properly.

## **!WARNING**

Serious injury or death can result from using this machine **BEFORE** understanding its controls and related safety information. **DO NOT** operate, or allow others to operate, machine until the information is understood.


## **!WARNING**

**DO NOT** start machine until all preceding setup instructions have been performed. Operating an improperly set up machine may result in malfunction or unexpected results that can lead to serious injury, death, or machine/property damage.



### To test run machine:

1. Clear all setup tools and loose objects away from machine.
2. Push STOP button in.
3. Connect machine to power supply.
4. Twist STOP button clockwise until it springs out (see **Figure 18**). This resets the switch so the machine can start.



**Figure 18.** Resetting the switch.

5. Press START button to turn machine **ON**. Verify motor starts up and runs smoothly without any unusual problems or noises.
6. Press STOP button to turn machine **OFF**.
7. WITHOUT resetting STOP button, try to start machine by pressing the START button. The machine should not start.

— If the machine *does not* start, the STOP button safety feature is working correctly. Congratulations! Test Run is complete.

— If the machine *does* start with the STOP button pushed in, immediately disconnect power to the machine. The STOP button safety feature is not working correctly and must be replaced before further using the machine. Call Tech Support for help.

## Recommended Adjustments

The adjustments listed below have been performed at the factory. However, because of the many variables involved with shipping, we recommend that you verify the adjustments to ensure the best possible results from your new machine.

Step-by-step instructions for these adjustments can be found in the **SERVICE** section starting on **Page 38**.

### Factory adjustments that should be verified:

- Tensioning/replacing V-belts (**Page 41**).
- Calibrating table elevation scale (**Page 47**).
- Pulley alignment (**Page 42**).

## **NOTICE**

**After approximately 16 hours of operation, V-belts will stretch and seat into pulley grooves and need to be properly tensioned to avoid severely reducing life of V-belts. Refer to Tensioning/Replacing V-Belts on Page 41 for detailed instructions.**







# SECTION 4: OPERATIONS

## Operation Overview

The purpose of this overview is to provide the novice machine operator with a basic understanding of how the machine is used during operation, so the machine controls/components discussed later in this manual are easier to understand.

Due to the generic nature of this overview, it is **not** intended to be an instructional guide. To learn more about specific operations, read this entire manual, seek additional training from experienced machine operators, and do additional research outside of this manual by reading "how-to" books, trade magazines, or websites.



To complete a typical operation, the operator does the following:

1. Examines workpiece to make sure it is suitable for planing.
2. Puts on safety glasses or face shield, a respirator, and hearing protection.
3. Places workpiece on table with flat side down and correctly adjusts table height for workpiece thickness and depth of cut.
  - If workpiece is bowed, operator surface planes workpiece on a jointer until one side is flat. Doing so ensures that it sits solidly on planer table during operation.
4. When all safety precautions have been taken, turns planer **ON**.
5. Stands to one side of planer path to reduce risk of kickback injuries, then feeds workpiece into planer until infeed roller grabs it.

**Note:** *Infeed and outfeed rollers control feed rate of workpiece as it passes through planer. Operator should not push or pull on workpiece.*

  - If cut is too deep and bogs down planer, operator immediately reduces depth of cut.
6. Once workpiece is clear of outfeed roller and stops moving, operator removes workpiece from outfeed table and measures workpiece thickness. If further planing is required, operator raises table slightly (approximately  $\frac{1}{4}$  to  $\frac{1}{2}$  turn of table height handwheel), then feeds workpiece into front of planer again.
7. Operator continues process until desired thickness is achieved, then turns machine **OFF**.





# Workpiece Inspection

Some workpieces are not safe to use or may require modification before they are. **Before cutting, inspect all workpieces for the following:**

- **Material Type:** This machine is only intended for workpieces of natural wood fiber. Attempting to use workpieces of any other material that may break apart during operation could lead to serious personal injury and property damage.
- **Foreign Objects:** Inspect lumber for defects and foreign objects (nails, staples, embedded gravel, etc.). If you have any question about the quality of your lumber, DO NOT use it. Remember, wood stacked on a concrete floor can have small pieces of stone or concrete pressed into the surface.
- **Large/Loose Knots:** Loose knots can become dislodged during operation. Large knots can cause kickback and machine damage. Always use workpieces that do not have large/loose knots.
- **Wet or "Green" Stock:** Avoid using wood with a high water content. Wood with more than 20% moisture content or wood exposed to excessive moisture (such as rain or snow), will cut poorly and cause excessive wear to the machine. Excess moisture can also hasten rust and corrosion of the machine and/or individual components.
- **Excessive Warping:** Workpieces with excessive cupping, bowing, or twisting are dangerous to cut because they are unstable and often unpredictable when being cut. DO NOT use workpieces with these characteristics!
- **Minor Cupping:** Workpieces with slight cupping can be safely supported if the cupped side is facing the table. On the contrary, a workpiece supported on the bowed side will rock during operation and could cause severe injury from kickback.

# Wood Types

The species of wood, as well as its condition, greatly affects the depth of cut the planer can effectively take with each pass.

The chart in the figure below shows the Janka Hardness Rating for a number of commonly used species. The larger the number, the harder the workpiece, and the less material should be removed in any one pass for good results.

**Note:** *The Janka Hardness Rating is expressed in pounds of force required to embed a 0.444" steel ball into the surface of the wood to a depth equal to half the ball's diameter.*

| Species            | Janka Hardness |
|--------------------|----------------|
| Ebony              | 3220           |
| Red Mahogany       | 2697           |
| Rosewood           | 1780           |
| Red Pine           | 1630           |
| Sugar Maple        | 1450           |
| White Oak          | 1360           |
| White Ash          | 1320           |
| American Beech     | 1300           |
| Red Oak            | 1290           |
| Black Walnut       | 1010           |
| Teak               | 1000           |
| Black Cherry       | 950            |
| Cedar              | 900            |
| Sycamore           | 770            |
| Douglas Fir        | 660            |
| Chestnut           | 540            |
| Hemlock            | 500            |
| White Pine         | 420            |
| Basswood           | 410            |
| Eastern White Pine | 380            |
| Balsa              | 100            |

**Figure 19.** Janka Hardness Rating for some common wood species.



# Planing Tips

---

- Inspect your lumber for twisting or cupping, and surface one face on a jointer if necessary before planing workpiece.
- Scrape off all glue when planing glued-up panels. Dried glue can quickly dull knives/inserts.
- DO NOT plane more than one piece at a time. Never plane multiple pieces side by side.
- Never remove more than the recommended amount of material on each pass. Only remove a small amount of material on each pass when planing wide or dense stock.
- Support the workpiece on both ends. Get assistance from another person if you are planing long lumber, or use roller stands to support the workpiece.
- Measure the workpiece thickness with calipers to get exact results.
- Carefully inspect all stock to make sure it is free of large knots or foreign objects that may damage your knives/inserts, cause kickback, or be ejected from the planer.
- When possible, plane equal amounts on each side of the board to reduce the chance of twisting or cupping.
- Use the entire width of the planer to wear knives/inserts evenly. With narrow workpieces, alternate between far left, far right, and the middle of the table. Your knives/inserts will remain sharp much longer.
- To avoid "chip marks," always plane WITH the grain direction of the wood. Never plane cross-grain or end-grain.
- Plane ONLY natural wood fiber. Do not plane wood composites or other materials that could break up in the planer and cause operator injury or damage to planer.
- Always true cupped or warped stock on a jointer before planing.

# Cutting Problems

---

Below is a list of wood characteristics you may encounter when planing. The following descriptions of defects will give you some possible answers to problems you may encounter while planing different materials. Possible solutions follow the descriptions.

## Chipped Grain

**Problem:** Usually a result of cutting against the grain, planing lumber with knots or excessive amount of cross grain, or using dull knives/inserts.

**Note:** *Some amount of chipping is normal with highly figured wood.*

**Solution:** Decrease the depth of cut. Reduce the feed rate. Inspect your lumber and determine if its grain pattern is causing the problem. If the lumber does not show substantial crossgrain, inspect your knives/inserts.

## Fuzzy Grain

**Problem:** Usually caused by surfacing lumber with too high of a moisture content. Sometimes fuzzy grain is an unavoidable characteristic of some woods, such as basswood. Fuzzy grain can also be caused by dull knives/inserts.

**Solution:** Check the lumber with a moisture meter. If moisture is greater than 20%, sticker the lumber and allow it to dry. Otherwise, inspect the knife/insert condition.

## Snipe

**Problem:** Occurs when board ends have more material removed than the rest of the board. Usually caused when the workpiece is not properly supported as it goes through the machine. In many cases, however, a small amount of snipe is inevitable.

**Solution:** Hold workpiece up slightly as it leaves the outfeed end of the planer. The best way to deal with snipe is by planing lumber longer than your intended work length and then cutting off the excess after planing is completed.



## Pitch & Glue Build-up

**Problem:** Glue and resin buildup on the rollers and cutterhead will cause overheating by decreasing cutting sharpness while increasing drag in the feed mechanism. The result can include scorched lumber, uneven knife/insert marks, and chatter.

**Solution:** Clean the rollers and cutterhead.

## Chip Marks or Indentations

**Problem:** Chip indentation or chip bruising is the result of wood chips not being thrown away from the cutterhead and out of the machine. Instead they are carried around the cutterhead, deposited on the planed surface and crushed by the outfeed roller. Some of the causes of chip indentation are:

- Wood chips/sawdust not being properly expelled from the cutterhead.
- The type of lumber being planed. Certain species have a tendency to chip bruise.
- A high moisture content (over 20%) or surface moisture (refer to **Workpiece Inspection**).
- Dull knives/inserts.
- Excessive depth of cut.

### Solution:

- Use a proper dust-collection system; adjust chip deflector in or out as necessary.
- Lumber must be completely dry, preferably kiln-dried (KD). Air-dried (AD) lumber must be seasoned properly and have no surface moisture. DO NOT surface partially-air-dried (PAD) lumber.
- Make sure planer knives/inserts are sharp.
- Reduce depth of cut.

## Rippled Cut

**Problem:** Regularly spaced indentations across face of workpiece are caused by excessive out-feed roller pressure or excessive feed rate.

**Solution:** Reduce outfeed roller pressure; reduce feed rate.

# Depth of Cut

## Table Movement per Handwheel Revolution

One Full Revolution .....2mm (0.08")

## Material Thickness Range

Minimum–Maximum Stock Thickness .... $\frac{3}{16}$ "–6"


The depth of cut on a planer means the amount of material that is removed from the top of the workpiece as it passes underneath the cutterhead.

The depth of cut is set by adjusting the distance of the table below the cutterhead. This distance is the thickness of the workpiece minus the depth of cut. The planing depth of cut is controlled by using the table elevation handwheel on the right side of the machine. Rotating the handwheel clockwise raises the table.

Although the correct depth of cut varies according to wood hardness and workpiece width, we recommend the maximum depth of cut (per pass) be no more than  $\frac{1}{16}$ ". A series of light cuts will give better end results and put less stress on the planer than trying to take off too much material in a single pass.

The depth of cut can be referenced directly from the inch/millimeter scale on the front of the planer, as shown.

**Note:** *The scale functions as a general guide only, and is not intended for low-tolerance, precision results.*




**Figure 20.** Location of depth-of-cut controls (G1021X2 shown).



# Bed Roller Height

Bed Roller Height Range .....0.002"—0.020"

The correct height of the bed rollers will vary, depending on the type of material you intend to plane. However, as a general rule, keep the bed roller height within 0.002"—0.020" above the table surface, as illustrated in **Figure 21**.



**Figure 21.** Recommended bed roller height above the table surface.

When planing rough stock, set the rollers high to keep the lumber from dragging along the bed. When planing milled lumber, set the rollers low to help minimize snipe.

To ensure accurate results and make the adjustment process quicker and easier, we recommend using a Rotacator (refer to **Page 32**) to gauge the bed roller height from the table surface. If a Rotacator is not available, a straightedge and feeler gauges can be used, but care must be taken to achieve accurate results.


## **NOTICE**

**Bed rollers that are not adjusted to the correct height or out of alignment with each other can cause poor finishes, inconsistent planing thickness, and other undesirable results.**

| Items Needed                                | Qty |
|---|-----|
| Hex Wrench 3mm.....                         | 1   |
| Open-End Wrench 12mm.....                   | 1   |
| Straightedge .....                          | 1   |
| Feeler Gauge Set .....                      | 1   |
| Rotacator (optional, <b>Page 32</b> ) ..... | 1   |

### To adjust bed rollers:

1. DISCONNECT MACHINE FROM POWER!
2. Completely lower table to give yourself enough room to work.
3. Loosen set screws (see **Figure 22**) above each of four roller adjustment cams (there are two on each side of planer).



**Figure 22.** Bed roller height controls (G1021X2 shown).

4. Rotate eccentric adjustment cams to raise or lower bed rollers to desired height above table surface.
5. Verify both sides of each roller are at the same height, then re-tighten set screws to secure in place.
6. Re-check roller heights to make sure they did not change while being secured.  
— If roller heights are not correct, repeat this procedure until they are.



# Setting Feed Rate

High Feed Rate .....28 FPM  
Low Feed Rate ..... 16 FPM

The infeed and outfeed rollers move the workpiece through the planer while keeping it flat and providing a consistent rate of movement. The speed that these rollers move the workpiece through the planer is the feed rate.

Generally, low feed rates are used for finishing passes, while higher feed rates are used for dimensioning passes.

The figure below illustrates the three different positions of the feed rate control knob:

- Push knob in to use high feed rate.
- Pull the knob out to use the low feed rate.
- Move knob to center position to place gearbox in neutral.






Figure 23. Feed rate control knob positions.

## NOTICE

Only change the feed rate when the planer is running, but DO NOT attempt to change the feed rate during any cutting operations or damage to the gearbox will result.

# Adjusting/Replacing Knives (G1021Z)

|   |  |
|---|--|
| <br> | <b>WARNING</b><br>To reduce risk of shock or accidental startup, always disconnect machine from power before adjustments, maintenance, or service. |
|---|--|

|   |
|---|
| <b>CAUTION</b><br>Cutterhead knives are extremely sharp. Accidental contact with knives can result in severe cuts. Take great caution whenever working with or around cutterhead knives. Wear heavy leather gloves to reduce risk of severe cuts. |
|---|

|  |
|--|
| <b>NOTICE</b><br>To maintain accurate and consistent planing results, we do not recommend sharpening knives yourself. Instead, just replace dull knives or have them professionally sharpened. |
|--|

Setting the height of the knives correctly is crucial to the proper operation of your planer and is very important in keeping the knives sharp. If one knife protrudes higher than the others, it will do the majority of the work, dull much faster, and produce poor cutting results.

The knife-setting jig included with this planer is designed to set the knives at a uniform distance of 0.070" above the cutterhead surface.

**Note:** If you need to replace or sharpen a knife, you can remove the knife from the cutterhead during **Step 4** of the following procedure. Thoroughly clean out any debris from the knife slots before replacing the knives.

Replacement knives are available through Grizzly (refer to **Accessories** for options).





| Items Needed                      | Qty    |
|-----------------------------------|--------|
| Phillips Screwdriver #2 .....     | 1      |
| Wrench or Socket 12mm, 13mm ..... | 1 Ea.  |
| Hex Wrench 3mm.....               | 1      |
| Knife-Setting Jig .....           | 1      |
| Heavy Leather Gloves.....         | 1 Pair |

**To adjust height of knives:**


1. DISCONNECT MACHINE FROM POWER!
2. Remove dust hood and top cover to expose cutterhead.
3. Put on heavy leather gloves.
4. Remove belt cover, then rotate cutterhead pulley to provide access to one of the knives.

**Note for G1021Z Only:** The cutterhead for Model G1021Z ships with both springs and jack screws to adjust the knife height (see **Figure 24**)—which one you use is up to your personal preference. However, if you use the springs, you must first remove the jack screws from the cutterhead before proceeding.


— The advantage of using springs is that springs maintain a constant upward pressure on the knives while using the knife-setting Jig during **Step 6**.

— The advantage of using jack screws is that once you set the proper height of the screws, they should require little to no adjustment when replacing the knives.

5. Loosen cutterhead gib bolts until knife is completely loose.
  - If you are replacing the knives, remove the old knife and install the new one, making sure the beveled edge of the new knife is facing the correct direction.
6. Position knife-setting jig over knife so that knife edge is directly under center pad, as shown below.



**Figure 25.** Knife-setting jig correctly positioned over knife.




**Figure 24.** G1021Z cutterhead components.






7. **Jack Screws:** Insert hex wrench into access holes in cutterhead (see **Figure 26**), and rotate jack screws to raise or lower knife until it barely touches center pad of knife-setting jig with all legs of jig still firmly on cutterhead, then snug gib bolts enough to hold knife in place without fully tightening gib bolts (see **Figure 27**).

**Springs:** Insert hex wrench into access holes in cutterhead (see **Figure 26**), and remove jack screws. Push down on knife jig until all legs of jig are firmly on cutterhead and knife just touches center pad of jig, then tighten gib bolts enough to hold knife in place without fully tightening gib bolts (see **Figure 27**).




**Figure 26.** Example of jack screw access holes in cutterhead.



**Figure 27.** Using knife-setting jig to set knife height on Model G1021Z.

8. Incrementally snug gib bolts in an even manner, starting at middle and working your way to ends by alternating left and right, as illustrated.



**Figure 28.** Gib bolt tightening sequence.

9. Repeat **Step 8**, snugging gib bolts a little more.


10. Repeat **Step 8**, this time fully tightening all gib bolts.

11. Repeat **Steps 4–8** for remaining knives.



# Rotating/Replacing Cutterhead Inserts (G1021X2)

The helical cutterhead is equipped with indexable carbide inserts that can be rotated to reveal any one of their four cutting edges. If one edge of the insert becomes dull or damaged, simply rotate it 90° to reveal a fresh cutting edge, as shown in **Figure 29**.



**Figure 29.** Insert rotating sequence.

| Items Needed                      | Qty       |
|-----------------------------------|-----------|
| Phillips Screwdriver #2 .....     | 1         |
| Wrench or Socket 12mm, 13mm ..... | 1         |
| Torque Wrench .....               | 1         |
| T-20 Torx Bit .....               | 1         |
| Heavy Leather Gloves .....        | 1 Pair    |
| Light Machine Oil.....            | As Needed |


## To rotate or replace a helical cutterhead insert:

1. DISCONNECT MACHINE FROM POWER!
2. Remove dust port, top cover, and belt cover.
3. Put on heavy leather gloves to protect your fingers and hands.

## **⚠ CAUTION**

The carbide inserts are very sharp and can quickly cut your hands. ALWAYS use caution and heavy leather gloves when handling these parts to reduce the risk of personal injury.

4. Remove any sawdust or debris from head of insert, Torx screw, and surrounding area (see **Figure 30**).



**Figure 30.** G1021X2 cutterhead inserts and Torx screws.

5. Remove Torx screw and insert, then clean all dust and debris from both parts and pocket they were removed from.

**Note:** Proper cleaning of insert, Torx screw, and cutterhead pocket is critical to achieving a smooth finish. Dirt or dust trapped between insert and cutterhead will raise insert, and make marks on your workpiece when planing.

**Tip:** Use low-pressure compressed air or a vacuum nozzle to clean out cutterhead pocket.

6. Rotate insert 90° and install so that a fresh cutting edge faces outward (see **Figure 29**).

— When all four insert cutting edges have been used, replace insert with a new one. Always position insert reference dot in same position when installing a new insert to aid in rotational sequencing.

7. Lubricate Torx screw threads with a very small amount of light machine oil, wipe excess off, and torque screw to 50–55 inch/pounds.

**Note:** If too much oil is applied to the threads, excess oil will attempt to squeeze out of the threaded hole and raise insert during installation, bringing it out of height alignment.



# SECTION 5: ACCESSORIES

## **!WARNING**


Installing unapproved accessories may cause machine to malfunction, resulting in serious personal injury or machine damage. To reduce this risk, only install accessories recommended for this machine by Grizzly.

## **NOTICE**

Refer to our website or latest catalog for additional recommended accessories.

### **W1218A—Rotacator™ Precision Planer Tool**

The Rotacator is a dial indicator on a magnetic base, designed for quickly and accurately setting the critical tolerances needed when making planer adjustments. Perfect for adjusting infeed/outfeed rollers, pressure bars, chip breakers, and bed rollers. Also a great setup tool for other machines! Accurate to 0.001". Indicator rotates 360°



**Figure 31.** Rotacator™ Precision Planer Tool.

### **T27695—15" Helical Spiral Cutterhead for Planers**

These helical spiral cutterheads feature four spirals and replaceable carbide inserts for providing an incredible finish.




**Figure 32.** T27695 15" Helical Spiral Cutterhead.

### **For G1021X2:**

#### **H9893—Indexable Carbide Inserts, 10 Pack**

These Indexable Carbide Inserts are designed for use in spiral or helical cutterhead systems and made to last up to 10 times longer than a set of HSS steel inserts. Made of solid carbide. Size: 15 x 15 x 2.5mm.



**Figure 33.** H9893 Indexable Carbide Inserts.


**order online at [www.grizzly.com](http://www.grizzly.com) or call 1-800-523-4777**



**For G1021Z:**

**G6701—HSS Replacement Knives, Set of 3**

These M-2 HSS planer knife sets are hardened and tempered to 62–64 Rockwell and balanced to within 1 gram.



**Figure 34.** Grizzly planer blades.

**D2273— Single Roller Stand**

This super heavy-duty roller stand features convenient hand knobs for fast height adjustment. Invaluable for supporting work on machines of varying heights. Adjusts from 26<sup>5</sup>/<sub>8</sub>" to 45". 250 lb. capacity.



**Figure 35.** D2273 Single Roller Stand.

**Basic Eye Protection**

T20501—Face Shield Crown Protector 4"

T20502—Face Shield Crown Protector 7"

T20503—Face Shield Window

T20451—"Kirova" Clear Safety Glasses

T20452—"Kirova" Anti-Reflective S. Glasses

T20456—DAKURA Safety Glasses, Black/Clear



**Figure 36.** Assortment of basic eye protection.

H4978—Deluxe Earmuffs - 27dB

H4979—Twin Cup Hearing Protector - 29dB

T20446—Classic Earplugs, 200-pair - 31dB

Protect yourself comfortably with a pair of cushioned earmuffs. Especially important if you or employees operate for hours at a time.



**Figure 37.** Hearing protection.

**order online at [www.grizzly.com](http://www.grizzly.com) or call 1-800-523-4777**





- G5562—SLIPIT® 1 Qt. Gel
- G5563—SLIPIT® 12 Oz. Spray
- G2871—Boeshield® T-9 12 Oz. Spray
- G2870—Boeshield® T-9 4 Oz. Spray
- H3788—G96® Gun Treatment 12 Oz. Spray
- H3789—G96® Gun Treatment 4.5 Oz. Spray



**Figure 38.** Recommended products for protecting unpainted cast iron/steel parts on machinery.

- D4206—Clear Flexible Hose 4" x 10'
- W1034—Heavy-Duty Clear Flex Hose 4" x 10'
- W1015—Y-Fitting 4" x 4" x 4"
- W1017—90° Elbow 4"
- W1019—Hose Coupler (Splice) 4"
- W1317—Wire Hose Clamp 4"
- W1007—Plastic Blast Gate 4"
- W1053—Anti-Static Grounding Kit

We've hand-picked a selection of commonly used dust-collection components for machines with 4" dust ports.



**Figure 39.** Dust-collection accessories.

**SB1365—South Bend Way Oil-ISO 68**

Engineered for the high pressure exerted on horizontal or vertical ways and slides. Protects against rust and corrosion. Ensures stick-free, smooth motion which maximizes finishes and extends the life of your machine. Won't gum up! 12 oz. AMGA#2 (ISO 68 Equivalent)



**Figure 40.** SB1365 Way Oil.

**T28042—Moly-D Industrial Gear Oil-ISO 320**

This industrial gear oil from Primrose has been developed specifically for the high temperatures and pressures typical of modern industrial applications. 1-gallon size.



**Figure 41.** T28042 Gear Oil.

**T26419—Syn-O-Gen Synthetic Grease**

100% pure synthesized hydrocarbon basestocks compounded with special thickeners and additives make Syn-O-Gen non-melt, tacky, and water resistant. Extremely low pour point, high temperature oxidation, and thermal stability produce a grease unmatched in performance.




**Figure 42.** T26419 Synthetic Grease.

**order online at [www.grizzly.com](http://www.grizzly.com) or call 1-800-523-4777**



# SECTION 6: MAINTENANCE

---



## Schedule

---

For optimum performance from your machine, follow this maintenance schedule and refer to any specific instructions given in this section.

**Note:** *This maintenance schedule is based on average daily usage. Adjust the maintenance schedule to match your usage, to keep your planer running smoothly, and to protect your investment.*

### Every 8 Hours of Operation:

- Clean machine and protect unpainted cast-iron surfaces.
- Lubricate feed roller bushings (**Page 36**).
- Tighten loose mounting bolts.
- Check/sharpen/replace damaged or worn knives/inserts (**Page 28**).
- Check/repair/replace worn or damaged wires.
- Resolve any other unsafe condition.

### Every 40 Hours of Operation:

- Clean cutterhead and, for G1021Z, check knife height (**Page 28**).
- Lubricate table columns and leadscrews (**Page 36**).

### Every 160 Hours of Operation:

- Check/tension/replace V-belts (**Page 41**).
- Clean/vacuum dust buildup from inside cabinet and off motor.
- Lubricate table height worm gear (**Page 36**).
- Lubricate table height chain and sprockets (**Page 36**).
- Lubricate drive chain and sprockets (**Page 37**).

### Yearly:

- Change gearbox oil (**Page 37**).

## Cleaning & Protecting

---

Vacuum excess wood chips and sawdust, and wipe off the remaining dust with a dry cloth. If any resin has built up, use a resin-dissolving cleaner to remove it.

Protect the unpainted cast-iron table by wiping it clean after every use—this ensures moisture from wood dust does not remain on bare metal surfaces. Keep the table rust-free with regular applications of products like G96® Gun Treatment, SLIPIT®, or Boeshield® T-9 (see **Page 34** for more details).

## Lubrication

---

### **NOTICE**

**Failure to follow reasonable lubrication practices as instructed in this manual for your machine could lead to premature failure of components and void the warranty.**

This planer features bearings that are lubricated and sealed at the factory. These bearing do not require any further attention unless they need to be replaced. If a bearing fails, your planer will probably develop a noticeable rumble or vibration, which will increase when the machine is under a load. The bearings are standard sizes and can be replaced through Grizzly.

Follow the maintenance schedule on this page and the procedures beginning on **Page 36** to properly lubricate the other planer components, which are essential for long life and trouble-free operation of your planer.






## Feed Roller Bushings

Oil Type ..... SB1365 or ISO-68 Equivalent  
Oil Amount ..... 2–3 Drops  
Frequency ..... Every 8 Hours of Operation

The infeed and outfeed rollers rotate inside bushing blocks on both ends of the rollers. Add 2–3 drops of ISO 68 machine oil to the center hole of the four feed roller tension adjustment bolts on top of the head casting, as shown in **Figure 43**.




**Figure 43.** Example of lubrication locations for feed roller bushings.

## Columns & Leadscrews

Oil Type ..... SB1365 or ISO-68 Equivalent  
Oil Amount ..... Thin Coat  
Grease Type ..... NLGI#2 Equivalent  
Frequency ..... Every 40 Hours of Operation

The table rides on the columns and is moved by the rotation of the leadscrews inside the columns. Loosen the dust sleeve (see **Figure 44**) to access the columns and leadscrews. Apply a thin coat of ISO 68 machine oil to the outside surface of the columns and brush on a light application of multi-purpose grease to the leadscrew threads. Move the table up and down to distribute the lubricant.




**Figure 44.** Location of column and leadscrew.

## Table Height Worm Gear

Grease Type ..... NLGI#2 Equivalent  
Frequency ..... Every 160 Hours of Operation

Remove the three cap screws that secure the worm gear housing (see **Figure 45**), then lift the housing and handwheel assembly off the machine. Clean away any debris from the housing and gears, then brush on a moderate amount of multi-purpose grease to the gear teeth.




**Figure 45.** Example of table height worm gear housing.

## Table Height Chain & Sprockets

Grease Type ..... NLGI#2 Equivalent  
Frequency ..... Every 160 Hours of Operation

The table leadscrews are synchronized by the table height chain and sprockets located underneath the planer base (see **Figure 46**). Use shop rags and mineral spirits to clean away debris and grime, then brush on a light coat of multi-purpose grease to the chain and sprockets.



**Figure 46.** Example of table height chain and sprockets as viewed from underneath the base.




## Drive Chain & Sprockets

Grease Type..... T26419 Synthetic Grease  
Frequency..... Every 160 Hours of Operation

The infeed and outfeed rollers receive the transferred power from the cutterhead through the drive chain system on the right side of the machine, as shown in **Figure 47**.

Remove the table height handwheel and the safety covers attached to the inside of the drive chain cover, then remove the cover to access these parts.

Use shop rags and mineral spirits to clean away any debris and grime, then brush on a light coat of multi-purpose grease to the chain and sprockets.




**Figure 47.** Drive chains and sprockets for infeed and outfeed rollers.

## Gearbox Oil


Oil Type..... T28042 or ISO-320 Equivalent  
Oil Amount.....20 Oz.  
Frequency..... After First 20 Hours, Then Yearly

**Note:** *We recommend that you replace the gearbox oil after the first 20 hours of operation. This is a normal break-in procedure and will help maximize the service life of the machine by flushing away any particles from the break-in and manufacturing process.*

Although it is not necessary to remove the drive chain cover to access the fill and drain plugs, it is more convenient to do so (see **Figures 48–49**). Replace the gearbox oil with ISO 320 or equivalent oil until it just reaches the fill plug.



**Figure 48.** Location of gearbox drain plug.




**Figure 49.** Example of gearbox fill plug.



# SECTION 7: SERVICE

Review the troubleshooting procedures in this section if a problem develops with your machine. If you need replacement parts or additional help with a procedure, call our Technical Support. **Note:** *Please gather the serial number and manufacture date of your machine before calling.*

## Troubleshooting



### Motor & Electrical

| Symptom   | Possible Cause  | Possible Solution   |
|---|---|---|
| Machine does not start, or power-supply fuse/breaker trips immediately after startup. | <ol style="list-style-type: none"> <li>1. Stop button depressed/at fault.</li> <li>2. Incorrect power supply voltage or circuit size.</li> <li>3. Thermal overload relay has tripped.</li> <li>4. Power supply circuit breaker tripped or fuse blown.</li> <li>5. Motor wires connected incorrectly.</li> <li>6. Wiring open/has high resistance.</li> <li>7. Start button switch at fault.</li> <li>8. Centrifugal switch/contact points at fault.</li> <li>9. Start capacitor at fault.</li> <li>10. Thermal overload relay has tripped.</li> <li>11. Contactor not energized; has poor contacts.</li> <li>12. Motor at fault.</li> </ol>             | <ol style="list-style-type: none"> <li>1. Rotate button head to reset; replace if at fault.</li> <li>2. Ensure correct power supply voltage and circuit size.</li> <li>3. Reset; adjust trip load dial if necessary; replace.</li> <li>4. Ensure circuit is sized correctly and free of shorts. Reset circuit breaker or replace fuse.</li> <li>5. Correct motor wiring connections.</li> <li>6. Check/fix broken, disconnected, or corroded wires.</li> <li>7. Replace switch.</li> <li>8. Adjust/replace centrifugal switch/contact points if available.</li> <li>9. Test/replace if at fault.</li> <li>10. Reset; adjust trip load dial if necessary; replace.</li> <li>11. Test all legs for power/replace.</li> <li>12. Test/repair/replace.</li> </ol>  |
| Machine stalls or is underpowered.  | <ol style="list-style-type: none"> <li>1. Machine undersized for task.</li> <li>2. Workpiece not suitable for machine.</li> <li>3. Motor overheated, causing thermal overload to trip.</li> <li>4. Belt(s) slipping; oil/grease on belt(s).</li> <li>5. Dull knives/inserts.</li> <li>6. Dust-collection problem causing internal components to clog up with shavings.</li> <li>7. Motor wired incorrectly.</li> <li>8. Centrifugal switch/contact points at fault.</li> <li>9. Run capacitor at fault.</li> <li>10. Pulley slipping on shaft.</li> <li>11. Contactor not energized/has poor contacts.</li> <li>12. Motor bearings at fault.</li> </ol> | <ol style="list-style-type: none"> <li>1. Reduce feed rate/depth of cut.</li> <li>2. Only cut wood/ensure moisture is below 20%.</li> <li>3. Allow motor to cool, reset overload if necessary, and reduce depth of cut.</li> <li>4. Clean/tension/replace belt(s) (<b>Page 41</b>); align pulleys (<b>Page 42</b>).</li> <li>5. Sharpen/replace knives (<b>Page 28</b>), or replace inserts (<b>Page 31</b>).</li> <li>6. Clear blockages in dust chute/ducting, ensure dust collector is operating efficiently.</li> <li>7. Wire motor correctly.</li> <li>8. Adjust/replace centrifugal switch/contact points if available.</li> <li>9. Test/repair/replace.</li> <li>10. Tighten loose pulley; replace pulley/shaft if damaged.</li> <li>11. Test all legs for power/replace.</li> <li>12. Test/repair/replace.</li> </ol> |



## Motor & Electrical (Cont.)

| Symptom                                   | Possible Cause  | Possible Solution  |
|---|---|--|
| Machine has vibration or noisy operation. | <ol style="list-style-type: none"> <li>1. Motor or component loose.</li> <li>2. V-belt(s) worn, loose, or slapping cover.</li> <li>3. Pulley loose.</li> <li>4. Bed rollers protruding unevenly.</li> <li>5. Plastic chip deflector hitting knives.</li> <li>6. Motor fan rubbing on fan cover.</li> <li>7. Knives/gibs at fault.</li> <li>8. Cutterhead bearings at fault.</li> <li>9. Motor bearings at fault.</li> </ol> | <ol style="list-style-type: none"> <li>1. Inspect/tighten loose bolts/nuts; replace damaged components.</li> <li>2. Tension/replace belts as a matched set (<b>Page 41</b>).</li> <li>3. Re-align/replace shaft, pulley set screw, and key.</li> <li>4. Adjust bed rollers (<b>Page 27</b>).</li> <li>5. Adjust chip deflector (<b>Page 47</b>); replace if necessary.</li> <li>6. Fix/replace fan cover; replace loose/damaged fan.</li> <li>7. Sharpen/replace knives; set knife alignment/height correctly (<b>Page 28</b>).</li> <li>8. Replace bearing(s).</li> <li>9. Test by rotating shaft; rotational grinding/loose shaft requires bearing replacement.</li> </ol> |

## Machine Operation

| Symptom  | Possible Cause   | Possible Solution   |
|--|--|---|
| Excessive snipe (gouge in end of board that is uneven with rest of cut).<br><br>Note: A small amount of snipe is inevitable with all types of planers. The key is minimizing it as much as possible. | <ol style="list-style-type: none"> <li>1. One or both of bed rollers are set too high.</li> <li>2. Outfeed extension slopes down or is not level with main table.</li> <li>3. Chip breaker set too low.</li> <li>4. Workpiece is not supported as it leaves planer.</li> <li>5. Some snipe is inevitable.</li> </ol> | <ol style="list-style-type: none"> <li>1. Lower bed rollers (<b>Page 27</b>).</li> <li>2. Shim outfeed extension wing level with main table.</li> <li>3. Raise height of chip breaker (<b>Page 43</b>).</li> <li>4. Hold workpiece up slightly as it leaves outfeed end of planer.</li> <li>5. Plane lumber longer than your intended workpiece length, then cut off excess after planing complete.</li> </ol>  |
| Workpiece stops/slow in middle of cut.   | <ol style="list-style-type: none"> <li>1. Taking too heavy of a cut.</li> <li>2. One or both of bed rollers are set too low or too high.</li> <li>3. Chip breaker or pressure bar set too low.</li> <li>4. Feed rollers set too low or too high.</li> <li>5. Pitch and glue buildup on planer components.</li> </ol> | <ol style="list-style-type: none"> <li>1. Take a lighter cut.</li> <li>2. Adjust bed rollers (<b>Page 27</b>).</li> <li>3. Raise height of chip breaker or pressure bar (<b>Page 43</b>).</li> <li>4. Adjust feed rollers (<b>Page 43</b>).</li> <li>5. Clean internal cutterhead components with a pitch/resin-dissolving solvent.</li> </ol>  |
| Chipping (consistent pattern).   | <ol style="list-style-type: none"> <li>1. Knots or conflicting grain direction in wood.</li> <li>2. Taking too deep of a cut.</li> <li>3. Feeding workpiece too fast.</li> <li>4. Mis-adjusted chip breaker.</li> <li>5. Nicked or chipped knife/insert.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Inspect workpiece for knots and grain direction; only use clean stock, and cut WITH the grain.</li> <li>2. Take a smaller depth of cut. (Reduce cutting depth when planing hard woods.)</li> <li>3. Slow down feed rate.</li> <li>4. Adjust both sides of chip breaker to correct height.</li> <li>5. Replace affected knife (<b>Page 28</b>), or have it sharpened; rotate/replace insert (<b>Page 31</b>).</li> </ol> |
| Chipping/indentation in workpiece surface (inconsistent pattern).  | <ol style="list-style-type: none"> <li>1. Chips aren't being properly expelled from cutterhead.</li> <li>2. Chip breaker not set correctly.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Use a proper dust-collection system.</li> <li>2. Correctly adjust chip breaker (<b>Page 43</b>).</li> </ol>   |



## Machine Operation (Cont.)

| Symptom  | Possible Cause  | Possible Solution   |
|--|---|---|
| Fuzzy grain.   | <ol style="list-style-type: none"> <li>1. Wood may have high moisture content or surface wetness.</li> <li>2. Dull knives/inserts.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Check moisture content is below 20% and allow to dry if moisture is too high.</li> <li>2. Replace knives (<b>Page 28</b>) or have them professionally sharpened; rotate/replace inserts (<b>Page 31</b>).</li> </ol>  |
| Long lines or ridges that run along length of board.                       | <ol style="list-style-type: none"> <li>1. Nicked or chipped knife/inserts.</li> </ol>   | <ol style="list-style-type: none"> <li>1. Replace knives (<b>Page 28</b>) or have them professionally sharpened; rotate/replace inserts (<b>Page 31</b>).</li> </ol>  |
| Uneven cutting marks, wavy surface, or chatter marks across face of board. | <ol style="list-style-type: none"> <li>1. Feeding workpiece too fast.</li> <li>2. Chip breaker or pressure bar set unevenly or not low enough.</li> <li>3. Knives not installed evenly/inserts not properly installed.</li> <li>4. Worn cutterhead bearings.</li> </ol> | <ol style="list-style-type: none"> <li>1. Slow down feed rate.</li> <li>2. Adjust height of chip breaker (<b>Page 43</b>).</li> <li>3. Adjust knives with knife gauge (<b>Page 28</b>); remove inserts, properly clean mounting pocket and re-install (<b>Page 31</b>).</li> <li>4. Replace cutterhead bearings.</li> </ol> |
| Glossy surface.  | <ol style="list-style-type: none"> <li>1. Knives/inserts are dull.</li> <li>2. Feeding workpiece too slow.</li> <li>3. Cutting depth too shallow.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Replace knives (<b>Page 28</b>) or have them professionally sharpened; rotate/replace inserts (<b>Page 31</b>).</li> <li>2. Increase feed rate.</li> <li>3. Increase depth of cut.</li> </ol>   |
| If workpiece twists in machine.  | <ol style="list-style-type: none"> <li>1. Feed rollers not parallel with table.</li> </ol>  | <ol style="list-style-type: none"> <li>1. Adjust feed rollers (<b>Page 43</b>).</li> </ol>  |





# Tensioning/ Replacing V-Belts

## NOTICE

After approximately 16 hours of operation, V-belts will stretch and seat into pulley grooves and need to be properly tensioned to avoid severely reducing life of V-belts.

Three V-belts transfer power from the motor to the cutterhead, and then to the infeed and outfeed rollers with the use of the drive chain system. To ensure efficient transfer of power to these systems, make sure the V-belts are always properly tensioned and in good condition.

If the V-belts are worn, cracked, or damaged, replace them. Always replace the V-belts with a matched set of three, or belt tension may not be even among the belts, causing premature belt failure.

## CAUTION


V-belts and pulleys will be hot after operation. Allow them to cool before handling.

| Items Needed                  | Qty |
|-------------------------------|-----|
| Phillips Screwdriver #2 ..... | 1   |
| Open-End Wrench 16mm.....     | 1   |

### To tension/replace V-belts:


1. DISCONNECT MACHINE FROM POWER!
2. Remove V-belt cover from left side of machine to expose belts, as shown in **Figure 50**.

**Note:** A collection of black belt dust at the bottom of the belt cover is normal during the life of the belts.



**Figure 50.** Example of belt cover removed to expose V-belts and pulleys.

3. Remove front cabinet cover to access motor, as shown in **Figure 51**.




**Figure 51.** Example of front cabinet cover removed to access motor.





4. If V-belts need to be replaced, raise motor to release belt tension (see next step for instructions), roll them off pulleys, then replace with a matched set of 3.
5. To adjust V-belt tension, loosen top motor mount hex nut (see **Figure 51** on **Page 41**), then adjust bottom hex nut to raise or lower motor.

**Note:** V-belts are correctly tensioned when there is approximately  $\frac{3}{4}$ " deflection when moderate pressure is applied to them midway between pulleys, as illustrated in **Figure 52**.



**Figure 52.** Belt deflection when V-belts are correctly tensioned.

6. After V-belts are correctly tensioned, tighten top motor mount hex nut, then re-install cabinet cover and belt cover.


# Pulley Alignment

Proper pulley alignment prevents premature V-belt wear and unnecessary load on the motor. The pulleys are properly aligned when they are parallel and in the same plane as each other.

| Items Needed                      | Qty   |
|-----------------------------------|-------|
| Straightedge 3' .....             | 1     |
| Wrench or Socket 14mm, 17mm ..... | 2 Ea. |

## To check/re-align pulleys:

1. DISCONNECT MACHINE FROM POWER!
2. Remove belt cover, then use straightedge to check pulley alignment, as shown in **Figure 53**.



**Figure 53.** Example of checking pulley alignment.

— If pulleys are parallel and in the same plane, no adjustment is necessary. Re-install belt cover.

— If pulleys are not parallel or in the same plane, remove motor access panel, then proceed to **Step 3**.

3. Loosen four motor mount bolts, shift motor until pulleys are properly aligned, then re-tighten motor mount bolts.
4. Re-check pulleys and repeat **Step 3** as necessary until you are satisfied with pulley alignment, then re-tighten all fasteners, and replace belt cover and motor access panel.



# Feed Rollers & Chip Breaker Heights


It is essential that the feed rollers and chip breaker are set at the correct distance below the cutterhead knives at BDC (bottom dead center) to ensure that the workpiece moves through the planer evenly and the correct distance from the cutterhead knives.

To ensure accurate results and make the adjustment process quicker and easier, we recommend using a Rotacator for these adjustments (refer to **Accessories**).

If a Rotacator is not available, a 6' 2x4 cut into two even sized pieces and a feeler gauge set can be used, but care must be taken when jointing the wood to achieve accurate results.

## Dist. Below Knife/Insert at BDC (Figure 54)

|                                |        |
|--------------------------------|--------|
| <b>A.</b> Infeed Roller .....  | 0.040" |
| <b>B.</b> Chip Breaker.....    | 0.040" |
| <b>C.</b> Outfeed Roller ..... | 0.020" |




**Figure 54.** Planer component recommended clearances (illustration is not to scale).

## Using a Rotacator

| Items Needed                          | Qty   |
|---------------------------------------|-------|
| Phillips Screwdriver #2 .....         | 1     |
| Hex Wrenches 3mm, 5mm.....            | 1 Ea. |
| Wrench or Socket 10mm.....            | 1 Ea. |
| Rotacator (see <b>Page 32</b> ) ..... | 1     |

### To use a Rotacator:

1. DISCONNECT MACHINE FROM POWER!
2. Make sure knives are set to correct height (refer to **Adjusting/Replacing Knives** on **Page 28** for detailed instructions). If machine is helical cutterhead, make sure all inserts are properly installed (refer to **Rotating/Replacing Cutterhead Inserts** on **Page 31** for detailed instructions).
3. Lower table at least 4" below head casting, then lock it in place.
4. Remove dust port, top cover, belt cover, and drive chain cover.
5. Using your Rotacator, find bottom dead center (BDC) of any knife/insert edge by slowly rocking cutterhead pulley back and forth, then set Rotacator dial to "0" (see **Figure 55**).




**Figure 55.** Example of using a Rotacator to find BDC.

6. Move feed speed knob to neutral position to allow infeed roller to freely rotate.
7. Keeping Rotacator dial at "0", position it under right-hand side of infeed roller and find BDC of a serrated edge by rocking infeed roller back and forth.




- Loosen jam nuts and use set screws on each side of feed roller as shown to adjust height of infeed roller bushing block until Rotacator dial shows 0.040", which is the recommended distance for infeed roller below cutterhead.



**Figure 56.** Example of infeed roller bushing block and height adjustment controls.

- Repeat **Steps 7–8** on left side of infeed roller.
- Re-check both sides of infeed roller and, if necessary, make further adjustments until infeed roller height from side-to-side is 0.040" below BDC of cutterhead knife, then retighten both jam nuts.
- Keeping same "0" reference on Rotacator dial from **Step 5**, repeat **Steps 7–10** for out-feed roller, but adjust it until it is 0.020" below BDC of cutterhead knife.

- Using same "0" reference on Rotacator dial from **Step 5**, perform similar steps as described previously to adjust height of chip breaker to its recommended specification given at beginning of this subsection. The adjustment controls are shown below.



**Figure 57.** Example of adjusting chip breaker height.

- Re-install belt cover, top cover, drive chain cover, and dust port.



## Using Wood Blocks

### Items Needed


|                               | Qty |
|-------------------------------|-----|
| Phillips Screwdriver #2 ..... | 1   |
| Hex Wrench 3mm, 5mm.....      | 1   |
| Wrench or Socket 10mm.....    | 1   |
| 2x4 6' Long.....              | 1   |
| Feeler Gauge Set.....         | 1   |

### To use wood blocks:

1. Build wood blocks by cutting a *straight* 6-foot-long 2x4 in half.


**Note:** Having the wood blocks at an even height is critical to the accuracy of your overall adjustments. For best results, make the 2x4 square with a jointer and table saw before cutting it in half.

2. **G1021Z Only:** Make sure knives are set to correct height (refer to **Adjusting/Replacing Knives** on **Page 28** for detailed instructions).
3. DISCONNECT MACHINE FROM POWER!
4. Lower bed rollers below table surface (refer to **Bed Roller Height** on **Page 27** for detailed instructions).
5. Place wood blocks along sides of table, as illustrated in **Figure 58**.



**Figure 58.** Wood blocks properly positioned on the planer table.

6. Remove dust port, top cover, belt cover, and drive chain cover.
7. Raise table until wood blocks get close to cutterhead.
8. Use belt to rotate cutterhead and continue raising table until blocks just barely touch cutterhead knife/insert at its lowest point of rotation (BDC).
9. Lock table in place. Upward pressure of wood blocks will be holding infeed and outfeed rollers, chip breaker, and pressure bar at same level as knife/insert at BDC.
10. Loosen jam nuts and set screws on each side of infeed roller (see **Figure 59**).
11. Using a feeler gauge, adjust set screw so it is 0.040" from roller bushing block (see **Figure 59**), then tighten jam nut. Repeat on other side of infeed roller.




**Figure 59.** Example of feeler gauge location for adjusting infeed roller height when using wood blocks (one of two locations shown).

12. Repeat **Steps 10–11** with outfeed roller, only adjust the gaps to 0.020".



13. Loosen jam nuts and set screws on each side of chip breaker (see **Figure 60**).
14. Using a feeler gauge, adjust set screw so it is 0.040" from cross bar (see **Figure 60**), then tighten jam nut. Repeat on other side of chip breaker.



**Figure 60.** Example of feeler gauge locations for adjusting chip breaker height when using wood blocks.

15. Re-install belt cover, top cover, drive chain cover, and dust port.

## Adjusting Roller Spring Tension

The infeed and outfeed rollers keep the workpiece moving through the planer. Springs exert downward pressure on the feed rollers while allowing them to raise with an uneven workpiece surface. Proper spring tension is crucial to keep the workpiece moving through the planer during operation.


The ideal feed-roller spring tension varies depending upon the type of wood you plane. When adjusting spring tension, keep the following in mind:

- If you are planing milled lumber with a consistent surface, use less spring tension to reduce the risk of marring the workpiece.
- If you are planing rough lumber with inconsistent surfaces, use greater spring tension to keep the stock moving through the planer.
- If the workpiece consistently stops feeding during operation, the spring tension may need to be increased.

| <b>Items Needed</b> | <b>Qty</b> |
|---------------------|------------|
| Hex Wrench 5mm..... | 1          |

### To adjust feed-roller spring tension:

1. DISCONNECT MACHINE FROM POWER!
2. Rotate tension screws (shown below) clockwise to increase tension or counter-clockwise to decrease tension.



**Figure 61.** Example of roller spring tension adjustment screws.





# Positioning Chip Deflector

## Chip Deflector Gap Setting


If Planer Used w/Dust Collector ..... 1/4"  
 If Planer Used w/o Dust Collector ..... 1/16"

When properly distanced from the cutterhead, the chip deflector directs the chips into the dust hood, and keeps them from falling onto the outfeed roller and being pressed into the workpiece.

| Items Needed:              | Qty |
|----------------------------|-----|
| Wrench or Socket 10mm..... | 1   |
| Hex Wrench 5mm.....        | 1   |

### To adjust chip deflector gap:

1. DISCONNECT MACHINE FROM POWER!
2. Remove dust hood, top cover, and belt cover.
3. Use cutterhead pulley to rotate cutterhead until a knife/insert reaches closest distance to chip deflector (see **Figure** below), then measure distance between knife/insert and chip deflector.



**Figure 62.** Example of chip deflector and mounting hardware.

4. If distance measured in **Step 3** is *not* equal to correct chip deflector gap setting, then loosen flange bolts (see **Figure 62**) that secure chip deflector and adjust gap to correct setting.
5. Re-tighten flange bolts, then replace belt cover, top cover, and dust port.

# Calibrating Table Elevation Scale

Although correctly set at the factory, the table elevation scale can be adjusted for accuracy if necessary.


| Items Needed                 | Qty |
|------------------------------|-----|
| Phillips Screwdriver #2..... | 1   |
| Scrap Piece of Stock.....    | 1   |
| Calipers.....                | 1   |

### To calibrate table elevation scale:

1. Plane a scrap piece of stock until it is flat and of even thickness along its length.

**Note:** Turn board over between each pass.

2. Use calipers to measure board thickness.
3. If there is a discrepancy between board thickness and reading on table elevation scale, loosen the screw shown in **Figure 63**, adjust scale as necessary, then re-tighten screw.



**Figure 63.** Location of adjustment screw for table elevation scale.





# Checking Anti-Kickback Fingers

The anti-kickback fingers are an important safety feature of your planer. The fingers hang from a rod suspended across the head casting and in front of the infeed roller, as shown. This design allows the workpiece to easily enter the planer but reduces the risk of kickback by digging into the workpiece if it moves backward.




Figure 64. Anti-kickback fingers.

Check the anti-kickback fingers regularly to ensure they swing freely and easily. If the fingers do not swing freely and easily, first clean them with a wood-resin solvent, then inspect them for damage. If any of the fingers are damaged, the device must be replaced before using the machine.

Do not apply oil or other lubricants to the anti-kickback fingers that will attract dust and restrict free movement of the fingers.

## **⚠️ WARNING**

Proper operation of anti-kickback fingers is critical for safe operation of this planer. DO NOT operate planer if anti-kickback fingers are not operating correctly. Failure to heed this warning could result in serious personal injury.

# Tensioning Table Height Chain

The table height chain transfers movement from the elevation handwheel to the columns that control table height. The chain drive can be adjusted to remove slack if the chain stretches over time or is loosened during table leveling procedures.

| Items Needed                  | Qty |
|-------------------------------|-----|
| Phillips Screwdriver #2 ..... | 1   |
| Wrench or Socket 12mm .....   | 1   |

### To adjust table height chain tension:

1. DISCONNECT MACHINE FROM POWER!
2. Remove motor access panel to access table height to chain (see Figure 65).
3. Loosen the two chain tension lock bolts, then push idler sprocket against chain with moderate pressure to eliminate slack in chain. While maintaining pressure on idler sprocket, re-tighten lock bolts (see Figure 65).




Figure 65. Table height chain adjustment (shown without stand for purpose of illustration).

4. Clean and lubricate chain and sprockets (refer to **Table Height Chain & Sprockets** on Page 36 for detailed instructions), then re-install motor access panel.

## **NOTICE**

DO NOT let chain fall off sprockets. It can be very difficult to return chain to its proper location on sprockets without changing table adjustments.




# Adjusting Table Parallelism

## Maximum Allowable Tolerances:


Cutterhead/Table Side-to-Side.....0.002"  
 Head Casting/Table Front/Back ..... 0.020"

Table parallelism is critical to the operation of the machine. As such, it is essential that the table is parallel with the cutterhead (within 0.002") from side-to-side, as illustrated in **Figure 66**.



**Figure 66.** Side-to-side parallelism of table and cutterhead.

How the table sits in relation to the head casting from front-to-back is also important (see **Figure 67**). Because the feed rollers, pressure bar, and chip breaker will be adjusted off the table position, the tolerances on the front-to-back positioning are not as critical as the cutterhead/table side-to-side positioning. Therefore, the maximum allowable tolerance for the front-to-back parallelism is not more than 0.020".



**Figure 67.** Front-to-back parallelism of table and cutterhead.

## Table Parallelism Inspection

Use your Rotacator to inspect the table parallelism. If you do not have a Rotacator, a wood block and feeler gauges may be used, but extra care must be taken to ensure accuracy. If the table is not within the maximum allowable tolerances, it must be adjusted.

## Table Parallelism Adjustments

The table is adjusted by turning the chain sprockets underneath the table for movements over 0.008" or by adjusting how the table is mounted on the columns for movements under 0.008".

## NOTICE

When making adjustments, tighten fasteners after each step to ensure the accuracy of your tests. When adjusting the chain sprockets, keep in mind that if the chain becomes too loose, it will fall off of all the sprockets, and returning it to its proper location can be extremely difficult.

### To adjust table parallelism:


1. DISCONNECT MACHINE FROM POWER!
  2. Remove cabinet panel and locate chain on underside of table.
  3. Loosen idler sprocket (see **Chain Tension** instructions on **Page 36**).
  4. Move chain away from sprocket you want to adjust so only that sprocket can be rotated independent of chain.
- Note:** *If the left side of the table is too high, the left two sprockets will need to be adjusted. Each tooth on the sprocket represents .008" of vertical movement as the cogs are turned. Make sure, as you turn the sprockets, to keep an accurate tooth count to ensure that the table is adjusted equally.*
5. Mark location of one tooth of sprocket that you are adjusting.



6. Carefully rotate sprocket (clockwise to lower table; counterclockwise to raise table) just enough to position next tooth at marked location, then fit chain around sprocket again.
7. Repeat **Steps 4–6** with each sprocket that needs to be adjusted until table-to-cutterhead clearance is within 0.008" from one side to the other.
8. Make sure chain is properly fitted on sprockets, then re-tighten idler sprocket and lock bolts.

9. If necessary, micro-adjust table position by loosening cap screws shown in **Figure 68** and raising or lowering table until it is properly aligned with cutterhead.

**Note:** *This process may require adjusting the columns on both the left and right hand sides until you find the correct combination.*



**Figure 68.** Location of table micro-adjustment screws (one side shown only).



# SECTION 8: WIRING

These pages are current at the time of printing. However, in the spirit of improvement, we may make changes to the electrical systems of future machines. Compare the manufacture date of your machine to the one stated in this manual, and study this section carefully.

If there are differences between your machine and what is shown in this section, call Technical Support at (570) 546-9663 for assistance BEFORE making any changes to the wiring on your machine. An updated wiring diagram may be available. **Note:** *Please gather the serial number and manufacture date of your machine before calling. This information can be found on the main machine label.*

## WARNING

### Wiring Safety Instructions

**SHOCK HAZARD.** Working on wiring that is connected to a power source is extremely dangerous. Touching electrified parts will result in personal injury including but not limited to severe burns, electrocution, or death. Disconnect the power from the machine before servicing electrical components!

**MODIFICATIONS.** Modifying the wiring beyond what is shown in the diagram may lead to unpredictable results, including serious injury or fire. This includes the installation of unapproved after-market parts.

**WIRE CONNECTIONS.** All connections must be tight to prevent wires from loosening during machine operation. Double-check all wires disconnected or connected during any wiring task to ensure tight connections.

**CIRCUIT REQUIREMENTS.** You MUST follow the requirements at the beginning of this manual when connecting your machine to a power source.

**WIRE/COMPONENT DAMAGE.** Damaged wires or components increase the risk of serious personal injury, fire, or machine damage. If you notice that any wires or components are damaged while performing a wiring task, replace those wires or components.

**MOTOR WIRING.** The motor wiring shown in these diagrams is current at the time of printing but may not match your machine. If you find this to be the case, use the wiring diagram inside the motor junction box.
















**CAPACITORS/INVERTERS.** Some capacitors and power inverters store an electrical charge for up to 10 minutes after being disconnected from the power source. To reduce the risk of being shocked, wait at least this long before working on capacitors.

**EXPERIENCING DIFFICULTIES.** If you are experiencing difficulties understanding the information included in this section, contact our Technical Support at (570) 546-9663.

#### NOTICE


The photos and diagrams included in this section are best viewed in color. You can view these pages in color at [www.grizzly.com](http://www.grizzly.com).

#### COLOR KEY

|   |  |  |  |
|---|--|--|--|
| BLACK  | BLUE    | YELLOW        | LIGHT BLUE  |
| WHITE  | BROWN   | YELLOW GREEN  | BLUE WHITE  |
| GREEN  | GRAY    | PURPLE        | TURQUOISE   |
| RED    | ORANGE  | PINK          |  |



# G1021X2 Wiring Diagram



**⚠ WARNING!**

**SHOCK HAZARD!**  
Disconnect power before working on wiring.

**NOTICE**

The motor wiring shown here is current at the time of printing, but it may not match your machine. Always use the wiring diagram inside the motor junction box.





# G1021X2 Electrical Components




Figure 69. G1021X2 magnetic switch with cover removed.



Figure 70. G1021X2 motor junction box.





Figure 71. G1021X2 control panel.

# G1021Z Wiring Diagram







**WARNING!**

**SHOCK HAZARD!**  
Disconnect power before working on wiring.



### NOTICE

The motor wiring shown here is current at the time of printing, but it may not match your machine. Always use the wiring diagram inside the motor junction box.



# G1021Z Electrical Components



Figure 72. G1021Z magnetic switch with cover removed.




Figure 73. G1021Z motor junction box.



# SECTION 9: PARTS

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call (800) 523-4777 or visit [www.grizzly.com/parts](http://www.grizzly.com/parts) to check for availability.

## G1021X2 Main



# G1021X2 Main Parts List

| REF  | PART #       | DESCRIPTION                               |
|------|--------------|---|
| 1    | P1021X2001   | KNOB 5/16-18, D1-3/4, ROUND               |
| 2V2  | P1021X2002V2 | BELT/PULLEY COVER V2.05.18                |
| 3V2  | P1021X2003V2 | V-BELT M58 3L580 V2.05.18                 |
| 4    | P1021X2004   | STANDOFF-HEX MM 5/16-18 X 3/8, 3          |
| 5    | P1021X2005   | FLANGE BOLT M6-1 X 12                     |
| 6    | P1021X2006   | BELT/PULLEY GUARD                         |
| 7    | P1021X2007   | FLAT WASHER 5/16                          |
| 8    | P1021X2008   | HEX NUT 5/16-18                           |
| 9    | P1021X2009   | HEX BOLT M8-1.25 X 20                     |
| 10   | P1021X2010   | FENDER WASHER 8 X 30 X 4MM                |
| 11   | P1021X2011   | CUTTERHEAD PULLEY                         |
| 13   | P1021X2013   | UPPER COVER                               |
| 15V2 | P1021X2015V2 | FLANGE BOLT M6-1 X 12                     |
| 17   | P1021X2017   | CAP SCREW M6-1 X 20                       |
| 18   | P1021X2018   | RETURN ROLLER BRACKET                     |
| 19   | P1021X2019   | KEY 4 X 4 X 10                            |
| 20   | P1021X2020   | HANDWHEEL TYPE-3 151D X 10B-K X 3/8-16    |
| 21   | P1021X2021   | CHIP BREAKER                              |
| 22   | P1021X2022   | FLAT WASHER 10MM                          |
| 23   | P1021X2023   | HEX NUT M10-1.25                          |
| 24   | P1021X2024   | REVOLVING HANDLE 1 X 3-9/16, 3/8-16 X 1/2 |
| 25   | P1021X2025   | CHIP DEFLECTOR                            |
| 26   | P1021X2026   | HEX BOLT M6-1 X 12                        |
| 28   | P1021X2028   | FLAT SPRING 84 X 46 X 0.6MM               |
| 29   | P1021X2029   | TENSIONING SET SCREW M22-1.5 X 20         |
| 30   | P1021X2030   | SPACER 8.2 X 22 X 3MM                     |
| 31   | P1021X2031   | CHAIN TENSIONER                           |
| 32   | P1021X2032   | SHOULDER BOLT M8-1.25 X 14, 4 X 12        |
| 33   | P1021X2033   | IDLER WHEEL                               |
| 34   | P1021X2034   | IDLER SHAFT                               |
| 35   | P1021X2035   | ROLL PIN 6 X 20                           |
| 36V2 | P1021X2036V2 | DRIVE CHAIN COVER V2.05.18                |
| 37   | P1021X2037   | CAP SCREW M8-1.25 X 50                    |
| 38   | P1021X2038   | SET SCREW M6-1 X 16                       |
| 39   | P1021X2039   | EXTENSION SPRING 1 X 8.5 X 33             |
| 40   | P1021X2040   | SPRING BRACKET                            |
| 41   | P1021X2041   | BALL BEARING 6205-2RS                     |
| 42   | P1021X2042   | CAP SCREW M6-1 X 10                       |
| 43   | P1021X2043   | KEY 8 X 8 X 36                            |
| 44V2 | P1021X2044V2 | HELICAL CUTTERHEAD 15" V2.05.18           |
| 46   | P1021X2046   | SET SCREW M10-1.5 X 12                    |
| 47   | P1021X2047   | SET SCREW M8-1.25 X 12                    |
| 48   | P1021X2048   | COMPRESSION SPRING 3.5 X 19.7 X 70        |
| 49   | P1021X2049   | BUSHING BLOCK                             |
| 50   | P1021X2050   | BUSHING BLOCK PLATE                       |
| 51   | P1021X2051   | HEX NUT M6-1                              |
| 52   | P1021X2052   | HEAD CASTING                              |
| 53   | P1021X2053   | OUTFEED ROLLER                            |
| 54   | P1021X2054   | DEPTH LIMITER                             |
| 55   | P1021X2055   | FLAT HD SCR M5-.8 X 8                     |
| 56   | P1021X2056   | KEY 5 X 5 X 22                            |

| REF   | PART #        | DESCRIPTION                       |
|-------|---------------|-----------------------------------|
| 57V2  | P1021X2057V2  | SPROCKET 31T V2.05.18             |
| 58    | P1021X2058    | FENDER WASHER 6 X 20 X 3MM        |
| 59    | P1021X2059    | HEX BOLT M6-1 X 16                |
| 60    | P1021X2060    | CHAIN 06B-1 X 63 (31 LINKS)       |
| 60-1  | P1021X2060-1  | MASTER LINK                       |
| 61    | P1021X2061    | SPROCKET 31T                      |
| 63    | P1021X2063    | EXT RETAINING RING 12MM           |
| 64    | P1021X2064    | CHIP BREAKER ADJUSTMENT ROD       |
| 65    | P1021X2065    | CHIP BREAKER PIVOT ROD            |
| 66    | P1021X2066    | HEX NUT M12-1.75                  |
| 67    | P1021X2067    | E-CLIP 15MM                       |
| 68    | P1021X2068    | SPACER                            |
| 69    | P1021X2069    | ANTI-KICKBACK FINGER              |
| 70    | P1021X2070    | ANTI-KICKBACK SHAFT               |
| 71    | P1021X2071    | INFEED ROLLER                     |
| 72V2  | P1021X2072V2  | SPROCKET 31T V2.05.18             |
| 73    | P1021X2073    | CAP SCREW M6-1 X 12               |
| 74    | P1021X2074    | BALL BEARING 6204ZZ               |
| 75    | P1021X2075    | GEAR 16T                          |
| 76    | P1021X2076    | CAP SCREW M6-1 X 25               |
| 77    | P1021X2077    | BALL BEARING 6201-2RS             |
| 78    | P1021X2078    | GEAR 47T                          |
| 79    | P1021X2079    | GEARED SHAFT 18T                  |
| 80    | P1021X2080    | KEY 5 X 5 X 10                    |
| 81V2  | P1021X2081V2  | GEARBOX COVER V2.05.18            |
| 82    | P1021X2082    | LOCATING PIN 8 X 7.55 X 7.95      |
| 84V2  | P1021X2084V2  | GEARED SHAFT 28T/18T V2.02.19     |
| 85    | P1021X2085    | KEY 6 X 6 X 40                    |
| 86    | P1021X2086    | GEAR 71T                          |
| 87    | P1021X2087    | KNOB 3/8-16, D1-1/4, BALL         |
| 88    | P1021X2088    | CHAIN 06B-1 X 47 (23 LINKS)       |
| 88-1  | P1021X2088-1  | HALF LINK                         |
| 89    | P1021X2089    | SPROCKET 12T W/KEY                |
| 90V2  | P1021X2090V2  | OIL PLUG 1/4 NPT X 3/4" V2.05.18  |
| 91    | P1021X2091    | OIL SEAL 28 X 40 X 8              |
| 92V2  | P1021X2092V2  | GEARBOX V2.05.18                  |
| 92AV2 | P1021X2092AV2 | GEARBOX ASSEMBLY V2.05.18         |
| 93    | P1021X2093    | GASKET                            |
| 94V2  | P1021X2094V2  | COMBO GEAR 86T/96T V2.02.19       |
| 95    | P1021X2095    | BEARING SHAFT                     |
| 96    | P1021X2096    | GEAR SHAFT                        |
| 97    | P1021X2097    | COMPRESSION SPRING 0.6 X 5.9 X 16 |
| 98    | P1021X2098    | STEEL BALL 6MM                    |
| 99    | P1021X2099    | OIL SEAL 25 X 47 X 6              |
| 100   | P1021X2100    | BALL BEARING 6204ZZ               |
| 101   | P1021X2101    | KEY 5 X 5 X 12                    |
| 102   | P1021X2102    | SHIFTING FORK                     |
| 103   | P1021X2103    | SHIFTING SHAFT                    |
| 104   | P1021X2104    | O-RING 11.8 X 2.4 P12             |
| 108V2 | P1021X2108V2  | BALL BEARING 608ZZ V2.05.18       |
| 114   | P1021X2114    | SET SCREW M6-1 X 12               |






# G1021X2 Main Parts List (Cont.)

| REF | PART #     | DESCRIPTION                           |
|-----|------------|---------------------------------------|
| 166 | P1021X2166 | CARBIDE INSERTS 15 X 15 X 2.5MM-10 PK |
| 167 | P1021X2167 | FLAT HEAD TORX 10-32 X 1/2            |
| 169 | P1021X2169 | CAP SCREW M5-.8 X 5                   |
| 171 | P1021X2171 | WORM GEAR HOUSING                     |
| 172 | P1021X2172 | WORM SHAFT                            |
| 173 | P1021X2173 | BALL BEARING 6200ZZ                   |
| 174 | P1021X2174 | INT RETAINING RING 30MM               |
| 178 | P1021X2178 | RETURN ROLLER                         |
| 179 | P1021X2179 | DUST HOOD                             |
| 180 | P1021X2180 | FLANGE SCREW M6-1 X 12                |

| REF   | PART #       | DESCRIPTION                  |
|-------|--------------|------------------------------|
| 181   | P1021X2181   | CLIP-ON NUT M6-1             |
| 184   | P1021X2184   | PHLP HD SCR M4-.7 X 8        |
| 185V2 | P1021X2185V2 | CAP SCREW M8-1.25 X 10       |
| 186   | P1021X2186   | PULLEY GUARD PLATE           |
| 188V2 | P1021X2188V2 | GEARBOX COVER PLATE V2.05.18 |
| 190   | P1021X2190   | FLAT WASHER 8MM              |
| 191   | P1021X2191   | HEX BOLT M8-1.25 X 30        |
| 192   | P1021X2192   | LOCK WASHER 8MM              |
| 204   | P1021X2204   | HANDWHEEL DIRECTION LABEL    |



# G1021X2 Stand & Motor





# G1021X2 Stand & Motor Parts List

| REF       | PART #           | DESCRIPTION                            |
|-----------|------------------|--|
| 12V2      | P1021X2012V2     | STRAIN RELIEF TYPE-1 7/16 V2.05.18     |
| 16V2      | P1021X2016V2     | PHLP HD SCR M6-1 X 16                  |
| 45V2      | P1021X2045V2     | MAGNETIC SWITCH ASSY MPE-18 V2.05.18   |
| 45V2-1    | P1021X2045V2-1   | MAGNETIC SWITCH COVER (FRONT)          |
| 45V2-2    | P1021X2045V2-2   | MAGNETIC SWITCH COVER (REAR)           |
| 45V2-3    | P1021X2045V2-3   | CONTACTOR SDE MA-18 220-240V           |
| 45V2-4    | P1021X2045V2-4   | OL RELAY SDE RA-20 12-18A              |
| 45V2-5    | P1021X2045V2-5   | SWITCH CORD 12G 4W 79"                 |
| 45V2-6    | P1021X2045V2-6   | MOTOR CORD 12G 3W 33"                  |
| 45V2-7    | P1021X2045V2-7   | POWER CORD 12G 3W 138" 6-20P           |
| 62V2      | P1021X2062V2     | SWITCH MOUNTING PLATE V2.05.18         |
| 140       | P1021X2140       | PHLP HD SCR M5-.8 X 10                 |
| 141V2     | P1021X2141V2     | STAND V2.05.18                         |
| 142       | P1021X2142       | MOTOR ACCESS PANEL                     |
| 143       | P1021X2143       | FLAT HD SCR M6-1 X 12                  |
| 145       | P1021X2145       | SWITCH BOX                             |
| 146       | P1021X2146       | MOTOR MOUNT PLATE                      |
| 147       | P1021X2147       | LOCK COLLAR                            |
| 148       | P1021X2148       | SWITCH PLATE                           |
| 149V2     | P1021X2149V2     | MOTOR 3HP 230V 1-PH V2.05.18           |
| 149V2-1   | P1021X2149V2-1   | MOTOR FAN COVER                        |
| 149V2-2   | P1021X2149V2-2   | CAPACITOR COVER (START)                |
| 149V2-3   | P1021X2149V2-3   | CAPACITOR COVER (RUN)                  |
| 149V2-4   | P1021X2149V2-4   | MOTOR JUNCTION BOX                     |
| 149V2-5   | P1021X2149V2-5   | MOTOR FAN                              |
| 149V2-6   | P1021X2149V2-6   | START CAP 400M 125V 1-9/16 X 3-1/2     |
| 149V2-7V2 | P1021X2149V2-7V2 | R CAP 70M 250V 1-9/16 X 3-1/2 V2.09.18 |
| 149V2-8   | P1021X2149V2-8   | CONTACT PLATE                          |
| 149V2-9   | P1021X2149V2-9   | BALL BEARING 6205ZZ (FRONT)            |
| 149V2-10  | P1021X2149V2-10  | BALL BEARING 6203ZZ (REAR)             |
| 149V2-11  | P1021X2149V2-11  | CENTRIFUGAL SWITCH                     |

| REF   | PART #       | DESCRIPTION                           |
|-------|--------------|---------------------------------------|
| 150   | P1021X2150   | HEX BOLT M8-1.25 X 40                 |
| 151   | P1021X2151   | PLATE CONNECTING ROD                  |
| 152   | P1021X2152   | HEX NUT M8-1.25                       |
| 153   | P1021X2153   | FLAT WASHER 10 X 28 X 3MM             |
| 154   | P1021X2154   | ROD END BOLT M10-1.5 X 100, ID 16.5MM |
| 155   | P1021X2155   | START SWITCH                          |
| 156   | P1021X2156   | WRENCH 10 X 13MM OPEN-ENDS            |
| 158   | P1021X2158   | FOOT M8-1.25 X 67, D36                |
| 159   | P1021X2159   | HEX WRENCH 6MM                        |
| 161   | P1021X2161   | HEX WRENCH 4MM                        |
| 162   | P1021X2162   | HEX WRENCH 3MM                        |
| 164   | P1021X2164   | WRENCH 12 X 14MM OPEN-ENDS            |
| 165   | P1021X2165   | T-HANDLE TORX DRIVER T-25             |
| 176   | P1021X2176   | FRONT CABINET PANEL                   |
| 182   | P1021X2182   | PHLP HD SCR M4-.7 X 8                 |
| 183   | P1021X2183   | EXT TOOTH WASHER 4MM                  |
| 187   | P1021X2187   | STOP SWITCH                           |
| 189   | P1021X2189   | POWER INDICATOR LIGHT 220V 22MM RED   |
| 193V2 | P1021X2193V2 | SWITCH PEDESTAL V2.05.18              |
| 194   | P1021X2194   | HEX NUT M5-.8                         |
| 195   | P1021X2195   | HEX BOLT M5-.8 X 10                   |
| 196V2 | P1021X2196V2 | MOTOR PULLEY V2.05.18                 |
| 197   | P1021X2197   | FENDER WASHER 8 X 30 X 4MM            |
| 198V2 | P1021X2198V2 | HEX BOLT M8-1.25 X 25                 |
| 199   | P1021X2199   | KEY 5 X 5 X 30                        |
| 221   | P1021X2221   | FLANGE BOLT M6-1 X 12                 |
| 222   | P1021X2222   | HEX NUT M10-1.25                      |
| 223   | P1021X2223   | SPACER 8.2 X 22 X 3MM                 |
| 224   | P1021X2224   | HEX NUT M6-1                          |
| 225   | P1021X2225   | SET SCREW M6-1 X 12                   |



# G1021X2 Table & Base



# G1021X2 Table & Base


| REF   | PART #       | DESCRIPTION                     |
|-------|--------------|---------------------------------|
| 14    | P1021X2014   | HEX BOLT M8-1.25 X 25           |
| 19    | P1021X2019   | KEY 4 X 4 X 10                  |
| 27    | P1021X2027   | FLAT WASHER 8MM                 |
| 105   | P1021X2105   | EXTENSION TABLE (CAST IRON)     |
| 107   | P1021X2107   | ECCENTRIC SHAFT                 |
| 109   | P1021X2109   | TABLE ROLLER                    |
| 109-1 | P1021X2109-1 | BALL BEARING 608-2RS            |
| 110V2 | P1021X2110V2 | KNOB 6-LOBE M12-1.75, D53       |
| 111   | P1021X2111   | THREADED GIB                    |
| 112   | P1021X2112   | LOCKING ROD                     |
| 113   | P1021X2113   | MAIN TABLE                      |
| 115   | P1021X2115   | GIB                             |
| 116   | P1021X2116   | RIVET 2 X 5MM NAMEPLATE, COPPER |
| 117   | P1021X2117   | LEADSCREW NUT                   |
| 118   | P1021X2118   | LEADSCREW, SECONDARY            |
| 119   | P1021X2119   | COLUMN                          |
| 120   | P1021X2120   | CHAIN #410 X 134                |
| 121   | P1021X2121   | EXT RETAINING RING 15MM         |
| 122   | P1021X2122   | IDLER SPROCKET 10T              |
| 123   | P1021X2123   | IDLER SHAFT                     |
| 124   | P1021X2124   | IDLER BRACKET                   |
| 125   | P1021X2125   | BASE                            |
| 126   | P1021X2126   | HEX BOLT M8-1.25 X 25           |

| REF | PART #     | DESCRIPTION             |
|-----|------------|-------------------------|
| 127 | P1021X2127 | BALL BEARING 6202ZZ     |
| 128 | P1021X2128 | INT RETAINING RING 35MM |
| 129 | P1021X2129 | SPROCKET 10T            |
| 130 | P1021X2130 | SCALE COLUMN            |
| 131 | P1021X2131 | SCALE                   |
| 132 | P1021X2132 | PHLP HD SCR M3-.5 X 6   |
| 133 | P1021X2133 | E-CLIP 12MM             |
| 134 | P1021X2134 | LIFTING BAR             |
| 135 | P1021X2135 | EXT RETAINING RING 10MM |
| 136 | P1021X2136 | GEAR 14T                |
| 137 | P1021X2137 | INT RETAINING RING 38MM |
| 138 | P1021X2138 | SPACER                  |
| 139 | P1021X2139 | LEADSCREW, PRIMARY      |
| 144 | P1021X2144 | HEX BOLT M8-1.25 X 45   |
| 226 | P1021X2226 | CAP SCREW M6-1 X 20     |
| 227 | P1021X2227 | FLAT WASHER 10MM        |
| 228 | P1021X2228 | HEX NUT M10-1.25        |
| 229 | P1021X2229 | SPACER 8.2 X 22 X 3MM   |
| 230 | P1021X2230 | SET SCREW M10-1.5 X 12  |
| 231 | P1021X2231 | SET SCREW M8-1.25 X 12  |
| 232 | P1021X2232 | SET SCREW M6-1 X 12     |
| 233 | P1021X2233 | FLAT WASHER 8MM         |





# G1021X2 Labels & Cosmetics



| REF   | PART #       | DESCRIPTION                   |
|-------|--------------|-------------------------------|
| 201V2 | P1021X2201V2 | DISCONNECT POWER LABEL        |
| 202V3 | P1021X2202V3 | MACHINE ID LABEL V3.02.19     |
| 205V3 | P1021X2205V3 | SHIFT GEARBOX NOTICE V3.02.19 |
| 206   | P1021X2206   | TOUCH-UP PAINT, GRIZZLY PUTTY |
| 207V2 | P1021X2207V2 | READ MANUAL LABEL             |
| 208   | P1021X2208   | TOUCH-UP PAINT, GRIZZLY GREEN |
| 209   | P1021X2209   | EXTREME SERIES NAMEPLATE      |
| 210   | P1021X2210   | GRIZZLY NAMEPLATE-LARGE       |


| REF   | PART #       | DESCRIPTION                       |
|-------|--------------|-----------------------------------|
| 213   | P1021X2213   | ELECTRICITY LABEL                 |
| 215V2 | P1021X2215V2 | BELT COVER WARNING LABEL V2.05.18 |
| 216V2 | P1021X2216V2 | ADD OIL NOTICE V2.05.18           |
| 217V2 | P1021X2217V2 | MODEL NUMBER LABEL V2.05.18       |
| 218   | P1021X2218   | STOP OIL FILL TAG                 |
| 219   | P1021X2219   | INVENTORY SHIPPING NOTICE         |
| 220   | P1021X2220   | EYE/EAR/LUNG INJURY LABEL         |

**⚠ WARNING**

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com).



# G1021Z Main



# G1021Z Main Parts List

| REF    | PART #       | DESCRIPTION                               |
|--------|--------------|---|
| 1      | P1021Z001    | PULLEY/BELT COVER                         |
| 2      | P1021Z002    | FLANGE BOLT M6-1 X 12                     |
| 3V2    | P1021Z003V2  | V-BELT M58 3L580                          |
| 4      | P1021Z004    | HEX BOLT M8-1.25 X 25                     |
| 5      | P1021Z005    | FENDER WASHER 8 X 30 X 4MM                |
| 6      | P1021Z006    | KNOB 5/16-18, D1-3/4, ROUND               |
| 7      | P1021Z007    | CUTTERHEAD PULLEY                         |
| 9      | P1021Z009    | PULLEY GUARD PLATE                        |
| 10     | P1021Z010    | LOCK WASHER 8MM                           |
| 11     | P1021Z011    | SPROCKET 31T                              |
| 12     | P1021Z012    | STANDOFF-HEX MM 5/16-18 X 3/8, 3          |
| 13     | P1021Z013    | PULLEY GUARD                              |
| 21     | P1021Z021    | WORM GEAR HOUSING                         |
| 21-1   | P1021Z021-1  | RETURN ROLLER BRACKET                     |
| 22     | P1021Z022    | HEAD CASTING                              |
| 23     | P1021Z023    | CHIP DEFLECTOR                            |
| 25     | P1021Z025    | TENSIONING SET SCREW M22-1.5 X 20         |
| 26     | P1021Z026    | CAP SCREW M8-1.25 X 50                    |
| 27     | P1021Z027    | SET SCREW M6-1 X 12                       |
| 28     | P1021Z028    | FLAT SPRING 84 X 46 X 0.6MM               |
| 30     | P1021Z030    | HEX NUT M10-1.25                          |
| 31     | P1021Z031    | FLAT WASHER 10MM                          |
| 32     | P1021Z032    | REVOLVING HANDLE 1 X 3-9/16, 3/8-16 X 1/2 |
| 33     | P1021Z033    | HANDWHEEL TYPE-3 151D X 10B-K X 3/8-16    |
| 34V2   | P1021Z034V2  | INT RETAINING RING 30MM                   |
| 36     | P1021Z036    | SET SCREW M10-1.5 X 12                    |
| 79     | P1021Z079    | CAP SCREW M6-1 X 20                       |
| 87     | P1021Z087    | HEX BOLT M6-1 X 12                        |
| 90     | P1021Z090    | SET SCREW M6-1 X 16                       |
| 90-1   | P1021Z090-1  | HEX NUT M6-1                              |
| 91     | P1021Z091    | HEX BOLT M8-1.25 X 20                     |
| 92     | P1021Z092    | BUSHING BLOCK PLATE                       |
| 94     | P1021Z094    | SET SCREW M8-1.25 X 12                    |
| 97     | P1021Z097    | UPPER COVER                               |
| 99     | P1021Z099    | ROLL PIN 6 X 20                           |
| 100    | P1021Z100    | BALL BEARING 6205-2RS                     |
| 101V2  | P1021Z101V2  | KEY 8 X 8 X 36 V2.05.18                   |
| 102    | P1021Z102    | CUTTERHEAD 15" 3-KNIFE                    |
| 103    | P1021Z103    | COMPRESSION SPRING 0.6 X 5.9 X 16         |
| 104    | P1021Z104    | GIB BOLT M8-1.25 X 10                     |
| 105    | P1021Z105    | GIB                                       |
| 106    | P1021Z106    | CHAIN TENSIONER                           |
| 107V2  | P1021Z107V2  | OIL PLUG 1/4 NPT X 3/4" V2.05.18          |
| 108    | P1021Z108    | OIL SEAL 28 X 40 X 8                      |
| 109V2  | P1021Z109V2  | GEARBOX V2.05.18                          |
| 109AV2 | P1021Z109AV2 | GEARBOX ASSEMBLY V2.05.18                 |
| 110    | P1021Z110    | GASKET                                    |
| 111    | P1021Z111    | BALL BEARING 6204ZZ                       |
| 112    | P1021Z112    | GEAR 16T                                  |
| 114    | P1021Z114    | BALL BEARING 6201ZZ                       |
| 115    | P1021Z115    | GEAR 47T                                  |
| 116A   | P1021Z116A   | KEY 5 X 5 X 12                            |
| 116B   | P1021Z116B   | KEY 5 X 5 X 10                            |
| 117    | P1021Z117    | GEARED SHAFT 18T                          |
| 119V2  | P1021Z119V2  | GEARED SHAFT 28T/18T V2.02.19             |
| 120    | P1021Z120    | GEAR 71T                                  |

| REF   | PART #      | DESCRIPTION                           |
|-------|-------------|---------------------------------------|
| 121V2 | P1021Z121V2 | COMBO GEAR 86T/96T V2.02.19           |
| 122   | P1021Z122   | GEAR SHAFT                            |
| 123   | P1021Z123   | KEY 6 X 6 X 40                        |
| 125   | P1021Z125   | OIL SEAL 25 X 47 X 6                  |
| 127   | P1021Z127   | COMPRESSION SPRING 0.6 X 5.9 X 16     |
| 128   | P1021Z128   | STEEL BALL 6MM                        |
| 129   | P1021Z129   | SHIFTING FORK                         |
| 131   | P1021Z131   | SHIFTING SHAFT                        |
| 132   | P1021Z132   | O-RING 12 X 1.5 S12.5                 |
| 133V2 | P1021Z133V2 | GEARBOX COVER V2.05.18                |
| 134   | P1021Z134   | KNOB 3/8-16, D1-1/4, BALL             |
| 135   | P1021Z135   | CAP SCREW M6-1 X 25                   |
| 136   | P1021Z136   | LOCATING PIN 8 X 7.55 X 7.95          |
| 137   | P1021Z137   | SPROCKET 12T W/KEY                    |
| 138   | P1021Z138   | FENDER WASHER 6.2 X 22 X 3            |
| 139   | P1021Z139   | HEX BOLT M6-1 X 16                    |
| 140   | P1021Z140   | CHAIN 06B-1 X 47 (23 LINKS)           |
| 141V2 | P1021Z141V2 | DRIVE CHAIN COVER V2.05.18            |
| 142V2 | P1021Z142V2 | CAP SCREW M8-1.25 X 10                |
| 147   | P1021Z147   | CAP SCREW M6-1 X 12                   |
| 148   | P1021Z148   | FENDER WASHER 6 X 20 X 3MM            |
| 149V2 | P1021Z149V2 | SPROCKET 31T V2.05.18                 |
| 150   | P1021Z150   | KEY 5 X 5 X 22                        |
| 151   | P1021Z151   | OUTFEED ROLLER                        |
| 152   | P1021Z152   | COMPRESSION SPRING 3.5 X 19.7 X 70    |
| 153   | P1021Z153   | BUSHING BLOCK                         |
| 154   | P1021Z154   | CHIP BREAKER                          |
| 155   | P1021Z155   | HEX NUT M6-1                          |
| 156   | P1021Z156   | SET SCREW M6-1 X 12                   |
| 157   | P1021Z157   | CHIP BREAKER ADJUSTMENT ROD           |
| 159   | P1021Z159   | E-CLIP 15MM                           |
| 160   | P1021Z160   | SPACER                                |
| 161V2 | P1021Z161V2 | ANTI-KICKBACK FINGER V2.05.18         |
| 162   | P1021Z162   | ANTI-KICKBACK SHAFT                   |
| 163   | P1021Z163   | INFEED ROLLER                         |
| 164V2 | P1021Z164V2 | SPROCKET 31T V2.05.18                 |
| 165A  | P1021Z165A  | CHAIN 06B-1 X 63 (31 LINKS)           |
| 166   | P1021Z166   | KNIFE-SETTING JIG ASSEMBLY            |
| 166-1 | P1021Z166-1 | E-CLIP 9MM                            |
| 166-2 | P1021Z166-2 | KNIFE-SETTING JIG FOOT                |
| 166-3 | P1021Z166-3 | KNIFE-SETTING JIG SHAFT               |
| 168V2 | P1021Z168V2 | DUST HOOD V2.05.18                    |
| 170   | P1021Z170   | 15" X 1" X 1/8" HSS PLANER BLADES (3) |
| 172   | P1021Z172   | HALF LINK                             |
| 173   | P1021Z173   | MASTER LINK                           |
| 174   | P1021Z174   | DEPTH LIMITER                         |
| 175V2 | P1021Z175V2 | FLAT HD SCR M5-.8 X 8                 |
| 176V2 | P1021Z176V2 | SPACER 8.2 X 22 X 3MM V2.05.18        |
| 177   | P1021Z177   | EXT RETAINING RING 12MM               |
| 178   | P1021Z178   | CHIP BREAKER PIVOT ROD                |
| 179   | P1021Z179   | HEX NUT M12-1.75                      |
| 191   | P1021Z191   | CAP SCREW M6-1 X 10                   |
| 194   | P1021Z194   | EXTENSION SPRING 1 X 8.5 X 33         |
| 195   | P1021Z195   | SHOULDER BOLT M8-1.25 X 14, 4 X 12    |
| 196   | P1021Z196   | SPRING BRACKET                        |




# G1021Z Main Parts List (Cont.)

| REF   | PART #      | DESCRIPTION                 |
|-------|-------------|-----------------------------|
| 198   | P1021Z198   | HANDWHEEL DIRECTION LABEL   |
| 206   | P1021Z206   | BEARING SHAFT               |
| 207V2 | P1021Z207V2 | BALL BEARING 608ZZ V2.05.18 |
| 208   | P1021Z208   | WORM SHAFT                  |
| 209   | P1021Z209   | KEY 4 X 4 X 10              |
| 210   | P1021Z210   | BALL BEARING 6200ZZ         |
| 211   | P1021Z211   | RETURN ROLLER               |
| 219   | P1021Z219   | FLAT WASHER 5/16            |

| REF | PART #    | DESCRIPTION           |
|-----|-----------|-----------------------|
| 220 | P1021Z220 | HEX NUT 5/16-18       |
| 224 | P1021Z224 | IDLER SHAFT           |
| 225 | P1021Z225 | IDLER WHEEL           |
| 226 | P1021Z226 | FLAT WASHER 8MM       |
| 242 | P1021Z242 | GEARBOX COVER PLATE   |
| 243 | P1021Z243 | PHLP HD SCR M4-.7 X 8 |
| 244 | P1021Z244 | CLIP-ON NUT M6-1      |



# G1021Z Stand & Motor




| REF      | PART #          | DESCRIPTION                            |
|----------|-----------------|--|
| 8        | P1021Z008       | MOTOR PULLEY                           |
| 16V2     | P1021Z016V2     | MOTOR 3HP 230V 1-PH V2.05.18           |
| 16V2-1   | P1021Z016V2-1   | MOTOR FAN COVER                        |
| 16V2-2   | P1021Z016V2-2   | CAPACITOR COVER (START)                |
| 16V2-3   | P1021Z016V2-3   | CAPACITOR COVER (RUN)                  |
| 16V2-4   | P1021Z016V2-4   | MOTOR JUNCTION BOX                     |
| 16V2-5   | P1021Z016V2-5   | MOTOR FAN                              |
| 16V2-6   | P1021Z016V2-6   | START CAP 400M 125V 1-9/16 X 3-1/2     |
| 16V2-7V2 | P1021Z016V2-7V2 | R CAP 70M 250V 1-9/16 X 3-1/2 V2.09.18 |
| 16V2-8   | P1021Z016V2-8   | CONTACT PLATE                          |
| 16V2-9   | P1021Z016V2-9   | BALL BEARING 6205ZZ (FRONT)            |
| 16V2-10  | P1021Z016V2-10  | BALL BEARING 6203ZZ (REAR)             |
| 16V2-11  | P1021Z016V2-11  | CENTRIFUGAL SWITCH                     |
| 17       | P1021Z017       | MOTOR MOUNT PLATE                      |
| 18       | P1021Z018       | HEX BOLT M8-1.25 X 40                  |
| 19V2     | P1021Z019V2     | SPACER 8.2 X 22 X 3MM V2.05.18         |
| 20       | P1021Z020       | HEX NUT M8-1.25                        |
| 40V2     | P1021Z040V2     | MAGNETIC SWITCH ASSY MP-18 V2.05.18    |
| 40V2-1   | P1021Z040V2-1   | MAGNETIC SWITCH COVER (FRONT)          |
| 40V2-2   | P1021Z040V2-2   | MAGNETIC SWITCH COVER (REAR)           |
| 40V2-3   | P1021Z040V2-3   | CONTACTOR SDE MA-18 220-240V           |
| 40V2-4   | P1021Z040V2-4   | OL RELAY SDE RA-20 12-18A              |
| 41       | P1021Z041       | PLATE CONNECTING ROD                   |

| REF   | PART #      | DESCRIPTION                           |
|-------|-------------|---------------------------------------|
| 42    | P1021Z042   | SWITCH MOUNT BRACKET                  |
| 169V2 | P1021Z169V2 | CABINET STAND V2.05.18                |
| 180V2 | P1021Z180V2 | STRAIN RELIEF TYPE-1 7/16 V2.05.18    |
| 183V2 | P1021Z183V2 | POWER CORD 12G 3W 150" 6-20P V2.05.18 |
| 184   | P1021Z184   | SWITCH CORD 12G 3W 30"                |
| 185   | P1021Z185   | KEY 5 X 5 X 30                        |
| 186   | P1021Z186   | HEX WRENCH 3MM                        |
| 187   | P1021Z187   | HEX WRENCH 4MM                        |
| 189   | P1021Z189   | HEX WRENCH 6MM                        |
| 197   | P1021Z197   | WRENCH 12 X 14MM OPEN-ENDS            |
| 199   | P1021Z199   | WRENCH 10 X 13MM OPEN-ENDS            |
| 201   | P1021Z201   | SET SCREW M6-1 X 12                   |
| 202   | P1021Z202   | HEX NUT M10-1.25                      |
| 203   | P1021Z203   | FENDER WASHER 10 X 28 X 3MM           |
| 204   | P1021Z204   | ROD END BOLT M10-1.5 X 100, ID 16.5MM |
| 205   | P1021Z205   | LOCK COLLAR                           |
| 218   | P1021Z218   | PHLP HD SCR M6-1 X 12                 |
| 227   | P1021Z227   | FOOT M8-1.25 X 67, D36                |
| 228   | P1021Z228   | MOTOR ACCESS PANEL                    |
| 229   | P1021Z229   | FLAT HD SCR M6-1 X 12                 |
| 245   | P1021Z245   | HEX BOLT M8-1.25 X 25                 |
| 246   | P1021Z246   | FENDER WASHER 8 X 30 X 4MM            |





# G1021Z Table & Base




# G1021Z Table & Base

| REF PART # | DESCRIPTION                       |
|------------|-----------------------------------|
| 43         | P1021Z043 COLUMN                  |
| 44         | P1021Z044 LEADSCREW NUT           |
| 45         | P1021Z045 LEADSCREW, SECONDARY    |
| 46         | P1021Z046 KEY 4 X 4 X 10          |
| 48         | P1021Z048 SCALE COLUMN            |
| 49         | P1021Z049 SCALE                   |
| 50         | P1021Z050 PHLP HD SCR M3-.5 X 6   |
| 51         | P1021Z051 LEADSCREW, PRIMARY      |
| 52         | P1021Z052 POINTER                 |
| 53         | P1021Z053 MAIN TABLE              |
| 55         | P1021Z055 BALL BEARING 6202ZZ     |
| 57         | P1021Z057 SPROCKET 10T            |
| 62         | P1021Z062 E-CLIP 12MM             |
| 63         | P1021Z063 LIFTING BAR             |
| 64         | P1021Z064 BASE                    |
| 65         | P1021Z065 IDLER BRACKET           |
| 66         | P1021Z066 IDLER SHAFT             |
| 67         | P1021Z067 IDLER SPROCKET 10T      |
| 68         | P1021Z068 EXT RETAINING RING 15MM |
| 69         | P1021Z069 TABLE ROLLER            |
| 70         | P1021Z070 BALL BEARING 608-2RS    |
| 71         | P1021Z071 HEX BOLT M8-1.25 X 25   |
| 72         | P1021Z072 HEX BOLT M8-1.25 X 45   |

| REF PART # | DESCRIPTION                                      |
|------------|--|
| 73         | P1021Z073 INT RETAINING RING 35MM                |
| 74         | P1021Z074 FLAT WASHER 8MM                        |
| 75         | P1021Z075 FLAT WASHER 10MM                       |
| 76         | P1021Z076 HEX NUT M10-1.5                        |
| 77         | P1021Z077 CHAIN #410 X 134                       |
| 78         | P1021Z078 SET SCREW M6-1 X 12                    |
| 80         | P1021Z080 ECCENTRIC SHAFT                        |
| 82V2       | P1021Z082V2 HEX BOLT M8-1.25 X 25 V2.04.20       |
| 83V2       | P1021Z083V2 EXTENSION TABLE (CAST IRON) V2.04.20 |
| 86         | P1021Z086 SET SCREW M8-1.25 X 12                 |
| 143        | P1021Z143 THREADED GIB                           |
| 144        | P1021Z144 LOCKING ROD                            |
| 145        | P1021Z145 KNOB 6-LOBE M12-1.75, D53              |
| 146        | P1021Z146 GIB                                    |
| 190        | P1021Z190 RIVET 2 X 5MM                          |
| 212        | P1021Z212 EXT RETAINING RING 10MM                |
| 213        | P1021Z213 GEAR 14T                               |
| 214        | P1021Z214 INT RETAINING RING 38MM                |
| 215        | P1021Z215 SPACER                                 |
| 247        | P1021Z247 SET SCREW M10-1.5 X 12                 |
| 248        | P1021Z248 CAP SCREW M6-1 X 20                    |
| 250        | P1021Z250 FLAT WASHER 8MM                        |



# G1021Z Labels & Cosmetics



| REF   | PART #      | DESCRIPTION                       |
|-------|-------------|-----------------------------------|
| 216V3 | P1021Z216V3 | MACHINE ID LABEL V3.02.19         |
| 217V2 | P1021Z217V2 | BELT COVER WARNING LABEL V2.05.18 |
| 222   | P1021Z222   | GRIZZLY NAMEPLATE-LARGE           |
| 230   | P1021Z230   | INVENTORY SHIPPING NOTICE         |
| 231   | P1021Z231   | DISCONNECT POWER LABEL            |
| 232   | P1021Z232   | READ MANUAL LABEL                 |
| 233   | P1021Z233   | ADD OIL NOTICE                    |
| 234V2 | P1021Z234V2 | SHIFT GEARBOX NOTICE V2.02.19     |

| REF | PART #    | DESCRIPTION                   |
|-----|-----------|-------------------------------|
| 235 | P1021Z235 | STOP OIL FILL TAG             |
| 236 | P1021Z236 | EYE/EAR/LUNG INJURY LABEL     |
| 237 | P1021Z237 | ELECTRICITY LABEL             |
| 238 | P1021Z238 | GRIZZLY.COM LABEL             |
| 239 | P1021Z239 | MODEL NUMBER LABEL            |
| 240 | P1021Z240 | TOUCH-UP PAINT, GRIZZLY PUTTY |
| 241 | P1021Z241 | TOUCH-UP PAINT, GRIZZLY GREEN |

**⚠ WARNING**

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com).



# WARRANTY & RETURNS

---

Grizzly Industrial, Inc. warrants every product it sells for a period of **1 year** to the original purchaser from the date of purchase. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence, accidents, repairs or alterations or lack of maintenance. This is Grizzly's sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant or represent that the merchandise complies with the provisions of any law or acts unless the manufacturer so warrants. In no event shall Grizzly's liability under this warranty exceed the purchase price paid for the product and any legal actions brought against Grizzly shall be tried in the State of Washington, County of Whatcom.

We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special, or consequential damages arising from the use of our products.

The manufacturers reserve the right to change specifications at any time because they constantly strive to achieve better quality equipment. We make every effort to ensure that our products meet high quality and durability standards and we hope you never need to use this warranty.

In the event you need to use this warranty, contact us by mail or phone and give us all the details. We will then issue you a "Return Number," which must be clearly posted on the outside as well as the inside of the carton. We will not accept any item back without this number. Proof of purchase must accompany the merchandise.

Please feel free to write or call us if you have any questions about the machine or the manual.

Thank you again for your business and continued support. We hope to serve you again soon.

To take advantage of this warranty, you must register it at <https://www.grizzly.com/forms/warranty>, or you can scan the QR code below to be automatically directed to our warranty registration page. Enter all applicable information for the product.









# *grizzly.com*<sup>®</sup>

**TOOL WEBSITE**

Buy Direct and Save with Grizzly<sup>®</sup> – Trusted, Proven and a Great Value!  
~Since 1983~

*Visit Our Website Today For  
Current Specials!*

**ORDER  
24 HOURS A DAY!  
1-800-523-4777**

