LS-2600 Leak Sensors



Level Sense LS2600 Surface Liquid Sensor connects to a control device accepting an analog or digital input.

• Size: L64*W15.6*H12.7mm

Housing: ABS, white

Working Voltage: 5Vdc-24Vdc

Max. Voltage: 24Vdc

Max. Working Current: 0.5 Amp

• Temperature: $14^{\circ}F + 150^{\circ}F / (-10^{\circ}C + 65^{\circ}C)$

• Black wire to Positive, Red wire to Negative (ground)

Perfect for Arduio, Rasberry Pi, and home electronics projects.

If you are using this in home electronics projects, please take note of the following:

- This device is not providing a "contact closure" it is providing a trickle current between the two contacts when water with some ionic content is present.
- The Leak sensor behaves as an open circuit when no water is present, and behaves as a (roughly) $1.4M\Omega$ resistor when water is present. The resistance of it *depends on your water*.
- To confirm if the device is working, place the ohmmeter probes directly into water approximately 1.5" inches apart and take a reading. Then place the sensor in water and connect the ohmmeter to the red and white wires. The two readings should be similar.
- To get the best circuit design, put the sensor feet in water and measure the resistance with an ohmmeter. Use this resistance in your circuit design.
- In the unlikely event you have "non-conductive" water, it can be easily rectified by sprinkling some salt around the sensor location. The water will absorb the salt, the salt will ionize the water, and allow it to conduct.
- If you are using this sensor as an input to an Arduino or raspberry Pi, it is recommended to use either an Analog input, or a "PULL UP" input where the sensor is taking an input to ground.


| Application | Red Wire Connection | Black Wire Connection |
|---|---------------------|------------------------|
| Arduino / RP Analog Input | +5VDC | Input, with |
| | | 5MΩ Pull Down Resistor |
| Arduino Discrete Input (pinmode=PULL UP) | Input | Ground |
| Solid State Relay Control (with 3-32VDC Coil) and 12-24VDC+ Power Source | Coil - | Ground |

For help or assistance, call our support line at 314-787-8059 ext 2.


LS-2600 Leak Sensors



LS-2600 WITH MICROCONTROLLER ANALOG INPUT



LS-2600 WITH MICROCONTROLLER DIGITAL INPUT



ACTIVATING SOLID STATE RELAY WITH THE LS-2600 TO POWER A 120VAC PUMP (OR SOLENOID)

