

Radar 10ft Fin Pedal Drive Kayak Assembly Booklet

Congratulations on buying your Reel Yaks pedal kayak!! Note we also have assembly videos on our website at Reelyaks.com and on YouTube. If you have any questions on your Reel Yaks kayak assembly, then please email us at info@reelyaks.com or call us on 855 202 5035.

There are **six key** pieces of assembly to be done:

- 2 x Kayak halves
- Pedal drive
- Rudder
- Stadium seat
- Paddle
- Fishing rod holder

First step is to unpack your kayak which should come in two boxes and the kayak parts will have an outer sheet of bubble wrap, and some parts will be in cardboard boxes (e.g.: pedal drive). Please ensure to dispose of these materials safely in particular the plastic.



Each package will have:

- 1 x kayak (in two sections)
- 1 x rudder
- 1 x rudder security (cotter) pin
- 1 x paddle (in two sections)
- 1 x fin pedal drive unit
- 1 x pedals (2)
- 1 x spare fins (2)
- 1 x stadium chair
- 1 x fishing rod holder

The larger items will be secured in the main cockpit area: pedal drive unit, pedal drive pedals, spare fins, paddle and stadium chair. Others like the fishing rod holder will be inside the cockpit hatch.


Kayak Assembly

For the kayak assembly ensure you have the two halves facing each other.

Step 1) Flip the kayak over so it's bottom up and bring the two halves together

Step 2) Close the three underside latches

Step 3) Flip the kayak over so its facing up the right way and close the top two latches



The latches should be set correctly for your kayak, but if you find you're having to force it then stop. Adjust the nut (orange arrow) to get a firm lock closure, but not without forcing it. If it's too loose then adjust the nut accordingly to get a good firm fit. Forcing the latch closed for an overly tight fit can damage the screws unnecessarily (blue arrow) on the adjoining catch.



Pedal Drive Assembly

For the pedal drive assembly ensure that you have the main unit with flaps (x1) attached and the pedals (x2).




Note the numbering on the top of the pedal drive unit, to know which is forward, '1' will be at the bottom (closest to the seat) for shorter people and '7' for taller people. For the time being don't worry about the numbering as this will help you set the correct leg length later on. Insert each pedal (**green arrow**) with the main bolt fully un-screwed (**orange arrow**), and while holding the red handle depressed. Aim for insertion around '3' on the top of the unit so each pedal is at the same locked location. The insertion will deliver a tight fit and once the spring-loaded ping beneath the red handle pops in then go ahead and secure the main bolt again. It's always worth checking all the nuts on the drive are tight before using if for the first time e.g.: brass nuts, etc. Loctite while not required is always a good preventative measure if you have any concerns.



RY REEL YAKS

Once the pedals have been inserted into the drive unit, then drop the pedal drive into place, and the kayak locking pins should lock over the pins.



Note sometimes it requires pulling the pedals firmly to the left and right (**orange arrows**) each time when inserting the drive for the pins to lock in place. However, you do need to keep this in mind when beaching the kayak, by always pushing forward on one of the pedals to ensure the flaps are feathered and being careful when dragging the kayak up the beach.

We recommend removing the drive in deep enough water before coming into beach.




Once you are in the kayak on the water you can then adjust the red handles on the pedals to fit your leg length.

Rudder Assembly

In some case the rudder handle may be in the front compartment. Use the supplied screw to secure it (**orange arrow**). Ensure when you've completed securing the handle that you have left it in the neutral position, with the handle parallel to the centre line of the kayak (**blue arrow**).




Next, ensure your rudder is untangled and the lines run free when taking it out of the cargo area. Put the pin of the rudder through the rear hole in the kayak. Check that the raising and lowering of the rudder operates smoothly. Next put in the rudder security pin (**orange arrow**) through the hole at the bottom of the rudder pin.



RY REEL YAKS


Next unwind the butterfly nuts and put them through the plastic holes on either side of the rudder and righten the butterfly nuts again.



Next grab hold of the rudder steering handle on the left side of the kayak near where the seat would be located. Pull the rudder handle all the way left and then all the way right, to ensure the rudder is tracking correctly, adjust the butterfly nuts as needed. Leave the rudder steering in the approximate centre spot. The steering wires should have a little bit of slack for ease of turning and to ensure minimal wear and tear where they enter the kayak.


In most cases the rudders lowering and raising cable is attached for transport (**Green Arrow**). However, in some cases it may not be and you'll need to thread the rudder rope through the center line of the rudder and attach it.

- 1) Thread it through the main hole at the start of the rudder (**Yellow Arrow**)
- 2) over the top of the wheel, but under the cross bar
- 3) down through the gap (**Purple Arrow**) and
- 4) then thread it through the hole (**blue arrow**) and tie a knot.



RY REEL YAKS

Test your rudder by pulling on the rudder raising/lower cable on the right side of the cockpit. 1) rudder is deployed and down in the water 2) rudder is pulled up and locked in position




Stadium Chair Assembly

For the stadium chair assembly you'll need the 2 X long screws, black seat brackets and allen wrench. In each seat rail you will have two slider receivers in which to you can secure your seat. Move one to the back of the kayak for each rail and screw in the black bracket in each.



Sit the back bar of the seat on top of the brackets, but don't pop them in yet. Screw the front of the seat into the two front slider receivers.



And then push the back bar down into the back seat brackets to secure that.



Lastly connect and secure the two side straps which hold the back of the seat upwards. Secure this in a slightly off of 90 degree upright position, this can be further adjusted once you're on the water. Also remember to take your allen wrench on your first couple of outings in case you want to further adjust your seat location.

Paddle Assembly

The paddle assembly is super simple, just depress the button and pop it into the desired hold (3 locations to choose from) to get the preferred orientation of your blades. Then use the paddle stretch cord to secure it. Remember not to leave it attached like that when the kayak is travelling on your car or truck.



Fishing Rod Holder Assembly


The rod holder assembly requires the: rod holder, the rod holder bracket (3 pieces), 2 x screws and the allen wrench.



Combine the three black round pieces together with the bottom, middle and top as indicated above.

Decide which rail in the cockpit you want to secure it to and move the slider receivers apart the approximate width of the screw holds and insert the screws.

Next insert the fishing rod holder into the now secure base by 'opening' the base as indicated below (**orange arrow**). Next close the slider to lock the fishing rod holder in place (**green arrow**).



You're now ready to hit the water!!

And don't forget to fill out the warranty form on our site.

And a reminder if you have any questions or concerns in respect of your Reel Yaks kayak then please email us at info@reelyaks.com or call us on 855 202 5035.




If you are looking for any accessories to go with your Reel Yaks kayak such as a trolling mount, bimini, etc. then please visit us at REELYAKS.COM

Kayak Accessories

If you are looking for any accessories to go with your Reel Yaks kayak or spare parts then please visit us at REELYAKS.COM

Kayak Trolley Dolly		Pedal Drive Cover	
Kayak Uv waterproof Cover		Kayak Motor Mount Bar	
Kayak Stabilizer Pontoons		Spare Pedal Drive Fins	
6 pack Accessory Rail Slider Mounts		Kayak Anchor Trolley Kit	

RY REEL YAKS

<p>Kayak Uv shade Bimini</p>		<p>Kayak Sail Kite</p>	
<p>Pedal drive & bar mounted tolling motors</p> <p>Wide range 24lbs - 86lbs thrust</p>		<p>360 Fishing Rod Holder</p>	

Also checkout our **Reel Yaks Kayak Fishing shirts with SPF50 Protection**
And many many more....

