


QUICK START GUIDE

ENSURE THE COOKTOP IS CORRECTLY CONNECTED TO THE MAIN POWER SUPPLY

The power supply should be connected in compliance with the relevant standard, or a single-pole circuit breaker. The method of connection is shown below.



1. Red wires (L)
2. Green ground wires (E)
3. Cable from home Power supply
4. White wires
5. Black wires (L)
6. 3-wire cable from cooktop

▲ PLEASE READ THE USER MANUAL BEFORE USING THE APPLIANCE.

CHILD SAFETY LOCK

The Child Lock feature allows you to deactivate the cooktop controls, so wandering hands can't turn on any of the cooking zones.

1. Ensure your cooktop is on and all the cooking zones are off.
2. Press and hold the Lock button until indicator above it is red.
3. To unlock, press and hold the Lock button again.

COOKING BY THE NUMBERS

Cooking with power levels is a bit different than cooking with Hi-Med-Lo settings, but we've got you covered. Here's a quick induction cheat sheet to help you choose the right power levels for some breakfast, lunch and dinner basics.*



* Results may vary.

For additional information on using and maintaining your cooktop, refer to your Use and Care Guide or visit Owner Support on tecasakitchen.com


REGISTER YOUR COOKTOP

Register your appliance at tecasakitchen.com to easily access your warranty and other product information online, receive updates and helpful tips, and take advantage of exclusive deals.

FIND THE RIGHT COOKWARE

For induction Heating, only Induction-ready cookware works!

* Induction-ready refers to cookware having an induction plate on the bottom as shown, or if no induction plate the cookware must be magnet-friendly. If a magnet sticks to the bottom, it will work with the Induction Cooktop.



LEARN TO SPEAK COOKTOP

DISPLAY MESSAGE	MEANING
1-9	Incremental power levels
b	Power Boost
Lo	Cooktop controls locked
H	Hot surface

LOCK YOUR POWER SETTINGS


You can lock in your power level selection while you're cooking so you don't accidentally change the temperature.

1. Turn on a cooking zone and select your desired power level.
2. Press the lock button – the indicator above it is red.
3. If you try to change the power level, "Lo" will appear on the display. To unlock, press and hold the Lock button again.

GET COOKING



1. Place your cookware so it is level and centered over the cooking zone. Select a pot or pan that's larger than the zone's inner ring, but smaller than the outer ring.
2. Press the main Power button to turn the cooktop on.
3. Press the ON/OFF button for the corresponding cooking zone.
4. Increase or decrease settings control until you reach your desired power level.
5. If the cooking zone cannot detect the cookware (only induction cooktops), the power level in the display will flash "U". The cookware may be improperly placed, the incorrect size, or incompatible with induction.



► TIP: Soft humming and clicking sounds are perfectly normal with induction.

CUT DOWN ON CLEANUP

Your cooktop heats pans directly, so the surface stays cooler and you can start cleaning just minutes after you're done cooking, but be sure to wait until the "H" indicator has disappeared. Plus, a cooler cooktop means no burnt-on residue.

► TIP: Before using your cooktop for the first time, apply a ceramic cooktop cleaning cream to the surface to protect from scratches and make it even easier to clean in the future.

SET THE TIMER FOR MINUTE TIMER

Your cooktop has a timer, so you can make sure your food simmers or sears for just the right amount of time.

1. Press the Timer's On/Off button
2. Press +/- button to select a cooking time (works in whole minutes only).
3. A tone will sound when the specified time has lapsed. Press the On-Off button to stop the tone.

► TIP: When the timer stops or is cancelled, any active cooking zones will remain on.