



MASSIMO

T-BOSS 900L



OWNER'S MANUAL

⚠ WARNING



Operating this ATV if you are under the age of 16 increases your chance of severe injury or death.

NEVER operate this ATV if you are under age 16.

Not designed for use on race tracks or retanal services. Use of vehicle in an inintended manner can result in injury, property or personal damages. Such activities are not covered by warranty. Copyrighttt Massimo Motor, LLC

MassimoMotor.com

⚠ WARNING



RISK of ROLLOVER even on flat terrain
ROLLOVERS could result in DEATH or SERIOUS INJURY

AVOID sudden sharp turns

AVOID steep inclines

AVOID riding across slopes

CONTENTS

1. INTRODUCTION	1.1
2. UNDERSTANDING WARNING	2.1
3. SAFETY WARNING	3.1
4. DAILY PRE-RIDE INSPECTION	4.1
5. OPERATION WARNING	5.1
6. V.I.N., ENGINE SERIAL NUMBER AND KEY	6.1
7. CONTROL AND FUNCTIONS	7.1
8. STARTING THE ENGINE	8.1
9. RIDING GEAR	9.1
10. CARRYING LOADS	10.1
11. RIDING	11.1
12. CVT SYSTEM	12.1
13. BATTERY	13.1
14. EXHAUST SYSTEM	14.1
15. MAINTENANCE	15.1
16. TOOLS	16.1
17. SPECIFICATION	17.1
18. ENGINE	18.1
19. WIRING DIAGRAM	19.1
20. EMISSION CONTROL SYSTEM WARRANTY	20.1

1. INTRODUCTION

Introduction

Congratulations on the purchase of your All Terrain Vehicle (ATV). We take pride in offering you this product engineered and manufactured to the highest performance and quality standards. We are sure that you will enjoy superior levels of performance, reliability, riding comfort, and safety.

This manual is provided to help the owner and operators of this ATV become familiar with the operating characteristic, and the many features offered on the ATV. The manual also covers information on the care and maintenance of your ATV.

Please read this manual carefully. The information contained in this Owner's Manual, the Warning Labels supplied with this product will help you to understand the safe use and maintenance of your ATV. Make sure that you understand and follow all Warnings and Instructions in this material.

If you did not receive any of the material listed above, please call your dealer and request to have them sent to you.

Product and specifications are subject to change without notice.

1. INTRODUCTION

Important Safety Notice

● Never make any modifications to the engine, drive system, mechanical or electrical systems of your ATV. Never install aftermarket parts or accessories intended to increase the speed or power of your ATV.

● Failure to follow these warnings increases the possibility of accidents leading to **DEATH** or **SERIOUS INJURY!**

● Additionally, failure to follow these requirements will void the Warranty on your ATV.

NOTE

The addition and use of certain accessories including, (but not limited to) mowers, blades, sprayers, winches and windshields will change the handling characteristics and the performance of your ATV.

Practice Responsible ATV Riding

Make sure that you understand and follow all local, state/province, and federal/national riding laws and requirements.

Remember Respect your vehicle, respect the environment and respect the property of others. You are responsible for your safety and the safety of others around you when you ride!

A ATV CAN BE HAZARDOUS TO OPERATE. A ATV handles differently from other vehicles including motorcycles, ATVs and cars. A collision rollover can occur quickly, even during routine maneuvers such as turning and driving on hills or over obstacles, if you fail to take proper precautions.

1. INTRODUCTION



SERIOUS INJURY OR DEATH

can result if you do not follow these instructions.

- Read this manual and all labels carefully and follow the operating procedures described.
- This vehicle is designed to carry the driver and one passenger. Never carry passengers in the cargo bed.
- Always be sure the driver and passenger are wearing seat belts.
- Never allow anyone who is not an adult to operate this ATV.
- Never permit a guest to operate this ATV unless the guest has read this manual and all product labels.
- The driver and passenger must wear approved off-road motorcycle -type helmets that fits properly. The driver and passenger should also wear eye protections (goggles or face shields), gloves, boots, long-sleeved shirts or jackets, and long pants.
- As with any off-road-capable vehicle, there is a risk of tip over or rollover under certain conditions. Uneven terrain or slopes which pitch the vehicle sideways, turning too fast or sharp, or a combination of conditions increase the risk of tip over.

If you are in a situation where the vehicle is tipping over, do not put your arm or/ and leg outside the vehicle, do not try to stop tipping with your arm or leg. You could be severely injured. You could suffer a crushed hand, arm, leg, or foot, if part of your body is caught underneath the vehicle.

You must keep your arms and legs inside the vehicle until it has stopped moving.

- Never consume alcohol or drugs before or while operating this ATV.
- Never operate at excessive speeds. Always travel at a speed which is proper for the terrain, visibility and operating conditions, and your experience.
- Never attempt wheelies, jumps or other stunts.
- Always inspect your ATV each time you use it to make sure it is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in this manual.
- Always keep both hands, arms, feet, and legs inside the vehicle at all times during operation. Keep your feet on the floorboard. Never hold onto the enclosure except when using the handgrip inside the enclosure. Otherwise, your hand could be injured if it is caught between the enclosure and an obstacle outside the vehicle.
- Always keep both hands on the steering wheel when driving.
- Never wrap your thumbs and fingers around the steering wheel. This is particularly important when driving in rough terrain. The front wheels will move right and left as they respond to the terrain, and this movement will

1. INTRODUCTION

be felt in the steering wheel. A sudden jolt could wrench the steering wheel around, and your thumbs or fingers could be injured if they are in the way of the steering wheel spokes.

- Always go slowly and be extra careful when operating on unfamiliar terrain. Always be alert to changing terrain conditions when operating the ATV.
- Never operate on excessively rough, slippery or loose terrain.
- Always follow proper procedures for turning as described in this manual. Practice turning at low speeds before attempting to turn at faster speeds. Do not turn at excessive speed.
- Always have the ATV checked by an authorized dealer if it has been involved in an accident.
- Never operate ATV on hills too steep for the ATV or for your abilities. Practice on smaller hills before attempting larger hills.
- Always follow proper procedures for climbing hills as described in this manual. Check the terrain carefully before you start up any hill. Never climb hills with excessively slippery or loose surfaces. Never open throttle suddenly or make sudden gear changes. Never go over the top of any hill at high speed.
- Always follow proper procedures for going down hills and for braking on hills as described in this manual. Check the terrain carefully before you start down any hill. Never go down a hill at high speed. Avoid going down a hill at an angle which would cause the vehicle to lean sharply to one side. Go straight down the hill where possible.
- Always follow proper procedures for crossing the side of a hill as described in this manual. Avoid hills with excessively slippery or loose surfaces. Never attempt to turn the ATV around on any hill. Avoid crossing the side of a steep hill if possible.
- Always use proper procedures if you stall or roll backwards when climbing a hill. To avoid stalling, maintain a steady speed when climbing a hill. If you stall or roll backwards, follow the special procedure for braking described in this manual.
- Always check for obstacles before operating in a new area. Never attempt to operate over large obstacles, such as large rocks or fallen trees. Always follow proper procedures when operating over obstacles as described in this manual.
- Always be careful of skidding or sliding. On slippery surfaces, such as ice, go slowly and be very cautious in order to reduce the chance of skidding or sliding out of control.
- Avoid operating the ATV through deep or fast flowing water. Avoid water which exceeds the recommended maximum depth. Go slowly, carefully avoiding sudden movements, maintain a slow and steady forward motion, do not make sudden turns or stops, and do not make sudden throttle changes.

1. INTRODUCTION

- Wet brakes may have reduced stopping ability. Test your brakes after leaving water. If necessary apply them lightly several times to let friction dry out the pads.
- Always be sure there are no obstacles or people behind you when you operate in reverse. When it is safe to proceed in reverse, go slowly. Avoid turning at sharp angles in reverse.
- Always use the size and type tires specified in this manual. Always maintain proper tire pressure as described in this manual.
- Never modify A ATV through improper installation or use of accessories
- Never exceed the stated load capacity. Cargo should be as far forward in the bed as possible, and distributed evenly from side to side. Be sure cargo is secured so that it cannot move around during operation. Reduce speed and follow instructions in this manual for carrying cargo or pulling a trailer. Allow greater distance for braking.

2. UNDERSTANDING WARNINGS

ATTENTION:

This is an ADULT VEHICLE ONLY! Not a toy! READ AND UNDERSTAND WARNINGS AND OWNER'S MANUAL BEFORE OPERATION.



KNOW YOUR VEHICLE BEFORE YOU BEGING RIDING!

Read this manual thoroughly referring to the various areas which are being discussed on your machine. Operating this vehicle carries with it responsibilities for your personal safety, the safety of others, and the protection of our environment.

NOTE: Illustrations used in this manual are for general representation only. Your model may differ.

2. UNDERSTANDING WARNINGS

SAFETY ALERT

WARNINGS identify special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life. Read all **WARNINGS** in this manual care fully. Follow their instructions to remain safe.

The following precautionary signal words are used throughout this manual to convey the following messages:



This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury. Your safety is involved!



WARNING

Indicates a potential hazard which could result in severe injury or death.



CAUTION

Indicates a potential hazard which may result in minor personal injury or damage to the CUV.




CAUTION

Indicates a situation that can result in damage to the machine.

NOTE

The word “NOTE” in this manual will alert you to key information or instructions.

3. SAFETY WARNING



NOTE: Warning decals have been placed on the vehicle for your protection. Read and follow the instructions on each decal carefully. In the event any decal becomes illegible or comes off, contact your dealer for a replacement.

Attention: There is a risk of fire from driving the vehicle on the ground where grass has dried up or parking the vehicle on such surface while the engine is hot.

Attention: When reversing with the differential lock locked and the steering wheel turned to the limit position, it takes a lot of effort to restore the square disc to the neutral position.

3. SAFETY WARNING

1

⚠ WARNING

Improper Use of Off-Highway Vehicles Can Cause Severe Injury or Death

Be Prepared

- Fasten seat belts.
- Wear an approved helmet and protective gear.
- Reserved for message about other occupant restraint devices.
- Each rider must be able to sit with back against seat, feet flat on floor and foot rests, and hands on steering wheel or handhold where equipped. Stay completely inside the vehicle.



Drive Responsibly

Avoid loss of control and rollovers:

- Avoid abrupt maneuvers, sideways sliding, skidding, or fishtailing, and never do donuts.
- Slow down before entering a turn.
- Avoid hard acceleration when turning, even from a stop.
- Plan for hills, rough terrain, ruts, and other changes in traction and terrain. Avoid paved surfaces.
- Avoid side hilling (riding across slopes).



Rollovers have caused severe injuries and death, even on flat, open areas.

Be Sure Riders Pay Attention and Plan Ahead
If you think or feel the vehicle may tip or roll, reduce your risk to injury:

- Keep a firm grip on the steering wheel or handholds and brace yourself.
- Do not put any part of your body outside of the vehicle for any reason.



Require Proper Use of Your Vehicle

Do your part to prevent injuries :


- Do not allow careless or reckless driving.
- Make sure operators are 16 or older with a valid driver's license.
- Do not let people drive or ride after using alcohol or drugs.
- Do not allow operation on public roads (unless designated for off-highway vehicle access)--collision with cars and trucks can occur.
- Do not exceed seating capacity: three passengers.

**LOCATE AND READ THE OWNER'S MANUAL FOLLOW ALL INSTRUCTION AND WARNINGS
RESERVED FOR REFERENCE TO OTHER SOURCE OF SAFETY INFORMATION**

T021111

3. SAFETY WARNING

2




3




4




5



6



7




3. SAFETY WARNING


8




9



10




11




3. SAFETY WARNING

12



13




14



15




16




3. SAFETY WARNING

17



18



19



4. DAILY PRE-RIDE INSPECTION



WARNING

You must inspect your UTV each time before riding to ensure it is in proper working order. If proper inspection is not done, severe injury or death could result.

Use the following checklist to verify your machine is in proper working order each time you ride.

ITEM/ INSPECTION PROCEDURE

1, Tire— check condition and pressures.

2, Fuel tank— checking for leaking, fill the fuel tank to its proper level.

3, All brakes— check fluid level, check operation, adjustment (includes parking brake).

● Brake pedal

Check for correct brake pedal free play. If the brake pedal free play is incorrect, have an authorized dealer adjust it. Check the operation of the brake pedal. It should move smoothly and there should be a firm feeling when the brakes are applied. If not, have the vehicle inspected by your dealer.

● Brake fluid leakage

Check to see if any brake fluid is leaking out of the pipe joints or the brake fluid reservoir. Apply the brakes firmly for one minute. If there is any leakage, have the vehicle inspected by an authorized dealer.

Brake fluid level

● Check the brake fluid level.

Add fluid if necessary.

● Brake operation

Test the brakes at slow speed after starting out to make sure they are working properly. If the brakes do not provide proper braking performance, inspect the brake system.

4, Throttle/ Accelerator pedal— check for free operation, closing and freeplay.

Check to see that the accelerator pedal operates correctly. It must operate smoothly and fully spring back to the idle position when released.

Have an authorized dealer repair as necessary for proper operation.

5, Headlight / Taillight / Brake light— check operation of all indicator lights and switches.

4. DAILY PRE-RIDE INSPECTION

6, Wheels— check for tightness of wheel nuts and axle nuts; check those axle nuts are secured by cotter pins.

Check balance/ damage/ runout. Have an authorized dealer repair/ replace if necessary.

Check bearing assemblies for looseness/damage. Have an authorized dealer replace if damaged.

7, Air cleaner element— check for dirt; clean or replace.

8, Steering— check for free operation noting any unusual looseness in any area.

Park on level ground. Turn the steering wheel right and left. Check for excessive free play, abnormal noises, or a rough feeling. Have an authorized dealer repair as necessary for proper operation.

9, Loose parts— visually inspect vehicle for any damaged components or loose nuts/bolts or fasteners.

Always check the tightness of chassis fittings and fasteners before a ride. Take the vehicle to your dealer for correct tightening torque.

10, Operator's and passenger's helmets, goggles and clothing.

11, Engine coolant— check for proper level at the recovery bottle.

12, Seat belts— Check for proper operation and belt wear.

Make sure that both seat belts are not frayed or damaged. The seat belt must move smoothly when pulled out and retract on its own when released. The latch plate should click securely into the buckle and release when the release button is pushed firmly. Clean off any dirt or mud which could affect operation. Have an authorized dealer repair as necessary for proper operation.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Improper handling of gasoline.

WHAT CAN HAPPEN

Gasoline can catch fire and you could be burned.

HOW TO AVOID THE HAZARD

Always turn off the engine when refueling. Do not refuel right after the engine has been running and is still very hot. Do not spill gasoline on the engine or exhaust pipe/muffler when refueling. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.



WARNING

POTENTIAL HAZARD

Checking the fuel system while smoking or near an open flame.

WHAT CAN HAPPEN

Fuel can ignite or explode, causing severe injury or property damage.

HOW TO AVOID THE HAZARD

Do not smoke when checking the fuel system. Make sure there are no open flames or sparks in the area, including pilot lights from water heaters or furnaces.



WARNING

POTENTIAL HAZARD

When transporting the vehicle in another vehicle, be sure it is kept in an upright position. Otherwise, fuel may leak out of the carburetor or fuel tank.

WHAT CAN HAPPEN

Gasoline is poisonous and can cause injuries.

HOW TO AVOID THE HAZARD

If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Changing from 2WD to 4WD or vice-versa while the vehicle is moving.

WHAT CAN HAPPEN

The vehicle handles differently in 2WD than in 4WD, or vice-versa while moving may cause the vehicle to unexpectedly handle differently. This could distract the operator and increase the risk of losing control and an accident.

HOW TO AVOID THE HAZARD

Always stop the vehicle before changing from 2WD to 4WD, or vice-versa.



WARNING

POTENTIAL HAZARD

Malfunction of the accelerator pedal.

WHAT CAN HAPPEN

The accelerator pedal could be hard to operate, making it difficult to speed up or slow down when you need to. This could cause an accident.

HOW TO AVOID THE HAZARD

Check the operation of the accelerator pedal before you start the engine. If it does not work smoothly, check for the cause. Correct the problem before operating the vehicle. Consult an authorized dealer if you can't find or solve the problem yourself.



WARNING

POTENTIAL HAZARD

A loose seat.

WHAT CAN HAPPEN

The operator could lose control or the operator or passenger could fall if the seat is loose during operation.

HOW TO AVOID THE HAZARD

Make sure the seat is securely latched.



WARNING

POTENTIAL HAZARD

Not wearing the seat belt.

Wearing the seat belt improperly.

WHAT CAN HAPPEN

There is increased risk of being killed or seriously injured in an accident.

HOW TO AVOID THE HAZARD

5. OPERATION WARNINGS

Always wear your seat belt when riding in the vehicle.

Be sure the seat belt is close-fitting across your hips and chest and is latched securely.



WARNING

POTENTIAL HAZARD

Try to stop the tipping vehicle with your arm or leg.

WHAT CAN HAPPEN

You could be severely injured. You could suffer a crushed hand, arm, leg, or foot,

HOW TO AVOID THE HAZARD

You must keep your arms and legs inside the vehicle until it has stopped moving.

As with any off-road-capable vehicle, there is a risk of tip over or rollover under certain conditions. Uneven terrain or slopes which pitch the vehicle sideways, turning too fast or sharp, or a combination of conditions increase the risk of tip over.

If you are in a situation where the vehicle is tipping over, do not put your arm or/ and leg outside the vehicle, do not try to stop tipping with your arm or leg. You could be severely injured. You could suffer a crushed hand, arm, leg, or foot, if part of your body is caught underneath the vehicle.



WARNING

POTENTIAL HAZARD

Pinch points.

WHAT CAN HAPPEN

You or someone else could be pinched between the cargo bed and the frame when the bed is being lowered.

HOW TO AVOID THE HAZARD

Before closing the bed, be sure others are standing away from the vehicle. Keep hands and fingers away from the pinch points between the bed and the frame.



WARNING

POTENTIAL HAZARD

Overloading the cargo bed

WHAT CAN HAPPEN

Could cause changes in vehicle handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated maximum load limit for this cargo bed.

5. OPERATION WARNINGS

Cargo should be properly distributed and securely attached.
Reduce speed when carrying cargo. Allow greater distance for braking.



WARNING

POTENTIAL HAZARD

Carrying a passenger/ passengers in the cargo bed

WHAT CAN HAPPEN

The passenger(s) could fall, be thrown out, or be struck by objects in the cargo bed.

HOW TO AVOID THE HAZARD

Never carry a passenger/ passengers in the cargo bed. This cargo bed is designed to carry cargo only.



WARNING

POTENTIAL HAZARD

Improper shock absorber adjustment.

WHAT CAN HAPPEN

Uneven adjustment can cause poor handling and loss of stability, which could lead to an accident.

HOW TO AVOID THE HAZARD

Always adjust the shock absorbers on the left and right side to the same setting.



WARNING

POTENTIAL HAZARD

Driving with improperly operating brakes.

WHAT CAN HAPPEN

You could lose braking ability, which could lead to an accident.

HOW TO AVOID THE HAZARD

Always check the brakes at the start of every ride. Do not operate the vehicle if you find any problem with the brakes. If a problem cannot be corrected by the adjustment procedures provided in this manual, have the vehicle inspected by an authorized dealer.



WARNING

POTENTIAL HAZARD

Improper care when refueling.

WHAT CAN HAPPEN

Fuel can spill, which can cause a fire and severe injury. Fuel expands when it

5. OPERATION WARNINGS

heats up. If the fuel tank is overfilled, fuel could spill out due to heat from the engine or the sun.

HOW TO AVOID THE HAZARD

Do not overfill the fuel tank. Be careful not to spill fuel, especially on the engine or exhaust pipe. Wipe up any spilled fuel immediately. Be sure the fuel tank cap is closed securely.



WARNING

POTENTIAL HAZARD

Removing the radiator cap when the engine and radiator are still hot.

WHAT CAN HAPPEN

You could be burned by hot fluid and steam blown out under pressure.

HOW TO AVOID THE HAZARD

Wait for the engine to cool before removing the radiator cap. Always use a thick rag over the cap. Allow any remaining pressure to escape before completely removing the cap.



WARNING

POTENTIAL HAZARD

Operating vehicle without being familiar with all controls.

WHAT CAN HAPPEN

Loss of control, which could cause an accident or injury.

HOW TO AVOID THE HAZARD

Read the Owner's Manual carefully. If there is a control or function you do not understand, ask our authorized dealer.



WARNING

POTENTIAL HAZARD

Freezing control cables in cold weather.

WHAT CAN HAPPEN

You could be unable to control the vehicle, which could lead to an accident or collision.

HOW TO AVOID THE HAZARD

When riding in cold weather, always make sure all control cables work smoothly before you begin riding.



WARNING

POTENTIAL HAZARD

Overloading this vehicle or carrying or towing cargo improperly.

5. OPERATION WARNINGS

WHAT CAN HAPPEN

Could cause changes in vehicle handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated load capacity for this vehicle.

Cargo should be properly distributed and securely attached.

Reduce speed when carrying cargo or pulling a trailer. Allow greater distance for braking.



WARNING

POTENTIAL HAZARD

Servicing an engine while it is running.

WHAT CAN HAPPEN

Moving parts can catch clothing or parts of the body, causing injury.

Electrical components can cause shocks or can start fires.

HOW TO AVOID THE HAZARD

Turn off the engine when performing maintenance unless otherwise specified.

Have an authorized dealer perform service if you are not familiar with vehicle service.



WARNING

POTENTIAL HAZARD

Operating this vehicle with improper modifications.

WHAT CAN HAPPEN

Improper installation of accessories or modification of this vehicle may cause changes in handling which in some situations could lead to an accident.

HOW TO AVOID THE HAZARD

Never modify this vehicle through improper installation or use of accessories.

All parts and accessories added to this vehicle should be genuine parts or equivalent components designed for use on this vehicle and should be installed and used according to instructions. If you have questions, consult an authorized dealer.



WARNING

POTENTIAL HAZARD

Using low flash point solvents or gasoline to clean the sponge material.

WHAT CAN HAPPEN

Low flash point solvents or gasoline can catch fire or explode.

5. OPERATION WARNINGS

HOW TO AVOID THE HAZARD

Use parts cleaning solvent to clean the sponge material.



WARNING

POTENTIAL HAZARD

Improper cleaning of the spark arrester. Hot exhaust system

WHAT CAN HAPPEN

Could injure the eyes. Could cause burns.

Could cause carbon monoxide poisoning, possibly leading to death.

Could start a fire.

HOW TO AVOID THE HAZARD

When cleaning the spark arrester: Always let the exhaust system cool prior to touching exhaust components.

Do not start the engine when cleaning the exhaust system.



WARNING

POTENTIAL HAZARD

Operating with improperly serviced or adjusted brakes.

WHAT CAN HAPPEN

You could lose braking ability, which could lead to an accident.

HOW TO AVOID THE HAZARD

After servicing:

- Make sure the brakes operate smoothly and that the brake pedal position is correct.
- Make sure the brakes do not drag.
- All air must be bled from the brake system.

Replacement of brake components requires professional knowledge. These procedures should be performed by an authorized dealer.



WARNING

POTENTIAL HAZARD

Damaged control cables.

WHAT CAN HAPPEN

Corrosion can result when the outer covering of control cables becomes damaged. Cables can also become frayed or kinked. Operation of controls could be restricted, which could cause an accident or injury.

HOW TO AVOID THE HAZARD

Inspect cables frequently. Replace damaged cables.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Failure to handle batteries or battery electrolyte carefully.

WHAT CAN HAPPEN

You could be poisoned. You could be severely burned by the sulfuric acid in battery electrolyte. Batteries produce explosive gases.

HOW TO AVOID THE HAZARD

Avoid contact with skin, eyes or clothing. Always shield eyes when working near batteries. Keep out of reach of children.

Antidote:

EXTERNAL: Flush with water.

INTERNAL: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Get prompt medical attention.

EYES: Flush with water for 15 minutes and get prompt medical attention. Keep batteries away from sparks, flames, cigarettes or other sources of ignition. Ventilate when charging or using in a closed space.



WARNING

POTENTIAL HAZARD

Using an improper fuse

WHAT CAN HAPPEN

An improper fuse can cause damage to the electrical system, which could lead to a fire.

HOW TO AVOID THE HAZARD

Always use a fuse of the specified rating. Never use a material in place of the proper fuse.



WARNING

POTENTIAL HAZARD

A headlight bulb is hot when it is on and immediately after it is turned off.

WHAT CAN HAPPEN

You can be burned, or a fire could start if the bulb touches something flammable.

HOW TO AVOID THE HAZARD

Wait for the bulb to cool before touching or removing it.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Operation with wet brakes after washing.

WHAT CAN HAPPEN

Wet brakes may have reduced stopping ability, increasing the chance of an accident.

HOW TO AVOID THE HAZARD

Test the brakes after washing. Apply the brakes several times at slow speeds to let friction dry out the linings.



WARNING

POTENTIAL HAZARD

Operating/ riding this ATV without wearing an approved helmet, eye protection and protective clothing.

WHAT CAN HAPPEN

Operating/ riding without an approved helmet increases your chances of a severe head injury or death in the event of an accident.

Operating/ riding without eye protection can result in an accident and increases your chances of a severe injury in the event of an accident.

HOW TO AVOID THE HAZARD

Always wear an approved helmet which fits properly.

You should also wear: eye protection (goggles or face shield); gloves; boots; long-sleeved shirt or jacket; and long pants.



WARNING

POTENTIAL HAZARD

Operating this ATV after consuming alcohol or drugs.

WHAT CAN HAPPEN

Could seriously affect your judgment.

Could cause you to react more slowly.

Could affect your balance and perception.

Could result in an accident.

HOW TO AVOID THE HAZARD

Never consume alcohol or drugs before or while driving this ATV.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Operating this ATV at excessive speeds.

WHAT CAN HAPPEN

Increases your chances of losing control of the ATV, which can result in an accident.

HOW TO AVOID THE HAZARD

Always travel at a speed which is proper for the terrain, visibility and operating conditions; and your experience.



WARNING

POTENTIAL HAZARD

Attempting wheelies, jumps and other stunts.

WHAT CAN HAPPEN

Increases the chance of an accident, including an overturn.

HOW TO AVOID THE HAZARD

Never attempt stunts, such as wheelies or jumps.



WARNING

POTENTIAL HAZARD

Failure to inspect the ATV before operating.

Failure to properly maintain the ATV.

WHAT CAN HAPPEN

Increases the possibility of an accident or equipment damage.

HOW TO AVOID THE HAZARD

Always inspect your ATV each time you use it to make sure the ATV is in safe operating condition.

Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.



WARNING

POTENTIAL HAZARD

Removing hands from steering wheel or feet from footrests during operation.

WHAT CAN HAPPEN

Removing even one hand or foot can reduce your ability to control the ATV or could cause you to lose your balance and fall off the ATV.

5. OPERATION WARNINGS

HOW TO AVOID THE HAZARD

Always keep both hands on the steering wheel and both feet on the footrests of your ATV during operation.



WARNING

POTENTIAL HAZARD

Failure to use extra care when operating this ATV on unfamiliar terrain.

WHAT CAN HAPPEN

You can come upon hidden rocks, bumps, or holes, without enough time to react.

Could result in the ATV overturning or going out of control.

HOW TO AVOID THE HAZARD

Go slowly and be extra careful when operating on unfamiliar terrain.

Always be alert to changing terrain conditions when operating the ATV.



WARNING

POTENTIAL HAZARD

Failure to use extra care when operating on excessively rough, slippery or loose terrain.

WHAT CAN HAPPEN

Could cause loss of traction or vehicle control, which could result in an accident, including an overturn.

HOW TO AVOID THE HAZARD

Do not operate on excessively rough, slippery or loose terrain until you have learned and practiced the skills necessary to control the ATV on such terrain.

Always be especially cautious on these kinds of terrain.



WARNING

POTENTIAL HAZARD

Climbing hills improperly.

WHAT CAN HAPPEN

Could cause loss of control or cause ATV to overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for climbing hills as described in the Owner's Manual.

Always check the terrain carefully before you start up any hill.

Never climb hills with excessively slippery or loose surfaces.

Never open the throttle suddenly. The ATV could flip over backwards.

Never go over the top of any hill at high speed. An obstacle, a sharp drop, or another vehicle or person could be on the other side of the hill.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Turning improperly.

WHAT CAN HAPPEN

ATV could go out of control, causing a collision or overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for turning as described in the Owner's Manual.

Practice turning at low speeds before attempting to turn at faster speeds.

Do not turn at excessive speed.



WARNING

POTENTIAL HAZARD

Operating on excessively steep hills.

WHAT CAN HAPPEN

The vehicle can overturn more easily on extremely steep hills than on level surfaces or small hills.

HOW TO AVOID THE HAZARD

Never operate the ATV on hills too steep for the ATV or for your abilities.

Practice on smaller hills before attempting large hills.

Never operate an ATV on a hill with a steepness greater than 15%.



WARNING

POTENTIAL HAZARD

Going down a hill improperly.

WHAT CAN HAPPEN

Could cause loss of control or cause ATV to overturn.

HOW TO AVOID THE HAZARD

Always follow proper procedures for going down hills as described in the Owner's Manual. NOTE: A special technique is required when braking as you go downhill.

Always check the terrain carefully before you start down any hill.

Never go down a hill at high speed.

Avoid going down a hill at an angle which would cause the vehicle to lean sharply to one side. Go straight down the hill where possible.



WARNING

POTENTIAL HAZARD

Improperly crossing hills or turning on hills.

WHAT CAN HAPPEN

5. OPERATION WARNINGS

Could cause loss of control or cause ATV to overturn.

HOW TO AVOID THE HAZARD

Never attempt to turn the ATV around on any hill until you have mastered the turning technique as described in the Owner's Manual on level ground. Be very careful then turning on any hill.

Avoid crossing the side of a steep hill if possible.

When crossing the side of a hill:

Always follow proper procedures as described in the Owner's Manual.

Avoid hills with excessively slippery or loose surfaces.



WARNING

POTENTIAL HAZARD

Stalling, rolling backwards or improperly dismounting while climbing a hill.

WHAT CAN HAPPEN

Could result in ATV overturning.

HOW TO AVOID THE HAZARD

Maintain steady speed when climbing a hill.

If you lose all forward speed:

Keep weight uphill.

Apply the brakes.

Lock parking brake after you are stopped.

If you begin rolling backwards:

Keep weight uphill; never apply engine power.

Apply the brake gradually.

When fully stopped, apply rear brake as well, and then lock parking brake.

Dismount on uphill side, or to either side if pointed straight uphill.



WARNING

POTENTIAL HAZARD

Improperly operating over obstacles.

WHAT CAN HAPPEN

Could cause loss of control or a collision. Could cause the ATV to overturn.

HOW TO AVOID THE HAZARD

Before operating in a new area, check for obstacles.

Use extreme caution when riding over large obstacles, such as large rocks or fallen trees.

If you cannot avoid obstacles, always follow proper procedures as described in the Owner's Manual.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Skidding or sliding,

WHAT CAN HAPPEN

You may lose control of the ATV.

You may also regain traction unexpectedly, which may cause the ATV to overturn.

HOW TO AVOID THE HAZARD

On slippery surfaces, such as ice, go slowly and be very cautious in order to reduce the chance of skidding or sliding out of control.



WARNING

POTENTIAL HAZARD

Operating this ATV through deep or fast flowing water.

WHAT CAN HAPPEN

Tires may float, causing loss of traction and loss of control, which could lead to an accident.

HOW TO AVOID THE HAZARD

Never operating the ATV through water which exceeds the recommended maximum depth in this manual.

Avoid operating the ATV through deep or fast flowing water. If you cannot avoid water, go slowly, balance your weight carefully avoiding sudden movement, maintain a slow and steady forward motion, do not make sudden turns or stops, and do not make sudden throttle changes.

Remember that wet brakes may have reduced stopping ability.

Test your brakes after leaving water. If necessary, apply them several times to let friction dry out the pads.



WARNING

POTENTIAL HAZARD

Improperly operating in reverse,

WHAT CAN HAPPEN

You could hit an obstacle or person behind you, resulting in severe injury.

HOW TO AVOID THE HAZARD

When you select reverse gear, make sure there are no obstacles or people behind you. When it is safe to proceed, go slowly.

5. OPERATION WARNINGS



WARNING

POTENTIAL HAZARD

Operating this ATV with improper tires, or with improper or uneven tire pressure.

WHAT CAN HAPPEN

Use of improper tires on this ATV, or operation of this ATV with improper or uneven tier pressure, may cause loss of control, and increases the risk of an accident.

HOW TO AVOID THE HAZARD

Always use the size and type ties specified in the Owner's Manual for this vehicle.

Always maintain proper tire pressure a described in the Owner's Manual.

Use proper pressures stated on the side wall of the tire when seating the tire beads. Higher pressures may cause the tire to burst. Inflate the tires very slowly and carefully. Fast inflation could cause the tire to burst.



WARNING

POTENTIAL HAZARD

Operating this ATV with improper modifications.

WHAT CAN HAPPEN

Improper installation of accessories or modification of this vehicle may cause changes in handling which in some situations could lead to an accident.

HOW TO AVOID THE HAZARD

Never modify this ATV through improper installation or use of accessories. All parts and accessories added to this vehicle should be genuine or equivalent components designed for use on this ATV; and should be installed and used according to instructions. If you have questions, consult our authorized dealer.



WARNING

POTENTIAL HAZARD

Riding on frozen lakes and rivers.

WHAT CAN HAPPEN

Severe injury or death can result if the ATV and /or the operator break through the ice.

HOW TO AVOID THE HAZARD

Never ride you ATV on a frozen body of water.

5. OPERATION WARNINGS



WARNING

After a rollover or an accident, have a qualified service dealer check the complete machine including, but not limited to, brakes, throttle and steering for possible damage.



WARNING

Safe operation of this rider active vehicle requires good judgment and physical skills. Persons with cognitive or physical disabilities who operate this vehicle have an increased risk of overturns and loss of control which could result in severe injury or death.



CAUTION

Keep combustible materials away from exhaust system. Fire may result.

6. V.I.N. SERIAL NUMBER



Record these numbers from your ATV in the spaces provided.

1. Frame 14-bit Serial Number

--	--	--	--	--	--	--	--	--	--	--	--	--	--

2. Identification Plate

Your machine has an identification plate mounted as shown.

The Product Identification Number (PIN), weight, year of manufacture and serial number of the machine are shown on the plate.

Remove the spare key and store in a safe place. Your key can be duplicated only by obtaining a key blank and having it cut by mating it with your existing key.

Record Key Number

The vehicle frame is important for model identification when registering your vehicle, obtaining insurance or whenever replacement parts are required. In the event your vehicle were stolen these numbers are essential to the recovery and identification of your ATV.

7. CONTROL AND FUNCTIONS

Electrical Switches



- 1 2 3 4 5
1. Turn on the right turning lights. Symbol: “”
Turn on the left turning lights. Symbol: “”
2. Horn on. Symbol: “”
3. Main Switch. This key switch must be turned clockwise to the “on” position to start the engine.
4. Switch of Headlight
5. Switch distance light

7. CONTROL AND FUNCTIONS



CAUTION

Always shift as the vehicle stop.

NOTE: When shift 2WD/ 4WD, the mechanics in the front gear box maybe still engaged/ disengaged, the mechanics would finally disengaged/ engaged when rides on a hard surface or rides in reverse. The buzzer will beep if the procedure which list above is not done in 1 minute. Re-shift to stop the buzzer.



CAUTION

Do not switch on 4WD if the rear wheels are spining. This may cause severe machine damage. When switch on 4WD, the button will stay in 4WD position but 4WD mechanics maybe still disengaged. Always apply throttle gently and let the wheels move slightly to allow the 4WD mechanics finally engage. The 4WD indicator on the speedometer will come on when 4WD engaged.

Light Switches and Indicator Lights



WARNING


Use caution and drive at reduced speeds in conditions of reduced visibility such as fog, rain and darkness.

Switches

It will not light up unless the main switch is turned on.

7. CONTROL AND FUNCTIONS

LCD Meter



1. Coolant temperature meter

2. Speedometer

3. Motor speed

4. Hour/Odometer

5. Left turn indicator light

6. EFI

7. Right turn indicator light

8. Fuel level

9. Brake indicator light

10. Function keys1

11. High beam indicator light

12. Seat belt indicator not on


13. Brake fluid indicator light

14. Function keys2

15. 2WD/4WD indicator

7. CONTROL AND FUNCTIONS

Ten inch big screen meter



1. EFI

8. Fuel level

2. Oil alarm

9. Charge lamp

3. Dipped headlight

10. Coolant temperature meter

4. High beam indicator light

11. Motor speed

5. Left turn indicator light


12. Speedometer

6. Right turn indicator light

7. 2WD/4WD indicator

7. CONTROL AND PARTS FUNCTIONS

Wheel Drive /Diff Lock System



CAUTION

Always shift as the vehicle stop.

NOTE:

When shift 2WD/ 4WD or Diff Lock, the mechanics in the front gear box maybe still engaged/ disengaged, the mechanics would finally disengaged/ engaged when rides on a hard surface or rides in reverse.



CAUTION


Do not switch on 4WD if the rear wheels are spinning. This may cause severe machine damage. When switch on 4WD or Diff Lock, the button will stay in 4WD or Diff Lock position, but 4WD or Diff Lock mechanics maybe still disengaged. Always apply throttle gently and let the wheels move slightly to allow the 4WD or Diff Lock mechanics finally engage. The 4WD or Diff Lock indicator on the speedometer will come on when engaged.

7. CONTROL AND PARTS FUNCTIONS

KEY SWITCH

1.Insert the key to the key switch and turn it “ON”

- | | |
|-------------|-----------|
| 1 “PREHEAT” | 2 “OFF” |
| 3 “ON” | 4 “START” |



IMPORTANT:

Daily checks with the Easy Checker(TM) only are not sufficient. Never fail to conduct physical daily checks carefully by referring to Daily Check section.

(See “DAILY CHECK” in “PERIODOC SERVICE” section)

Push the vehicle gear in neutral position. Turn the key to “PREHEAT” position and hold it for about 2 to 3 seconds.

Temperature	Preheating Time
Over 0 °C	2 to 3 sec.
0 to -5 °C	5sec.
-5 to -15 °C	10sec.

NOTE:

Glow plug indicator comes on while engine is being preheated.

2.Turn the key to “START” position and release when the engine starts.


Cold Weather Starting

When the ambient temperature is below -5°C and the engine is very cold. If the engine fails to start, turn off the key for 30 seconds. Then repeat steps 2 and 3. To protect the battery and the starter, make sure that the starter is not continuously turned for more than 30 seconds.

7. CONTROL AND PARTS FUNCTIONS

ACCESSORY SOCKET

You can use the accessory socket to power a trouble light, spotlight, CB radio, or cell phone etc.



CAUTION

Do not plug in any heat-generating accessory such as an automobile cigarette lighter because it damages the socket.

To use the accessory socket, start the engine. Then turn the headlights OFF, and open the accessory socket cap (2).

Be sure the engine is on and the headlights are turned off before using the accessory socket, otherwise you may drain the battery.

The accessory socket is rated capacity is DC 12V. 120 Watts (10A) or less. If you exceed this limit, you may blow a fuse.

When you are done using an accessory, unplug it, and cover the socket with the cap.

Be careful not to flood this accessory socket when washing your UTV.

ENTERING AND LEAVING THE CAB INTRODUCTION



WARNING

ENTERING/LEAVING

Entering or leaving the cab or canopy must only be made where steps and handrails are provided. Always face the machine when entering and leaving. Make sure the step(s), handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls as handholds, use the handrails.



WARNING

Do not stand on the wheels. You could be trapped between the wheels if the vehicle moves.

The machine can be mounted and dismounted from either side. Use the handle on the ROPS for assistance, if necessary.

7. CONTROL AND PARTS FUNCTIONS


ACCELERATOR PEDAL



WARNING

Before starting the engine, check the accelerator pedal to be sure it is operating smoothly.

Make sure the accelerator pedal fully returns to the idle position as soon as it is released.



1. Accelerator pedal

Press the accelerator pedal down to increase engine speed. Spring pressure returns the pedal to the rest position when released. Always check that the accelerator pedal returns normally before starting the engine.



WARNING

POTENTIAL HAZARD

Malfunction of the accelerator pedal.

WHAT CAN HAPPEN


The accelerator pedal could be hard to operate, making it difficult to speed up or slow down when you need to. This could cause an accident.

HOW TO AVOID THE HAZARD

Check the operation of the accelerator pedal before you start the engine. If it does not work smoothly, check for the cause. Correct the problem before operating the vehicle. Consult the authorized dealer if you can't find or solve the problem yourself.

7. CONTROL AND PARTS FUNCTIONS

BRAKE PEDAL



1.Brake pedal

Press the brake pedal to slow or stop the vehicle.




WARNING

Never operate the UTV with a spongy feeling brake pedal. Operating the UTV with a spongy brake pedal can result in loss of braking. Loss of braking could cause an accident.

PARKING BRAKE LEVER

The parking brake lever is located at the left side of the driver's seat. It will help hold the vehicle from moving while parked. To set the parking brake, pull the lever up completely. The parking indicator light will come on if the main switch is on. To release the parking brake, pull up on the lever, press the release button, and then push the lever all the way down. Be sure to fully release the parking brake before starting out. Failure to do so may result in poor performance and premature wearing of the parking brake and V-belt.

1. Release button
2. Parking brake lever




7. CONTROL AND PARTS FUNCTIONS

AUTOMATIC OPERATION

TRANSMISSION

GEAR

SELECTOR



The transmission gear selector is located at the **left** side of the steering wheel. The transmission selector lever has **five** positions: high forward; reverse; neutral; **parking**; and low forward

NOTE: To extend belt life, use low forward gear in heavy pulling situations and in situations where you are operating below 7mph(11km/h) for extended periods of time.



CAUTION

To change gears, stop the vehicle and with the engine idling, move the lever to the desired gear. Shifting gears with the engine speed above idle or while the vehicle is moving could cause transmission damage.

Always place the transmission in gear with the parking brake locked whenever the vehicle is left unattended.

Maintaining shift linkage adjustment is important to assure proper transmission function. Should you experience any shifting problem see your dealer.

7. CONTROL AND PARTS FUNCTIONS



WARNING

POTENTIAL HAZARD

Engaging a lower gear when the engine speed is too high.


WHAT CAN HAPPEN

The wheels could stop rotating. This could cause loss of control, an accident and injury. It could also cause engine or drive train damage.

HOW TO AVOID THE HAZARD

Make certain the engine has sufficiently slowed before shifting to a lower gear.


FUEL TANK CAP



1.Fuel tank cap

Remove the fuel tank cap by turning it counterclockwise.

SEATS



1.Drive seat

2.Passenger seat

7. CONTROL AND PARTS FUNCTIONS



WARNING

POTENTIAL HAZARD

A loose seat.


WHAT CAN HAPPEN

The operator could lose control or the operator or passenger could fall if the seat is loose during operation.

HOW TO AVOID THE HAZARD


Make sure the seat is securely latched.

SEAT BELTS



1. Seat belt (× 2)


2. Buckle (× 2)



This vehicle is equipped with three-point seat belts for both the operator and passenger. Always wear the seat belt while riding in the vehicle.

1. Buckle

2. Latch plate



1. Buckle

2. Release button

To Wear The Seat Belt Properly, do the following:

1. Hold the latch plate as you pull the belt across your lap and chest. Make sure the belt is not twisted and is not caught on any portion of the vehicle, your clothing, or any equipment you are carrying.
2. Push the latch plate into the buckle until it clicks. Pull up on the latch plate to make sure it is secure.
3. Put the lap portion of the belt low on your hips. Push down on the buckle

7. CONTROL AND PARTS FUNCTIONS

end of the belt as you pull up on the shoulder part so the belt is snug across your hips.

4. Position the shoulder belt over your shoulder and across your chest. The shoulder belt should fit against your chest. If it is loose, pull the belt out all the way and then let it retract.

To Release The Buckle, firmly press the release button.



WARNING

POTENTIAL HAZARD

Not wearing the seat belt.

Wearing the seat belt improperly.

WHAT CAN HAPPEN


There is increased risk of being killed or seriously injured in an accident.

HOW TO AVOID THE HAZARD

Always wear your seat belt when riding in the vehicle.

Be sure the seat belt is close-fitting across your hips and chest and is latched securely.

GLOVE COMPARTMENT



a. Open




CAUTION

To protect from damage, do not put metal products, like tools or sharply edged products directly in the glove compartment. If they must be stored, wrap them in appropriate cushion material.


7. CONTROL AND PARTS FUNCTIONS

CARGO BED



- 1.Cargo bed
- 2.Tailgate
- 3.Cargo hook (×2)

Opening And Closing The Tailgate



- 1.Tailgate
- 2.Latch (×2)


To open

Unhook the latches, and then lower the tailgate.

To close

Place the tailgate in the original position, and then hook the latches.

Lifting And Lowering The Cargo Bed



- 1. Cargo hook

7. CONTROL AND PARTS FUNCTIONS

To lift

Release the cargo hook on the left or right side of the vehicle, and then slowly lift up the cargo bed until it stops.

To lower

Lower the cargo bed slowly to its original position then lock the cargo hook.

Our photos and information may not match the vehicle you have ordered. The vehicle in kind prevail.



WARNING

POTENTIAL HAZARD

Pinch points.

WHAT CAN HAPPEN

You or someone else could be pinched between the cargo bed and the frame when the bed is being lowered.

HOW TO AVOID THE HAZARD

Before closing the bed, be sure others are standing away from the vehicle. Keep hands and fingers away from the pinch points between the bed and the frame.

When you leave the vehicle, make sure the cargo is lowered.

Load Limit

Maximum load limit: 300kg (661lbs)



WARNING

POTENTIAL HAZARD

Overloading the cargo bed

WHAT CAN HAPPEN

Could cause changes in vehicle handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated maximum load limit for this cargo bed. Cargo should be properly distributed and securely attached. Reduce speed when carrying cargo. Allow greater distance for braking.

7. CONTROL AND PARTS FUNCTIONS



WARNING

POTENTIAL HAZARD

Carrying a passenger/ passengers in the cargo bed


WHAT CAN HAPPEN

The passenger(s) could fall, be thrown out, or be struck by objects in the cargo bed.

HOW TO AVOID THE HAZARD

Never carry a passenger/ passengers in the cargo bed. This cargo bed is designed to carry cargo only.

HOOD



To Open

Follow the steps as shown in the image to open the hood.

To Close

Lower the hood slowly to its original position, and then hook the hood latches, and be sure that they are locked into place..



WARNING

If the hood latches are hooked improperly, or the latches and their attachments can not work properly, the front hood can come off during operation, striking the driver or passenger and causing serious personal injury.

7. CONTROL AND PARTS FUNCTIONS

ENGINE COOLING SYSTEM

Coolant Level


The recovery bottle, located the right of the frame, must be maintained between the minimum and levels indicated on the recovery bottle.

The engine coolant level is controlled or maintained by the recovery system. The recovery system components are the recovery bottle, radiator filler neck, radiator pressure cap and connecting hose.

As coolant operating temperature increases, the expanding (heated) excess coolant is forced out of the radiator past the pressure cap and into the recovery bottle. As engine coolant temperature decreases, the contracting (cooled) coolant is drawn back up from the tank past the pressure cap and into the radiator.

NOTE: Some coolant level drop on new machines is normal as the system is purging itself of trapped air. Observe coolant levels and maintain as recommended by adding coolant to the recovery bottle. We recommend the use of a 50/50 mixture of high quality aluminum compatible anti-freeze coolant and distilled water.

NOTE: Always follow the manufacturer's mixing recommendations for the freeze protection required in your area.




WARNING

Never remove the pressure cap when the engine is warm or hot. Escaping steam can cause severe burns. The engine must be cool before removing the pressure cap.

Radiator Coolant Level Inspection

NOTE: This procedure is only required if the cooling system has been drained for maintenance and/or repair. However, if the recovery bottle has run dry, the level in the radiator should be inspected and coolant added if necessary.

NOTE: Use of a non-standard pressure cap will not allow the recovery system to function properly. If the cap should need replacement contact your dealer for the correct replacement part. To insure that the coolant maintains its ability to protect the engine, it is recommended that the system be completely drain every two years and a



7. CONTROL AND PARTS FUNCTIONS

fresh mixture of antifreeze and water be added.

Using a funnel, slowly add coolant as necessary through the radiator filler neck.

Tow Hitch Options

Introduction

Your machine may be equipped with an optional trailer pickup hitch.

Make sure you will be obeying all pertinent laws and regulations before towing.

Make sure that the trailer draw bar is suitable for your machine and has sufficient clearance to enable the machine to turn without fouling.

7. CONTROL AND PARTS FUNCTIONS



WARNING

Examine the tow hitch and the trailer draw bar towing ring for signs of wear before each use. A badly fitting or worn hitch or towing ring could cause loss of the trailer and injury to yourself or other people.



WARNING

Do not exceed the permitted limits on trailer gross weight or hitch load. The machine may become unstable.

Make sure your tyre pressures are correct and that the loaded trailer does not exceed the maximum gross trailer weight. Refer to **Specifications, Trailer Towing**.

When towing, the machine must be unladen (without ballast).

Connecting the Trailer

Important: Before the trailer is connected, refer to the trailer manual for more information. Do not modify the tow hitch.

Important: The procedure to connect the trailer to the tow hitch depends on the type of trailer. Always follow these precautions.

1. Stop the machine on hard, level ground.
2. Engage the park brake and set the forward/reverse lever to neutral. Stop the engine.
3. If applicable, adjust the mirror(s) to get a good view of the tow hitch area.



WARNING

Ensure that no person is between the machine and trailer when the machine is reversing up to the trailer.

4. Connect the trailer to the tow hitch.
 - a. Make sure that the trailer and its draw bars are in the correct position for connection before the machine approaches the trailer.
 - b. If a helper is available to manoeuvre the trailer, they must stand away from the machine until the tow hitch A is aligned correctly with the trailer towing eye.

7. CONTROL AND PARTS FUNCTIONS

- The helper must not go near the trailer or machine until the machine has stopped, with the park brake engaged and the engine turned off.
- c. Connect the trailer lights into the socket.
Make sure that all the trailer lights and the direction indicator lights operate correctly and are visible to other road users.
 - d. After the trailer is connected, the machine operator must not start the engine until the helper is away from the machine and trailer.
5. Select the applicable gear and drive to suit the conditions.
 6. Make sure the brakes operate correctly and get used to the braking effect before you drive on a public highway.



WARNING

Make sure the trailer hitch has correctly engaged and locked before driving off.

7. Tow at a speed at which you can keep full control of the machine.

Note: Only tow a full trailer when the loadbay is full. Otherwise the weight of the trailer could de-stabilise the machine by reducing the traction and braking performance.

Disconnecting the Trailer

To disconnect the trailer reverse the steps in Connecting the Trailer. Be careful when you disconnect the trailer. The load in the trailer may have moved when the machine was driven, this could cause the trailer to tip backwards unexpectedly when its disconnected.

Drawbar

1. TECHNICAL DATA

1.1. MAKER

Name: Changzhou Xiangrong Auto Industry Co., Ltd.

Address: No.199, North Qingyang Road, Yanning District, Changzhou City, 213028, Jiangsu Province, P.R.China

1.2. TYPE

Tractor drawbar non-automatic coupling: LH800U-D.36a

ISO 6489 Part 3 (Directive 2009/144/EC Annex IV - Appendix 1 - Fig. 3)

Type-approval number: e24*2009/144*2010/62*0001*00

7. CONTROL AND PARTS FUNCTIONS

1.3. TECHNICAL DATA

Technically permissible trailer mass: 3t


Test load: 3 t

Technically permissible static vertical load: 300Kg

2. MOUNTING PRESCRIPTIONS

2.1. HEIGHT ABOVE THE GROUND OF THE COUPLING DEVICE (H)

See figure below:



All

tractors with a loaded mass exceeding 2,5 tonnes must be fitted with a trailer coupling having a ground clearance satisfying one of the following relations:

$$h_1 \leq \frac{(m_a - 0.2 \times m_t) \times l - (S \times c)}{0.6 \times (0.8 \times m_t + S)}$$

or

$$h_1 \leq \frac{(m_{la} - 0.2 \times m_t) \times l - (S \times c)}{0.6 \times (0.8 \times m_{lt} - 0.2m_t + S)}$$

where:

m_t : mass of the tractor,

m_{lt} : mass of the tractor with ballast weight on the front axle,

m_a : weight on the front axle of the unladen tractor,

8. STARTING THE ENGINE

Procedure for Starting a Cold Engine



WARNING

Never run an engine in an enclosed area. Carbon monoxide exhaust gas is poisonous and can cause severe injury or death. Always start engines outdoors.



WARNING

POTENTIAL HAZARD

Freezing control cables in cold weather.

WHAT CAN HAPPEN

You could be unable to control the vehicle, which could lead to an accident or collision.

HOW TO AVOID THE HAZARD

When riding in cold weather, always make sure all control cables work smoothly before you begin riding.



CAUTION

You must allow your vehicle adequate warm up time before operating or engine damage could result.

1. Shift the drive select lever into the neutral position.

NOTE: When the drive select lever is in the neutral position, the neutral indicator light should come on. If the neutral indicator light does not come on, ask a dealer to inspect the electric circuit.

The engine can not be started in any other gear. However, it is recommended to shift into neutral before starting the engine.

3. With your foot off the accelerator pedal, start the engine by turning the key to "START".


NOTE: If the engine fails to start, release the key, and then try starting again. Wait a few seconds before the next attempt. Each cranking should be as short as possible to preserve battery energy. Do not crank the engine more than 5 seconds on each attempt.

8. STARTING THE ENGINE

Jump-starting

Jump-starting the vehicle should be avoided. The battery should be removed and charged instead. However, if the vehicle must be jumpstarted, proceed as follows.

1. Turn the key to "OFF".
2. Using a charged 12 V battery, connect the positive lead of the jumper cable to the positive terminal of the battery in the vehicle and the other end of the positive lead to the positive terminal of the charged battery.



1. Jumper cable positive lead 2. Jumper cable negative lead

5. Connect the negative lead of the jumper cable to the negative terminal of the charged battery and the other end of the negative lead to an unpainted metal surface of the vehicle.
6. Start the engine.
7. After the engine starts, disconnect the negative lead of the jumper cable from the vehicle and charged battery, and then disconnect the positive lead of the jumper cable from the charged battery and the battery in the vehicle.

9. RIDING GEAR

SAFE RIDING GEAR

Always wear clothing suitable to the type of riding you are doing. ATV riding requires special protective clothing which will make you feel more comfortable and reduce chances of injury.

1. Helmet

Your helmet is the most important piece of protective gear for safe riding. A helmet can prevent a severe head injury.

Select an approved off-road motorcycle -type helmets that fits properly.

2. Eye Protection

A pair of goggles or helmet face shield offer the best protection for your eyes.

3. Gloves (off-road style)

4. Boots

A pair of strong over the calf type boots with heels, such as motocross boots.

5. Clothing

To protect your body, long sleeves and pants should always be worn. Riding pants with kneepads, a jersey and shoulder pads provide the best protection.



WARNING

POTENTIAL HAZARD

Operating this vehicle without wearing an approved motorcycle helmet, eye protection, and protective clothing.

WHAT CAN HAPPEN

Operating without an approved motorcycle helmet increases your chances of a

9. RIDING GEAR

severe head injury or death in the event of an accident.

Operating without eye protection can result in an accident and increases your chances of a severe injury in the event of an accident.

HOW TO AVOID THE HAZARD

Always wear an approved motorcycle helmet that fits properly. You should also wear: eye protection (goggles or face shield), gloves, boots, long-sleeved shirt or jacket long pants.

10. CARRYING LOADS

CARRYING LOADS

Cargo or a trailer can change the stability and handling of a vehicle.

You must use common sense and good judgment when carrying cargo or towing a trailer. Keep the following points in mind:

- Never exceed the weight limits shown. An overloaded vehicle can be unstable.

MAXIMUM LOADING LIMIT

Cargo bed: 300 kg (661lbs)

Trailer hitch:

Pulling load (total weight of trailer and cargo): 520 kg (1146 lbs)

Tongue weight (vertical weight on trailer hitch point): 50 kg (110 lbs)

- Choose a trailer hitch drawbar designed for use with a 5 cm (2 in) receiver.
- Do not exceed the maximum tongue weight. You can measure tongue weight with a bathroom scale. Put the tongue of the loaded trailer on the scale with the tongue at hitch height. Adjust the load in the trailer, if necessary, to reduce the weight on hitch. If you are carrying cargo and towing a trailer, include the tongue weight in the maximum vehicle load limit.
- Load cargo in the cargo bed as close to the center of the vehicle as possible and tie it down using the cargo hooks equipped on the cargo bed.
- Tie down cargo securely in the trailer. Make sure cargo in the trailer cannot move around. A shifting load can cause an accident.
- Make sure the load does not interfere with controls or your ability to see where you are going.
- Drive more slowly than you would without a load. The more weight you carry, the slower you should go. Although conditions vary, it is good practice not to exceed low range whenever you are carrying heavier loads

10. CARRYING LOADS

or when towing a trailer.

- Allow more braking distance. A heavier vehicle takes longer to stop.
- Avoid making sharp turns unless at very slow speeds.
- Avoid hills and rough terrain. Choose terrain carefully. Added weight affects the stability and handling of the vehicle.



WARNING

POTENTIAL HAZARD

Overloading this vehicle or carrying or towing cargo improperly.

WHAT CAN HAPPEN

Could cause changes in vehicle handling which could lead to an accident.

HOW TO AVOID THE HAZARD

Never exceed the stated load capacity for this vehicle. Cargo should be properly distributed and securely attached. Reduce speed when carrying cargo or pulling a trailer. Allow greater distance for braking.



WARNING

POTENTIAL HAZARD


Carrying a passenger in the cargo bed.

WHAT CAN HAPPEN

The passenger could fall or be struck by objects in the cargo bed.

HOW TO AVOID THE HAZARD

Never carry a passenger in the cargo bed. The cargo bed is designed to carry cargo only.



11. DRIVING YOUR VEHICLE

GETTING TO KNOW YOUR VEHICLE

This off-highway utility vehicle will handle and maneuver differently from an ordinary passenger car or other vehicle. Before you begin to use your vehicle, be sure you have read this Owner's Manual completely and understand the operation of the controls. Pay particular attention to the safety information. Please also read all caution and warning labels on your vehicle. This vehicle is designed for the operator and one passenger. The driver and passenger must always wear a seat belt. Never carry passengers in the cargo bed.



WARNING

POTENTIAL HAZARD

Not wearing the seat belt.

Wearing the seat belt improperly.

WHAT CAN HAPPEN

There is increased risk of being killed or seriously injured in an accident.

HOW TO AVOID THE HAZARD

Always wear your seat belt when riding in the vehicle. Be sure the seat belt is close-fitting across your hips and is latched securely.



WARNING

The engine rpm limiter will work at [6000rpm](#), this may cause excessive fuel to build in the exhaust, and ignited by the catalyst in the muffler, MAY RESULT IN THE MUFFLERS OVERHEATING AND FIRE RISK.

Always reduce throttle when the engine reach top rpm, avoid the engine popping.



WARNING

You must inspect your UTV each time before riding to ensure it is in proper working order. If proper inspection is not done, severe injury or death could result.

See "4.DAILY PRE-RIDE INSPECTION"

11. DRIVING YOUR VEHICLE


LEARNING TO OPERATE YOUR VEHICLE

You should become familiar with the performance characteristics of the vehicle in a large, flat area that is free of obstacles and other vehicles. Practice control of the accelerator pedal, brakes, steering, and drive select lever. Drive first at slow speed and become comfortable at that speed before gradually increasing your speed. Become familiar with the way the vehicle feels in low and high ranges, first in two-wheel drive (2WD) and then in four-wheel drive (4WD). Also practice driving in reverse. Take the time to learn basic operation before attempting more difficult maneuvers.

1. Set the parking brake, shift to neutral, and follow the instructions to start the engine.
2. With the engine idling, shift the drive select lever into low or high. Then release the parking brake.
3. Press the accelerator pedal slowly and smoothly. The centrifugal clutch will engage and you will start to accelerate. Avoid higher speeds until you are thoroughly familiar with the operation of your vehicle.
4. When slowing down or stopping, take your foot off the accelerator pedal and smoothly press the brake pedal. Improper use of the brakes can cause the tires to lose traction, reducing control and increasing the possibility of an accident.

MAKING TURNS

It is possible for the vehicle to roll over or go out of control if you attempt sharp, high-speed turns. You should also be careful making sharp turns on rough terrain. Do not attempt to turn around or make abrupt maneuvers on slopes. Position your hands on the steering wheel so that your thumbs and fingers do not wrap around the wheel. This is particularly important when driving in rough terrain. The front wheels will move right and left as they respond to the terrain, and this movement will be felt in the steering wheel. A sudden jolt could wrench the steering wheel around, and your thumbs or fingers could be injured if they are in the way of the steering wheel spokes.



11. DRIVING YOUR VEHICLE

BRAKING

Braking ability is affected by the type of terrain. In most cases, gradually application of the brakes is more effective than abrupt braking, particularly on loose surfaces like gravel. Always allow for greater braking distance on rough, loose, or slippery surfaces.

GOING UPHILL

Do not attempt to climb hills until you have mastered basic maneuvers on flat ground. Use proper driving techniques to avoid overturns on hills and slopes. Drive straight up hills, and avoid crossing the side of a hill, which increases your chance of rollover. Practice first on gentle slopes before attempting steeper hills. Always check the terrain carefully before attempting any hill. Use common sense and remember that some hills are too steep for you to climb. Choose carefully which hills you attempt to climb. Avoid hills with slippery surfaces or ones where you will not be able to see far enough ahead of you.



WARNING

POTENTIAL HAZARD


Operating on excessively steep hills.

WHAT CAN HAPPEN

The vehicle can overturn more easily on extremely steep hills than on level surfaces or small hills.

HOW TO AVOID THE HAZARD

Never operate your vehicle on hills too steep for it or your abilities. Never operate vehicles on hills steeper than 15%. Do not drive across the face of a hill. Go straight up the hill. Practice on smaller hills before attempting large hills.



11. DRIVING YOUR VEHICLE

Before climbing the hill, first be sure you are operating in low range 4WD (4WD mode). To climb a hill, you need traction, momentum, and steady throttle. Travel fast enough to keep your momentum going, but not so fast that you cannot react to changes in the terrain as you climb. Slow down when you reach the crest of the hill if you cannot clearly see what is on the other side – there could be another person, an obstacle, or a sharp drop off.

If you start to lose traction or momentum when climbing, and you decide you will be unable to continue, use the brakes to come to a stop. Do not attempt to turn the vehicle around. With your foot on the brake, look behind you and plan your descent. Release the brake and begin to coast down the hill. gently applying the brakes when necessary.

GOING DOWNHILL

Check the terrain carefully before going down a hill. When possible, choose a path that lets you drive your vehicle straight downhill. Avoid sharp angles that could allow the vehicle to pitch or roll over. Carefully choose your path and drive no faster than you will be able to react to obstacles that may appear.



WARNING

POTENTIAL HAZARD

Going down a hill improperly.

WHAT CAN HAPPEN

Could cause loss of control or cause the vehicle to overturn.

HOW TO AVOID THE HAZARD

Always check the terrain carefully before you start down any hill. Never go down a hill at high speed. Avoid going down a hill at an angle that would cause the vehicle to lean sharply to one side.

Go straight down the hill where possible.

Before starting down hill, make sure the vehicle is in low-range 4WD (4WD model). Go as slowly as possible. If you are starting to go too fast, apply the brakes gently. Avoid sudden application of the brakes, which could cause the vehicle to start sliding. If you are sliding or skidding, try to steer in the direction the vehicle is sliding to help you regain control. If you must turn on the hill to avoid an obstacle, do so slowly and carefully. If the vehicle starts to tip, gradually steer in the downhill direction if there are no obstacles in your path. As you regain proper balance, gradually steer again in the direction you want to go.

11. DRIVING YOUR VEHICLE



WARNING

POTENTIAL HAZARD

Try to stop the tipping vehicle with your arm or leg.

WHAT CAN HAPPEN

You could be severely injured. You could suffer a crushed hand, arm, leg, or foot,

HOW TO AVOID THE HAZARD

You must keep your arms and legs inside the vehicle until it has stopped moving.

As with any off-road-capable vehicle, there is a risk of tip over or rollover under certain conditions. Uneven terrain or slopes which pitch the vehicle sideways, turning too fast or sharp, or a combination of conditions increase the risk of tip over.

If you are in a situation where the vehicle is tipping over, do not put your arm or/ and leg outside the vehicle, do not try to stop tipping with your arm or leg. You could be severely injured. You could suffer a crushed hand, arm, leg, or foot, if part of your body is caught underneath the vehicle.

CROSSING THROUGH SHALLOW WATER

If you must cross shallow, slow moving water up to 200mm (8 in) depth, choose your path carefully to avoid sharp drop-offs, large rocks, or slippery surfaces that could cause the vehicle to overturn. Never operate through water deeper than 200mm (8 in) or fast flowing water. Wet brakes may have reduced effectiveness. After leaving the water, test your brakes. If necessary, apply the brakes several times to let friction dry out the linings.

NOTE: After running the vehicle in water, it is critical your machine is serviced as outlined in the maintenance chart see "16.maintenance".The following areas need special attention: engine oil, transmission oil, rear gearcase, and all grease fittings.



WARNING

POTENTIAL HAZARD

Operating this vehicle through deep or fast-flowing water.

WHAT CAN HAPPEN

Loss of control, which could result in an accident including overturn, which could increase the risk of drowning.

HOW TO AVOID THE HAZARD

Never operate this vehicle in fast flowing water or in water deeper than 200 mm (8 in). Remember that wet brakes may have reduced stopping ability. Test your brakes after leaving water. If necessary, apply them several times to let friction dry out the linings.

11. DRIVING YOUR VEHICLE

RIDING OVER ROUGH TERRAIN

Operating over rough terrain should be done with caution. Look for obstacles that could cause damage to the vehicle or could lead to a rollover or accident. Avoid jumping the vehicle as injury, loss of control, and damage to the vehicle could occur.



WARNING

POTENTIAL HAZARD

Failure to use extra care when operating this vehicle on unfamiliar terrain.

WHAT CAN HAPPEN

You can come upon hidden rocks, bumps, or holes, without enough time to react. Could result in the vehicle overturning or going out of control.

HOW TO AVOID THE HAZARD

Go slowly and be extra careful when operating on unfamiliar terrain. Always be alert to changing terrain conditions when operating the vehicle.

RIDING IN BRUSH OR WOODED AREAS

When operating in areas with brush or trees, watch carefully on both sides and above the vehicle for obstacles such as branches that the vehicle might hit, causing an accident, or for brush that might enter the vehicle as you pass and strike the driver or passenger. Never hold onto the enclosure so your hand is outside the vehicle. Hold only onto the handgrip inside the enclosure.

ENCOUNTERING OBSTACLES ON THE TRAIL

If you cannot go around an obstacle such as a fallen tree trunk or a ditch, stop the vehicle where it is safe to do so. Set the parking brake and get out to inspect the area thoroughly. Look from your approach side and the exit side. If you believe you can continue safely, decide the path that will allow you to get over the obstacle at as close to a right angle as possible to minimize vehicle tipping. Go only fast enough to maintain your momentum but still give yourself plenty of time to react to changes in conditions. If there is any question about your ability to maneuver safely over the obstacle, you should turn around, if the ground is flat and you have the room, or back up until you find a less difficult path.



WARNING

POTENTIAL HAZARD

Improperly operating over obstacles

WHAT CAN HAPPEN

Could cause loss of control or a collision. Could cause the vehicle to overturn.

HOW TO AVOID THE HAZARD

Before operating in a new area, check for obstacles. Use extreme caution

11. DRIVING YOUR VEHICLE

when operating over large obstacles, such as large rocks or fallen trees.

PARKING

When parking, stop the engine and shift the drive select lever into the neutral position. Apply the parking brake to help prevent the vehicle from rolling.

Parking on a slope

1. Bring the vehicle to a stop by applying the brakes.
2. Stop the engine.
3. With the brakes applied, set the parking brake.



WARNING

POTENTIAL HAZARD


Parking on a hill or other incline.

WHAT CAN HAPPEN

The vehicle could roll out of control, increasing the chance of an accident.

HOW TO AVOID THE HAZARD

Avoid parking on hills or other inclines. If you must park on an incline, apply the parking brake, and block the front and rear wheels with rocks or other objects. Do not park the vehicle at all on hills that are so steep you could not walk up them easily.



12. CVT SYSTEM



WARNING

The CVT system rotates at high speeds. Creating large amounts of force on clutch components.

Do not modify any components of the CVT system. Any modification will damage the system; cause the system to be out of balance.

The CVT housing must be securely in place during operation.

Failure to comply with this warning can result in severe injury or death.

CVT SYSTEM

On UTV, the approximate gear ratio difference between high and low range is 1:1.29. This difference in gearing affects the operation of the CVT, especially at speeds less than 7 MPH, due to the system's dependence on engine speed.

By switching to low range while operating at low ground speeds, the air temperature in the clutch will be reduced. Reducing the temperature inside the clutch cover extends the life of the CVT components (belt, cover, etc.).

WHEN TO USE LOW RANGE

The following lists provide a guideline for when to use low range rather than high.

Low Range

- Basic operation at speeds less than 7 MPH (11km/h)
- Heavy pulling
- Riding through rough terrain (swamps, mountains, etc.) at low ground speeds

High Range:

- Basic operation at speeds greater than 7 MPH (11km/h)
- High ground speeds

13. BATTERY



WARNING

Whenever removing the battery, disconnect the negative (black) cable first. When reinstalling the battery, connect the negative (black) cable last or an explosive situation could result causing serious injury or death.



WARNING

Battery electrolyte is poisonous. It contains sulfuric acid. Serious burns can result from contact with skin, eyes or clothing. Antidote:

External: Flush with water.

Internal: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call physician immediately.

Eyes: Flush with water for 15minutes and get prompt medical attention.

Batteries produce explosive gases. Keep sparks, flame, cigarettes, etc. away. Ventilate when charging or using in an enclosed space. Always shield eyes when working near batteries. KEEP OUT OF REACH OF CHILDREN.

Battery Removal

1. Disconnect hold down straps holding the electrical box and battery in position and remove battery cover.
2. Disconnect the black (negative) battery cable first.
3. Disconnect the red(positive) battery cable next.
4. Lift the battery out of the UTV, being careful not to tip it sideways and spill electrolyte.



CAUTION

If electrolyte spills, immediately wash it off with a solution of one tablespoon baking soda and one cup water to prevent damage to the UTV.

Battery Installation and Connections



WARNING

To avoid the possibility of explosion, always connect battery cables in the order specified. Red (positive) cable first; black (negative) cable last. An exploding battery can cause serious injury or death.

baking soda and one cup water to prevent damage to the UTV.

13. BATTERY

Battery Installation and Connections



WARNING

To avoid the possibility of explosion, always connect battery cables in the order specified. Red (positive) cable first; black (negative) cable last. An exploding battery can cause serious injury or death.



WARNING

Battery terminals and connections should be kept free of corrosion. If cleaning is necessary, remove the corrosion with a stiff wire brush. Wash with a solution of one tablespoon baking soda and one cup water. Rinse well with tap water and dry off with clean rags. Coat the terminals with dielectric grease or petroleum jelly. Be careful not to allow cleaning solution or tap water into the battery.

1. Set the battery in its holder.
2. First connect and tighten the red (positive) cable.
3. Second connect and tighten the black (negative) cable.
4. Reinstall battery cover and attach the hold down strap.
5. Verify that cables are properly routed.

NOTE:

- When you UTV is placed in storage for one months or more, the battery should be removed, charged to proper level, and stored in a cool dry place.
- Before reusing, take the battery to your dealer for testing and recharging. Power plug leads may need to be bent down so that battery cover may be installed.
- When installing a new battery, make certain it is fully charged prior to it is initial use. Using a new battery that has not been fully charged can damage the battery resulting in a shorter life of the battery, It can also hinder vehicle performance.



CAUTION

Your UTV is equipped with a 60Ah Battery. This may not be sufficient to provide power for optional equipment. When installing optional equipment please upgrade your battery as necessary. See your dealer for the proper battery.

14. EXHAUST SYSTEM

SYSTEM REGULATION

TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED!

CAUTION: Exhaust system components are very hot during and after use of UTV.

- Do not touch exhaust system components. Serious burns can result.
- Be especially careful when traveling through tall grass. The potential for fire exists



WARNING

The engine exhaust from this product contains chemicals known, in certain quantities, to cause cancer, birth defects or other reproductive harm.

15. MAINTENANCE

Service Schedules

Introduction



WARNING

Maintenance must be done only by suitably qualified and competent persons.

Before doing any maintenance make sure the machine is safe, it should be correctly parked on level ground.

To prevent anyone starting the engine, remove the starter key. Disconnect the battery when you are not using electrical power. If you do not take these precautions you could be killed or injured.

A badly maintained machine is a danger to the operator and the people working around him. Make sure that the regular maintenance and lubrication jobs listed in the service schedules are done to keep the machine in a safe and efficient working condition.

Apart from the daily jobs, the schedules are based on machine running hours. Keep a regular check on the hourmeter readings to correctly gauge service intervals. When there is no hourmeter fitted, use the distance equivalents to determine the service intervals. ➡ Hours and Distance Equivalents (P16-3) Do not use a machine which is due for a service. Make sure any defects found during the regular maintenance checks are rectified immediately.

NOTE:

More often under severe use, such as dirty or wet conditions to purge water or dirt contamination from grease fittings and other critical components.

Vehicles subjected to severe use, such as operation in wet or dusty areas, should be inspected and serviced more frequently.

Inspect, clean, lubricate, adjust or replace parts as necessary.

15. MAINTENANCE

How to Use the Service Schedules

In the example shown, **A** shows all service requirements to be carried out every 10 hours and **B** shows the requirements to be carried out every 500 hours.

Important: Services should be carried out at eight the hourly interval or distance interval, whichever occurs first.

➔ Hours and Distance Equivalents(P16-3)

Important: The intervals given in the schedules must not be exceeded. If the machine is operated under severe conditions (high temperature, dust, water, etc.), shorten the intervals.

	Operation	10	50	100	125	250	500	1000	2000
ELECTRICS									
Battery - Electrolyte Level (If Applicable)	- Check		☐	☐	☐	☐	☐	☐	☐
Battery - Charge Condition	- Check			☐	☐	☐	☐	☐	☐
Battery Terminals - Condition/Tightness	- Check			☐	☐	☐	☐	☐	☐
Wiring for Chafing/Routing	- Check			☐	☐	☐	☐	☐	☐
TRANSMISSION, AXLES AND STEERING									
Steering System	- Check			☐	☐	☐	☐	☐	☐
Wheel Nut - Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Hub Nut - Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Wheel Bearings - Condition/Play	- Check			☐	☐	☐	☐	☐	☐

Hours and Distance Equivalents

Every 10 Hours or Daily

First 100 Hours or 1000 miles (1600 kilometres)

Every 125 Hours or 1,250 miles (2000 kilometres)

Every 250 Hours or 2,500 miles (4,000 kilometres)

Every 500 Hours or 5,000 miles (8,000 kilometres),

Every 1,000 Hours or 10,000 miles (16,000 kilometres)

Every 2,000 Hours or 20,000 miles (32,000 kilometres)

15. MAINTENANCE

	Operation	10	50	100	125	250	500	1000	2000
ELECTRICS									
Battery - Electrolyte Level (If Applicable)	- Check		☐	☐	☐	☐	☐	☐	☐
Battery - Charge Condition	- Check			☐	☐	☐	☐	☐	☐
Battery Terminals - Condition/Tightness	- Check			☐	☐	☐	☐	☐	☐
Wiring for Chafing/Routing	- Check			☐	☐	☐	☐	☐	☐
TRANSMISSION, AXLES AND STEERING									
Steering System	- Check			☐	☐	☐	☐	☐	☐
Wheel Nut - Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Hub Nut - Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Wheel Bearings - Condition/Play	- Check			☐	☐	☐	☐	☐	☐

15. MAINTENANCE

	Operation	10	50	100 ⁽¹⁾	125	250	500	1000	2000
Tyre Condition and Pressures (refer to Specifications)	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Gearbox Oil	- Check			☐	☐	☐	☐	☐	☐
Gearbox Oil	- Change			☐	☐	☐	☐	☐	☐
Gearbox Control Cables and Linkage	- Check/ Adjust/ Grease			☐	☐	☐	☐	☐	☐
Propshafts - Front and Rear	- Check/ Grease		☐	☐	☐	☐	☐	☐	☐
Front Differential Oil (and Rear for 4WD)	- Check			☐	☐	☐	☐	☐	☐
Front Differential Oil (and Rear for 4WD)	- Change			☐	☐	☐	☐	☐	☐
CVT Belt - Condition	- Check/ Change			☐	☐	☐	☐	☐	☐
CVT Joints (4WD)	- Check			☐	☐	☐	☐	☐	☐
BRAKES									
Brake Fluid	- Change							☐	☐

15. MAINTENANCE





Service Schedules

	Operation	10	50	100 ⁽¹⁾	125	250	500	1000	2000
SUSPENSION									
Front Suspension - Condition and Security	- Check			☐	☐	☐	☐	☐	☐
Rear Suspension - Condition and Security	- Check			☐	☐	☐	☐	☐	☐
BODYWORK AND CAB									
General Damage	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Wing Mirrors - Condition/Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
ROPS Structure - Mounting/Security	- Check	☐	☐	☐	☐	☐	☐	☐	☐
Seat Belt - Condition/Security	- Check/ Adjust	☐	☐	☐	☐	☐	☐	☐	☐

15. MAINTENANCE

LUBRICATION RECOMMENDATIONS

	Item	Lube Rec	Method	Frequency
	1. Engine Oil	SAE 10W/30 API SF	Add to proper level on dipstick	Check level daily
	2.Brake Fluid	DOT 3 Only	Maintain level Between fill lines. See "7.CONTROL"	As require; change every two years or 200 hours
	3.Transmission Oil	SAE GL-4 85W/90	Add to proper level on dipstick	Change annually or at 100 hours.
	4.Rear Gear case oil	SAE GL-4 85W/90	See "15.MAINTENANCE/ Rear Gear Case Lubrication"	Change annually or at 100 hours
	5.Front Gear case oil (only for 4WD Model)	SAE GL-4 85W/90	See "15.MAINTENANCE/ Front Gear Case Lubrication"	Change annually or at 100 hours



15. MAINTENANCE

	Item	Lube Rec	Method	Frequency
●	6.Steering system	Grease	Lubricate the pivoting and sliding parts	Every 3 months or 50 hours
●	7.Tie rods	Grease	Grease	Semi-annually
●	8.Shift Linkages	Grease	Locate fittings and Grease	Semi-annually
●	9.Ball joints	Grease	Inspect, Locate fittings and Grease, or replace it if necessary	Semi-annually
●	10.Prop Shaft & Shaft Yoke, Spline Joint	Grease	Locate fitting and Grease	Semi-annually or 50 hours
●	11. Front/Rear A-arm	Grease	Locate fitting on pivot shaft and grease with grease gun	Semi-annually or 50 hours
●	12.Throttle Cable	Grease M	Grease, inspect and replace it if necessary	Semi-annually or 50 hours
●	13. Accelerator pedal and brake pedal	Grease	Grease, inspect	Semi-annually or 50 hours

NOTE:

1. More often under severe use, such as wet or dusty conditions .
2. Grease: Light weight lithium-soap grease.
3. Grease M: molybdenum disulfide(MoS_2) grease(water resistant).
4. *When suspension action becomes stiff or after washing.
5. Hours are based on 10 mph(16Km/h) average.

15. MAINTENANCE

PERIODIC MAINTENANCE RECORD

Use the following chart to record periodic maintenance work:

Maintenance Interval Performed	Servicing Date	Servicing Dealer or Person	Remarks
First 5 Hrs			
10 Hrs			
15 Hrs			
20 Hrs			
25 Hrs			
50 Hrs			
75 Hrs			
100 Hrs			

The following items should be checked occasionally for tightness; or if they have been loosened for maintenance service.

15. MAINTENANCE


WHEEL NUT TORQUE SPECIFICATIONS

Bolt Size		Specification	
Front	M12X1.25	69Ft.Lbs	95N.m
Rear	M12X1.25	69Ft.Lbs	95N.m

NOTE: All nuts that have a cotter pin installed must be serviced by an authorized Dealer.

Front Wheel Hub Tightening

Front wheel bearing tightness and spindle nut retention are critical component operations. Service work must be performed by an authorized dealer.




Tapered nuts: install with tapered side against wheel

AXLE BOOTS

- Rear Prop Shaft Boots,
- Front Axle (CV Joints, 4x4 model) Boots,


Check the protective boots for holes or tears. If any damage is found, have them replaced by an authorized dealer.



1. Front axle boot (× 2 each side)

15. MAINTENANCE

AIR FILTER SERVICE



1. Release clamp and remove cover.
2. Remove filter element and clean it.
3. Replace filter element as required.
4. Reinstall filter element into air box and tighten clamp. Do not over tighten clamp or filter damage may occur.

STEERING

Steering Inspection


The steering assembly of the machine should be checked periodically for loose nuts and bolts, worn tie rod ends, worn boots, and damage. Checking routing of all cables, hoses, and wiring to be sure the steering mechanism is not restricted or limited. If any found, have your dealer repair them before riding your vehicle.

The steering assembly should be also checked periodically for free operation, steering should move freely through entire range of travel without binding. Park on level ground. Turn the steering wheel right and left. Check for excessive free play, abnormal noises, or a rough feeling. Have an authorized dealer repair as necessary for proper operation.

Lubricate the pivoting parts.

Recommended lubricant:

Lithium-soap-based grease



15. MAINTENANCE

CAMBER AND CASTER

The camber and caster are non-adjustable.

TOE ALIGNMENT CHECK




WARNING

Do not attempt to adjust the tie rod for toe alignment. Severe injury or death can result from improper adjustment.

Contact your dealer. He/she has the training and tools to Make these adjustment.

The recommended toe alignment is 1/8" to 1/4" (3 to 6mm) toe out.


1. Set the steering wheel in a straight ahead position and hold them in this position.
2. Measure A and B, A minus B should be 1/16" to 1/8" (1.5 to 3mm).
3. If this measurement needs to be adjusted, contact your dealer for service.




WARNING

If the tie rod is positioned incorrectly or adjusted incorrectly, it will not pivot, may break, and may separate. Severe injury or death can result

Hold Rod End



Correctly
Tightened
Jam Nut



Incorrectly
Tightened
Jam Nut

BRAKES

15. MAINTENANCE

Front brake




WARNING

Once a bottle of brake fluid is opened, use what is necessary and discard the rest. Do not store or use a partial bottle of brake fluid. Brake fluid is hygroscopic, meaning it rapidly absorbs moisture from the air. This causes the boiling temperature of the brake fluid to drop, which can lead to early brake fade and the possibility of serious injury.

The front brake is hydraulic disc brakes which is depressing the brake pedal. These brakes are self-adjusting and require no adjustment.

The following checks are recommended to keep the brake system in good operating condition. How often they need checking depends upon the type of driving that has been done.

- Keep fluid level in the master cylinder reservoirs as described see “7.Control and part functions”. Normal functioning of the diaphragm is to extend into the reservoir as fluid level drops. If the fluid level is low and the diaphragm is not extended, a leak is indicated and the diaphragm should be replaced. Always fill the reservoir as indicated whenever the cover is loosened or removed to insure proper diaphragm operation. Use DOT 3 brake fluid.
- Check brake system for fluid leaks.
- Check brake for excessive travel or spongy feel.
- Check friction pads for wear, damage and loosened.
- Check security and surface condition of the disc.
- Pads should be changed when friction material is worn to 3/64”(1mm).(A)




Rear Brake

- The rear brake is a hydraulic disc type brake which is activated by the same pedal which activates the front brake system is self adjusting and requires no maintenance other than periodic checks of the pads for wear
- Pads should be changed when the friction material is worn to 3/64”(1mm).
- Inspect the brake disc and pad wear surface for excessive wear.

15. MAINTENANCE

Checking the brake fluid level



Insufficient brake fluid may let air enter the brake system, possibly causing the brakes to become ineffective. Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake fluid level is low, be sure to check the brake pads for wear and the brake system for leakage.

The brake fluid reservoir is located under the hood.

- When checking the fluid level, make sure the top of the brake fluid reservoir is level.
- Use only the recommended quality brake fluid. Otherwise, the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid: DOT 3


- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.
- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- Have an authorized dealer inspect the brake system if the brake fluid level goes down.

Brake pedal and accelerator pedal lubrication

Lubricate the pivoting parts.

Recommended lubricant:

Lithium-soap-based grease (all-purpose grease)



PARKING BRAKE

Checking

Although the parking brake has been adjusted at the factory, the brake should be checked for proper operation. The mechanical brake must be maintained to be fully functional.

1. With the engine off, apply the parking brake lever and attempt to move the

15. MAINTENANCE

ATV.

2. If the rear wheels are locked, it is adjusted properly.
3. If the wheels are not locked, it must be adjusted.
4. The maximum free play is equal to one click of the parking brake lever. If necessary, adjust the free play as follows.

Adjusting

To adjust (set up) the mechanical parking brake, use the following procedure

Note: The adjusting on the caliper is for the wear out of the pads.

1. With the engine off, loosen the adjuster on the lever.
2. Loosen the jam nut of the adjuster on the caliper.
3. Turn the adjuster (bolt) CW (clockwise) by hand till the pad touch the brake disc, turn the adjuster bolt CCW (counterclockwise) by 1/4 to one turn for 10 to 20mm free play at the end of the parking lever.
4. Tighten the jam nuts securely against the adjusters.
5. Make sure the rear wheels turns freely without dragging.
6. Turn the adjuster (the one on the lever) and apply the lever. While adjusting, it is important you apply the lever back and forth for operation, free play and the locking of the parking position.
7. Make sure the rear wheels turns freely without dragging and parking brake works properly.





CAUTION

Don't over tighten the adjuster. The maximum free play is equal to one click of the parking brake lever.

- .8. Field test for parking. It must be capable of holding the laden ATV stationary on an 18% up and down gradient.


A temporary adjusting can also be done to the brake cable on the parking lever side by turn the adjuster (nut) directly. But the adjust range is limited. Always do the **procedure 1 to 8** when necessary.



15. MAINTENANCE

Parking Brake Indicator (light) Switch Adjustment

The parking indicator switch, which is activated by the parking lever, is properly adjusted when the indicator light comes on just before braking takes effect. If necessary, adjust parking indicator switch as follows.



1. Open the hood. (See 7. CONTROL AND PARTS FUNCTIONS in this manual for hood opening and closing procedures.)
2. Turn the adjusting nut ① in or out to make the light come on properly, then lock the lock nut ②.
(all-purpose grease)

Throttle Free Play Inspection


1. Apply the parking brake.
2. Put gear in Neutral position.
3. Start the engine, and warm it up thoroughly.
4. Measure the distance the throttle pedal moves before the engine begins to pick up seep. Free play should be 1/16" to 1/8" (1.5-3mm).

Throttle Free Play Adjustment

Throttle cable free play is adjusted at the cable, under the passenger seat.

- 1, Slide the boots off. Loosen adjuster locknut.
- 2, Turn adjuster until 1/16" to 1/8" (1.5 to 3mm) freeplay is achieved at the throttle pedal.

- NOTE:** While adjusting free play, it is important you flip the throttle pedal back and forth.
- 3, Tighten locknut and slide boots over cable adjuster.




15. MAINTENANCE

Transmission Lubrication



CAUTION

Be sure no foreign material enters the transmission case.



The oil level stick of the transmission is located on the left side of the machine.

The transmission lubricant level should be checked monthly or 20 hours, whichever comes first. Transmission oil should be changed annually.

With the UTV on a level surface, remove the oil level stick and check the lubricant level. The correct transmission lubricant to use is SEA GL-4 85W/90 Lubricant. And see

“ 16.Maintenance : lubrication recommendations ” for the correct fluid level.

Transmission Oil Changing Procedure

1. Remove the oil level stick.
2. Remove the drain plug located on the bottom and drain the oil. Catch and discard used oil properly.
3. Clean and reinstall the drain plug torque to 14 ft.lbs. (20Nm)
4. Add the correct amount of SAE GL-4 85W/90 Lubricant until oil reaches the middle limit position of the oil level stick.
5. Check for leaks.

15. MAINTENANCE

Rear Gear case Lubrication




CAUTION

Be sure no foreign material enters the rear gear case.

Which the ATV on a level surface, remove the fill plug and visually inspect the lubricant level through the fill hole. Lubricant should be kept even with the center of the drill point approximately below the top of the fill hole.

NOTE: Do not add lubricant to the bottom of the fill plug threads. The correct load gear oil to use is SAE GL-4 85W/90 Weight Gear Lube.

Oil Changing Procedure



1. Remove drain plug. Catch and discard used oil properly.
2. Clean and reinstall the drain plug with a new sealing washer and tighten securely (11~14 ft. lbs/15~20N.m).
3. Remove fill plug and add 500ml of SAE GL-4 85W/90 Weight Gear Lubricant and inspect oil level. Oil level should be kept even with the center of the drill point (approximately below the top of the fill hole).
4. Reinstall the fill plug. Tighten securely (16~22 ft. lbs/22~30N.m).
5. Check for leaks.

15. MAINTENANCE

Front Gear case Lubrication




CAUTION

Be sure no foreign material enters the front gear case.

Which the ATV on a level surface, remove the fill plug and visually inspect the lubricant level through the fill hole. Lubricant should be kept even with the center of the drill point approximately below the top of the fill hole.

NOTE: Do not add lubricant to the bottom of the fill plug threads. The correct load gear oil to use is SAE GL-4 85W/90 Weight Gear Lube.



Front Gear case Oil Changing Procedure

1. Remove drain plug. Catch and discard used oil properly.
 2. Clean and reinstall the drain plug with a new sealing washer and tighten securely (11~14 ft. lbs/15~20N.m).
 3. Remove fill plug and add 550ml of SAE GL-4 85W/90 Weight Gear Lubricant and inspect oil level. Oil level should be kept even with the center of the drill point (approximately below the top of the fill hole).
 4. Reinstall the fill plug. Tighten securely (16~22 ft. lbs/22~30N.m).
- Check for leaks.

15. MAINTENANCE

WHEELS AND TIRES



WARNING

Operating your ATV with worn tires, improperly inflated tires, non-standard tires or improperly installed tire will affect vehicle handling which could cause an accident resulting in serious injury or death.

Follow the safeguards listed below to prevent this type of situation.

Important Safeguards

Maintain proper tire pressure according to charts below. Improper tire inflation may affect ATV maneuverability.

Do not use improper tires. The use of non-standard size or type tires may affect ATV handling.

Make certain the wheels are installed properly. If wheels are improperly installed it could affect vehicle handling and tire wear.

Tire Pressure	
front	rear
69kPa/10PSI	69kPa/10PSI

Wheel Removal Procedure

1. Stop the engine, place the transmission in gear and lock the parking brake.
2. Loosen the wheel nuts slightly.
3. Elevate the side of the vehicle by placing a suitable stand under the footrest frame.
4. Remove the wheel nuts and remove the wheel.

Wheel Installation

1. With the transmission in gear and the parking brake locked, place the wheel in the correct position on the wheel hub. Be sure the valve stem is toward the outside and rotation arrows on the tire point toward forward rotation.
2. Attach the wheel nuts and finger tighten them.
3. Lower the vehicle to the ground.
4. Securely tighten the wheel nuts according to the chart found in "**16.MAINTENANCE/ Wheel Nut Torque**".


Tire Inspection

When replacing a tire always use original equipment size and type.

15. MAINTENANCE

Tire Tread Depth

Always replace tires when tread depth is worn to 1/8" (3mm) (1) or less. Please refer to your Owner's Manual for tire specifications.



LIGHTS



WARNING

Keep your headlights and taillights clean. Poor light while riding can result in an accident causing severe injury or death.



CAUTION

Do not service while headlight is hot. Serious burns may result.
Do not touch a halogen lamp with bare fingers. Oil from your skin leaves a residue, causing a hot spot which will shorten the life of the lamp.

Headlight Lamp Replacement



WARNING

Keep your headlights and taillights clean. Poor light while riding can result in an accident causing severe injury or death.




CAUTION

Do not service while headlight is hot. Serious burns may result.
Do not touch a halogen lamp with bare fingers. Oil from your skin leaves a residue, causing a hot spot which will shorten the life of the lamp.


15. MAINTENANCE

A. HEADLIGHT LAMP REPLACEMENT AND ADJUST



1. To lower headlight brightness cut-off line, turn adjusting bolt (1) counterclockwise. And to raise brightness cut-off line, turn the bolt clockwise.
2. Take rubber cap (2) out from holder. Remove rebound clip to take the worn bulb out from socket. Align the semicircle on a new bulb with that in the socket before mounting the bulb. Install rebound clip just removed to fasten the bulb and then plug in wires.
3. Remove position lamp socket out of top cover. Remove the worn bulb by taking a hold of it and pulling it out. Insert a new bulb into socket before inserting the socket in its mounting hole.

B. TAILLIGHT LAMP REPLACEMENT



Taillight / Brake light Lamp /Indicator Lamp Replacement

If the taillight / brake light /Indicator Lamp does not work the lamp may need to be replaced.

Remove the cover.

1. Turn the plug and remove it from the socket.
2. Fit the plug in the socket and reassemble the cover.

1. Remove screws used to fasten lampshade, turn the screws counterclockwise with a Phillips screwdriver.
2. Remove lampshade.
3. Keeping a firm grasp on holder, hold bulb to remove it by pressing it down and turning it counterclockwise.
4. To install bulb, align high locating stud on bulb with that in brass socket and

15. MAINTENANCE

low locating stud on bulb with that in brass socket, and bulb will be locked after being pressed down and turned clockwise simultaneously.

CLEANING YOUR ATV

Keeping your ATV clean will extend the life of various components.

Washing

Never use a high pressure type car wash system, it can damage to the wheel bearings, transmission seals, body panels, brakes and warning labels, and water might enter the engine or exhaust system.

The best and safest way to clean your ATV is with a garden hose and a pail of mild soap and water. Use a professional type washing mitten, cleaning the upper body first and lower parts last. Rinse with water frequently and dry with a chamois to prevent water spots.

NOTE: If warning labels are damaged, contact your dealer for replacement.

Warning

Your ATV can be waxed with any non-abrasive automotive paste wax. Avoid the use of harsh cleaners since they can scratch the body finish.



CAUTION

Certain products, including insect repellants and chemicals, will damage plastic surfaces. Care must be taken when using these products plastic surfaces.

Storage of the Machine

INTRODUCTION

If you will not use the machine for an extended period, you must store the machine correctly. If you prepare the machine carefully and apply on-going care you can prevent deterioration and damage to the machine while it is in storage.

STORAGE AREA

The machine can be stored in a temperature range of: -20°C to 54°C (-4°F to 129°F).

When possible, you must keep the machine in a dry building or shelter.

If only an outdoor storage area is available, look for a storage area with good drainage.

If the machine is to be out of use for an extended period, careful preparation and on-going care will minimise the possibility of deterioration and damage while in storage.

15. MAINTENANCE

PREPARE THE MACHINE FOR STORAGE

1. Clean the machine to remove all unwanted material and corrosive products. Dry the machine to remove solvents and moisture.
2. Apply grease to the moving parts. Refer to Greasing the Machine.
3. Examine the machine for worn or damaged parts. Replace if necessary.
4. Fill the fuel tank to prevent a build up of condensation in the tank.
5. Examine the coolant condition. Replace if necessary.
6. Examine all fluid levels. Top up if necessary.

PUT THE MACHINE INTO STORAGE

1. Park the machine on level, solid ground. Park the machine in a position where the machine is easy to tow (in case the machine does not start at the end of the storage period). Place suitable timbers under the machine to eliminate direct contact with the ground.
2. Retract all rams and lower the attachments to the ground, if applicable.
3. Vent the hydraulic system, if applicable.
4. Remove the starter key.
5. Apply a thin layer of grease or petroleum jelly to all exposed ram piston rods, if applicable.
6. Remove the battery. Charge the battery. Keep the battery in warm, dry conditions. Charge the battery periodically.
7. If you keep the machine outdoors, cover the machine with tarpaulins or plastic sheets.
8. Frequently turn the road wheels to prevent distortion of the tyre-ply.

DURING STORAGE

Operate the machine functions each week to prevent a build up of rust in the engine and hydraulic circuits, and to minimise deterioration of the hydraulic seals.

1. Clean the machine to remove all unwanted material and corrosives. Remove the grease or petroleum jelly from the ram piston rods, if applicable.
2. Install a charged battery.
3. Start the engine.
4. Operate the hydraulic controls, if applicable. Make sure that the hydraulic functions operate correctly.
5. Prepare the machine for storage. Refer to **Put the Machine into Storage**.

TAKE THE MACHINE OUT OF STORAGE

- 1 Examine the coolant condition. Replace If necessary.
- 2 Examine all fluid levels. Top up if necessary.
- 3 Clean the machine to remove unwanted material and corrosives.

15. MAINTENANCE

Remove the grease or petroleum jelly from the ram piston rods, if applicable.

4 Install a charged battery.

5 Check the tension of the alternator drive belt.

6 Start the engine.

7 Operate the hydraulic controls, if applicable.

Make sure that the hydraulic functions operate correctly.

STORAGE TIPS



CAUTION

Do not start the engine during the storage period. This will disturb the protective film created by fogging.

Cleaning——Clean the ATV thoroughly.

Fuel——drain the carburetor bowl completely.

Oil Add and Filter Change——Warm the engine and change oil and filter.

Air Filter/Air Box——Inspect and clean or replace the pre-cleaner and air filter. Clean the air box and drain the sediment tube.

Inspect All Fluid Levels——Inspect the following fluid levels and change if necessary: transmission; brake fluid (change every two years or as required if fluid looks dark or contaminated).

Check and Lubricate Cables/Grease——Inspect all cables and lubricate.

Storage Area/Covers——Set tire pressure and safely support the ATV with the tires 1-2"(25-50mm) off the ground. Be sure the storage area is well ventilated. Cover the machine with a ATV cover.

NOTE: Do not use plastic or coated materials. They do not allow enough ventilation to prevent condensation, and may promote corrosion and oxidation.

TRANSPORTING

Whenever the ATV is to be transported the following measures should be taken.

1. Turn off the engine and remove the key.
2. Be certain the fuel cap, oil cap, and seat are installed correctly.
3. Always tie the frame of the ATV to the transporting until securely using suitable straps or rope.
4. Always place the transmission in gear and lock the parking brake.

15. MAINTENANCE

Lifting the Machine



WARNING

The machine can only be lifted safely when there is no payload in the load bay. Important: This procedure must only be done by the Dealer.

1. Remove any excess or loose dirt from the machine. (The dirt could unbalance the machine when it is lifted).
2. Park the machine on hard, level ground and engage the park brake. Stop the engine and remove the starter key.
3. You must use only the forklift points 1 to lift the machine.



WARNING

Keep people clear of the unload area. The load can roll off the forks and injure bystanders.

4. Be careful when you lift the machine, make sure the pallet forks are aligned correctly and will not cause damage to the engine sump.



CAUTION

Fork Spacing




Loads can fall off incorrectly spaced forks. Always space the forks correctly for the load. Make sure the forks are completely under the load before lifting.

5. Make sure the machine is stable on the forks.
6. Use straps to secure the machine to the forks.

Important: Make sure that the lifting machine is rated to lift the gross weight of the machine.



16. TOOL



17. SPECIFICATION

Dimension & Capacities		
L X W X H	4010X1543X1995 mm	158X61X79 in
Wheel Base	2830 mm	111 in
Turn Radius	Outer: 6000 mm	236 in
Ground Clearance	215mm	8 in
Fuel capacity	30 L	7.9 gal
Dry Weight	900kg	1984 lbs
Cargo Bed Maximum load limit	300 kg	661 lbs
Load Capacity (Combined Rider& Payload)	600 kg	1323 lbs
Gross Vehicle Weight (Maximum Technically Permissible Mass)	1490 kg	3285 lbs
Tongue Weight	50 kg	110 lbs
Tow Capacity	520kg	1146 lbs
Drive System		
Drive System	CVT	
Front Tire	26×9-14	
Rear Tire	26×11-14	
Tire Pressure(front)	69kPa	10 PSI
Tire Pressure(rear)	69kPa	10 PSI
Brake System		
Front Brake	4 Wheel Hydraulic Disc	Front and rear unified
Rear Brake		
Operation	Foot	
Parking Brake	Hand	
Suspension		
Front	Dual A-arm	
Rear	Independent suspension(IRS)	
Front and Rear shock absorber	Coil spring/oil damper	
Drawbar		

17. SPECIFICATION

Type	tractor drawbar non-automatic coupling T-BOSS 900L-U
Technically permissible static vertical load	520Kg
Technically permissible trailer mass	3t

Electrical Equipment			
Battery		12V 60AH	
High Beam Light		55W x2	
Dip Beam Light		55W x2	
Brake/ Tail Light		1W/1W x2	
FRONT Turn Light		12V/1W X2	
REAR Turn Light		12V/ 1W X2	
Front Position Light		12V 5W x2	
REAR Position Light		12V 5W x2	
Register Plate Light		12V 5W	
Specified fuses	MAIN FUSE	40A	In The Fuse Box
	ELECTRICAL HEATING RELAY	20A	
	URGENCY SWITCH	10A	
	DIFF LOCK/4WD	30 A	
	12V DC-OUT	20 A	
	SHUT DOWN SWITCH	10A	
	LIGHTING SYSTEM	10 A	
	Fan SYSTEM	20 A	

Engine	
	CHERY SQR372
Engine Type	In-line, four-cylinder, water-cooled, DOHC
Bore x Stroke	72mm×66.5mm
Displacement	0.812L

EC Declaration of Conformity

A completed copy of the EC Declaration of Conformity is supplied with all machines manufactured according to 2003/37/ EC type examination and/or self-certification requirements.

17. SPECIFICATION

Emission Related Parts List	
Part Name	Part Number
Catalytic	4FM-14721-00
Oxygen Sensor	S18-3611065
Coolant Temp Sensor	B2G06-3611043
Intake Air Temperature Sensor	480ED-1008060
Throttle Position Sensor	F01R 00Y 196
Fuel Injector	IPM 018
ECM	FC50MAK
Spark Plugs	S11-3707100
Coil	372-3705110
Air Cleaner	4FM-14410-00
Fuel Tank	4FM-24110-00
Fuel Pump	4FM-24410-00
Roll-Over Valve	3AU-24105-00
Fuel Tank Caps	4AD-24601-00

18. ENGINE

The engine model is SQR372.

Note:

- This chapter is from the CHERY engine manual. If there is any inconsistency between the content and the previous chapter, the contents of the previous chapter of the **T-BOSS 900L-U** manual shall prevail.
- Please refer to chapter 1-17 of the **T-BOSS 900L-U** manual. for those places marked ☆ below.

California Proposition 65

WARNING

Engine exhaust, some of its constituents, certain vehicle components and fluids, contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.



SQR372 Engine User's Manual



Chery Engine Company





- I This manual is for reference only .
- I The information is subject to change without notice.
- I If you have any question, please call the service hotline 0086-553-5923068.



Contents

Chapter 1	The Technical Characteristics and Configuration Parameter	1
Chapter 2	Engine Outline.....	4
Chapter 3	Cooling Cycle Diagram	5
Chapter 4	Suspension Installed Location	6
Chapter 5	Electrical Appliances and Wiring Harness Installation Requirements	7
Chapter 6	Transmission Installed Location	8
Chapter 7	Inatallation Diagram of Crankshaft Position Sensor and Start.....	9
Chapter 8	Service and Maintenance	10

Chapter 1 The Technical Characteristics and Configuration Parameter

Model、Type and Parameters

No.	Item		Basic parameters
	Code		SQR372
1	Type		In-line,four-cylinder,water-cooled,DOHC
2	Fuel supply		EFI
3	Bore（mm）		72
4	Stroke（mm）		66.5
5	Displacement（L）		0.812
6	Compression ratio		9.5：1
7	Combustion chamber type		Tent-shaped
8	Ignition sequence		1-2-3
9	Fuel grade		93
10	Oil capacity（L）		2.9（The new oil filter）
11	Oil grade		SAE 10W/30 API SF
12	The direction of crankshaft rotary motion		clockwise（From the front-end look at the engine crankshaft pulley）
13	Start-up mode		Electric starter
14	Cool type		Mandatory cycle of antifreeze-coolant
15	Lubrication type		Compound (pressure, splash lubrication)
16	Net weight kg		76
17	Crank angle at intake valve open （budc）（°）		19
	Crank angle at intake valve closed （atdc）（°）		59
	Crank angle at exhaust valve open （bbdc）（°）		62
	Crank angle at exhaust valve closed （abdc）（°）		16
18	Normal Installation angle	Longitudina l incline（°）	≤5
		sidelong incline（°）	≤5



SQR372EngineUser'sManual

19	Engine normal inclination to use (°)	≤35
20	Overall dimension (L×W×H)mm	481×443×699


Performance Indicators

No.	Item	Indicators
1	Idling speed (r/min)	850±50
2	Rated stability (r/min)	≤±30
3	Rated power (kW@r/min)	39/6000
4	Max torque (N·m@r/min)	70/3500-4000
5	The lowest rate of fuel consumption (The total power) (g/kWh)	275
6	Starting Performance	The engine should be started smoothly in 30S without any special measure when the air temperature is -25℃.Start test is allowed to start three times continuously as a row. It can be restarted in 2 minutes later after the first failure.


Main characteristics and parameters of the assembly structure

Water Pump	Centrifugal
Gasoline Pump	Electric pump
Oil Pump	Rotor Style
Oil Filter	As a whole mounted rotating
Spark plug	RK06G
Starter	Permanent-magnet type slowdown slowdown
Generator	14V75A whole-alternator


Net power experiment




Chapter 2 Engine Outline




Engine vertical view



Engine back end view




Engine front-end view



Engine profile


Chapter 3 Cooling Cycle Diagram




Water flow	60 (L/min)		
Wind speed	6M/S	8M/S	10M/S
Wind resistance	33Pa	145Pa	293Pa
Heat dissipation capacity	30kW	35kW	39kW

Chapter 4 Suspension Installed Location

1、The installation requirements in intake side :



2、The installation requirements in exhaust side:




Chapter 5 Electrical Appliances and Wiring Harness


Installation Requirements

- 1、 Turn the ignition switch to the first gear and keep it for 20minutes then shut it down and repeat this action three times (aim to make ECU and engine sensor self-study) before these
- 2、 Water-proof the installation of ECU, all sensors assembled in engine, in case damaged by water,
- 3、 No barbaric operation and pay more attention to the direction of inserting or plugging wiring harness, which prevent stitch bended or broke off from working properly.
- 4、 Be attentive especially to ECU water-proof in case circuit board burned out.
- 5、 Make sure the installations of plug-ins are in position in case that the poor contact could cause malfunction.

Chapter 6 Transmission Installed Location



Chapter 7 Inatallation Diagram of Crankshaft Position Sensor and Starter



Characteristics of data :

Quantity	Numerical		Unit
	minimum	maximum	
Phase accuracy	+0.45	-0.45	°
Air space	0.3	1.7	mm
Round of the target speed	15	8000	rpm
Supply voltage	6	16	V

Chapter 8 Service and Maintenance

一、Service Precautions

Take care when check or repair vehicle to prevent person injury or damage.

Read and comply following general precautions when service vehicle:

- Turn off engine and let engine cool down when engine is hot.
- Use car stand when work under vehicle. Do work under vehicle when a jack supports vehicle.
- Fireworks, flame and electricity spark should be far away from battery, all parts related with fluid to avoid sudden accident.
- Do not reverse battery poles when connecting.
- Take care to avoid short on vehicle battery, ignition wiring or high load current or voltage.
- Keep good ventilation when work in closed condition as auto repairing workshop (especially when engine is running).
- Avoid children touching used oil, coolant and other fluid.

二、Engine oil checking procedures

Ensure engine oil at specified level and right lubrication. Inspect oil level because oil will consume when engine runs. Vehicle must be stopped at level surface when checking. Wait several minutes when checking oil level ensuring oil return oil pan. If engine is cold, it will take a long time for oil returning.

Checking Oil Level: remove oil dipstick and clean with discottony cloth, then insert dipstick to full. Remove dipstick and inspect if oil is between MIN and MAX scale.



Check if dipstick is dirty.

If oil level is under MIN scale, add oil to ensure oil level reaches MAX scale. Oil should not surpass MAX scale, otherwise oil consumption will increase which will foul spark park and cause carbon deposit.



When add oil, use same brand and grade oil with previous.

! Notice

Avoid frequent touch with engine oil; otherwise skin illness will be caused. Clean thoroughly after touching oil. Used oil should be kept away from children. Inadequate and over oil will cause engine damage. Inspect engine oil timely and frequently. Add oil as necessary. DO NOT over add engine oil.

三、Oil and oil filter change

For engine damage caused by inadequate oil, manufacturer does not effect warranty.

Replacing engine oil and oil filter

Replace engine oil upon time and mileage interval because oil may also deteriorate with time besides engine running.

Under special conditions as frequent cold starting and on-off switching in municipal road surface, engine oil and oil filter replacing interval shall shorten accordingly (comparing with recommended service schedule)

Replace oil filter when replace oil.



Service Interval	Capacity
5,000km or 6 months (3,000 km or 3 months under poor conditions)	SQR372: 2.9L (including oil filter)

Bad Conditions:

- Most driving distance less than 3,000km.
- Ambient temperature always under zero centigrade degree, and most driving distances less than 3,000 km.

- Frequent long-time idle running and/or driving at low speed (such as frequent ON-OFF switching)
- Driving under dusty area.

! Notice

Used oil and container is harmful to health and environment. DO NOT dispose used oil as normal waste. Dispose should be accordant to Chery Sedan Special Service Station (CSSS) or local safety disposal unit.

四、Coolant Level

Cooling system shall be filled with glycol coolant. Under normal concentration, coolant supplies good antiseptis and antifreeze protection, therefore common water cannot be used to replace coolant even in summer season.



When engine is cold, coolant shall be within MAX and MIN scale on expansion tank. Level rises with engine temperature increasing and falls with engine cooling. If coolant level is under MIN scale, add anti-freezing mixture of 50% water and 50% glycol to improve anti-freezing and antiseptis performance.

	Coolant Concentration	
	Antifreeze	Water
General Area	50%	50%
Cold Area	60%	40%

Replacing Coolant

Service Interval	Capacity
40,000 kM or every 2 years	SQR372: 3.8L



! Notice

Boiling coolant and vapor may eject under pressure, which may cause serious injury. Do not open coolant expansion tank lid when engine and water is hot. Antifreeze in engine coolant may hurt skin and eyes. Therefore necessary measures must be taken for avoiding antifreeze touch with eyes and skin. If coolant touches skin or eyes, wash with adequate water. If pain does not disappear, see a doctor in time. Antifreeze content in coolant is not over than 60% and not less than 50%. Do not use alcohol or methanol or mix them with specified coolant. In coolant mixture, do use soften water, do not mix over coolant. If needs frequent adding, contact nearest CSSS. Check cooling system. USE antifreeze and coolant specified by Chery Sedan Company.

五、Engine Overheating

If engine water temperature gauge indicates high readings or other reasons is doubted for causing engine overheating, stop vehicle and check.

Turn off A/C, let engine idle for several minutes. Check if cooling fan operates.

If cooling fan does not operate, turn off ignition switch, and ask for help from CSSS.

If cooling fan operates, but no hot vapor occurs, open engine hood, let engine idle till cooling down.

If cooling fan operates but temperature keeps high, turn off engine and let engine cool down, then check coolant level. If coolant level falls, check if water tank hose, connecting hose, water tank and pump leak.

If any leakage is detected, do not run engine. Contact and declare to the nearest CSSS.

! Notice

Vapor from overheated engine may hurt skin. Keep anybody away from such high temperature vapor. Turn off engine and let engine cool down. After vapor disappear, open engine hood.

SPECIAL NOTICE:

DO NOT open coolant expansion tank before cooling system cooling down to avoid person hurt.

六、Spark Plug

Check spark plug as specified schedule. If heavy carbon deposit exists on spark plug, strong spark cannot generate which will cause inadequate engine power. Clean carbon deposit on spark plug. Use brush to clean electrode, then raze carbon on insulation with small file. Then blow using compressed air. Upper insulation must be cleaned. Adjust spark plug clearance (standard clearance is 0.7 mm-0.9 mm).

Service Interval
Every 3,000 km or 18 months, replace.

Replacing Spark Plug

- Clean dust on spark plug seat.
 - Remove high tension wire, then remove spark plug using spark plug wrench.
 - Install new or cleaned spark plug using hand force, rotate spark plug clockwise for several turns. If spark plug cannot be smoothly rotated, remove it and try again. Ensure proper engage between plug thread and cylinder head thread.
 - Tighten spark plug to specified torque using spark plug wrench (standard torque: 25 N. m).
- Connect high-tension wire using right sequence.

! Notice


If engine spark plugs are installed improperly or spark plugs of wrong brand are installed, stumble engine operating may be caused, and even engine components may be damaged. To prevent engine or other components damaging, follow below items:

1. Spark plug must be tightened to specified torque. Spark plug cannot be over tightened, otherwise cylinder body threads may be damaged;
2. Align spark plug with hole when removing or tightening.
3. When install spark plug, tighten using hand force first.
4. Pull the sleeve when install spark wiring, do not pull spark plug.
5. Do no use spark plug of other brand.
6. Do not foul spark plug hole.
7. Use cares to avoid accidental burning when remove spark plug while engine is at high temperature.

! Notice

DO NOT run engine when checking belt, otherwise moving parts will be pressed,

七、Drive Belt




Install belt properly and ensure appropriate belt tension, otherwise generator, A/C and other system operating may be affected. If drive belt is worn, cracked or swelled, replace it.

Check belt tension: apply appropriate thumb pressure at the middle and measure if belt displacement is about 10mm. If belt is too loose, adjust and repair.



Chery Engine Company
Add. : No. 8, Changchun Road, Wuhu City, Anhui Province, P. R. China
FAX: 0553-5923747
Tel. : 0553-5923068
Website: www.cheryacteco.com
CEC-SD-025
First edition 2008-11-13

WIRING DIAGRAM FOR LH800ATV-U AUS MODEL



Note	Colour
B	Black
Y	Yellow
P	Pink
R	Red
Br	Brown
W	White
Bl	Blue
G	Green
LB	light blue
G/Bl	Green/Blue
G/W	Green/White
Y/R	Yellow/Red
B/W	Black/White
Br/W	Brown/White
G/R	Green/Red
G/Y	Green/Yellow
B/R	Black/Red
Pu	Purple
B/Y	Black/Yellow
Br/R	Brown/Red
Gr	Gray
Br/B	Brown/Black
R/W	Red/White
Gr/B	Gray/Black
Bl/R	Blue/Red
LG	Light green
DBr	Deep Brown

EMISSION CONTROL SYSTEM WARRANTY

This All-Terrain Vehicle (ATV) emissions limited warranty is in addition to the Massimo Motor Sports LLC standard limited warranty for All-Terrain Vehicles.

Massimo Motor Sports LLC warrants that this vehicle is: (1) designed, built, and equipped to conform at the time of initial sale with the requirements of 40 CFR 1051.120 (b). And, (2) free from defects in materials and workmanship that may keep it from meeting these requirements.

The emissions warranty period for this vehicle begins on the date the vehicle is delivered to the original retail purchaser, vehicles with displacement of 976 cc and (under), warranty period shall be 2 ½ years or 5,000 km, whichever comes first.

This emission - related warranty covers components whose failure would increase an engine's emissions, including electronic controls, fuel injection, exhaust-gas recirculation, after treatment, or any other system utilized in this vehicle to

control emissions. Replacing or repairing other components not covered by this emissions warranty or the standard warranty is the responsibility of the owner; including the parts, labor and other costs associated with recommended maintenance.

The exclusive remedy for breach of this limited warranty shall be, at the exclusive option of Massimo Motor Sports LLC, repair or replacement of any defective materials, components or products.

THE REMEDIES SET FORTH IN THIS LIMITED WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON FOR BREACH OF THIS WARRANTY. MASSIMO MOTOR SPORTS SHALL HAVE NO LIABILITY TO ANY PERSON FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY DESCRIPTION, WHETHER ARISING OUT OF EXPRESS OR IMPLIED WARRANTY OR ANY OTHER CONTRACT, NEGLIGENCE OR OTHER TORT OR OTHERWISE.

ALL IMPLIED WARRANTIES (INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO THE WARRANTY PERIOD DESCRIBED HEREIN. MASSIMO MOTOR SPORTS LLC DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED IN THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply if it is inconsistent with the controlling state law.

This limited warranty excludes failures not caused by a defect in material or workmanship. This limited warranty does not cover damage due to accidents, abuse or improper handling, maintenance or use. This limited warranty also does not cover any engine that has been structurally altered, or any engine that has been used in racing competition. This limited warranty also does not cover physical damage, corrosion or

defects caused by fire, explosions to other similar causes beyond the control of Massimo Motor Sports LLC.

If you have any questions regarding your warranty rights and responsibilities, you should contact the Massimo Motor Sports LLC Warranty Department at 877-881-6376.

OWNER'S/OPERATOR'S MANUAL *USA* 25.0

PN.F010229U29

T-BOSS 900L

⚠ WARNING

Improper Use of Off-Highway Vehicles Can Cause Severe Injury or Death

Be Prepared

- Fasten seat belts.
- Wear an approved helmet and protective gear.
- Reserved for message about other occupant restraint devices.
- Each rider must be able to sit with back against seat, feet flat on floor and foot rests and hands on steering wheel or handhold where equipped. Stay completely inside the vehicle.



Drive Responsibly

- Avoid loss of control and rollovers:
- Avoid abrupt maneuvers, sideways sliding, skidding, or fishtailing, and never do donuts.
- Slow down before entering a turn.
- Avoid hard acceleration when turning, even from a stop.
- Plan for hills, rough terrain, ruts, and other changes in traction and terrain. Avoid paved surfaces.
- Avoid side hilling (riding across slopes).



Rollovers have caused severe injuries and death, even on flat, open areas.

Be Sure Riders Pay Attention and Plan Ahead
If you think or feel the vehicle may tip or roll, reduce your risk to injury:

- Keep a firm grip on the steering wheel or handholds and brace yourself.
- Do not put any part of your body outside of the vehicle for any reason.

Require Proper Use of Your Vehicle

- Do your part to prevent injuries :
- Do not allow careless or reckless driving.
- Make sure operators are 16 or older with a valid driver's license .
- Do not let people drive or ride after using alcohol or drugs.
- Do not allow operation on public roads (unless designated for off-highway vehicle access)-collision with cars and trucks can occur .
- Do not exceed seating capacity; three passengers.



LOCATE AND READ THE OWNER'S MANUAL FOLLOW ALL INSTRUCTION AND WARNINGS

RESERVED FOR REFERENCE TO OTHER SOURCE OF SAFETY INFORMATION

1021111