

AWF Pro® Pro Foam Gun - OPERATING INSTRUCTIONS

For use with Canned Insulating Foam Sealant

STEP 1: CAN ATTACHMENT

Remove Foam Can Cap, Shake can vigorously for one minute
Screw Foam Can onto **Can Adapter**
You may hit a spot where you feel some resistance; keep turning
Until can is snug and you do not have gas or foam escaping.

STEP 2: APPLY FOAM

Turn **Regulator** knob clockwise to open flow.
Aim **Nozzle** at desired spot.
Squeeze **Trigger** to apply foam
Turn **Regulator** knob to adjust flow of foam
Release **Trigger** to stop flow.

When finished, turn **Regulator** knob counter clockwise to close flow.
Spray **Nozzle** with Foam cleaner. Wipe off excess foam.
Store gun with partially filled can attached.
It is not recommended to store gun with empty can or no can attached.

NOZZLE



CAN ADAPTER



REGULATOR



TRIGGER



STORING GUN WITHOUT CAN

Perform following procedures in well-ventilated area.
Unscrew & remove empty foam can.
Immediately attach Foam Gun cleaner to **Can Adapter**.
With **Regulator** knob open, squeeze **Trigger** until only cleaner is released from **Nozzle**.
Release **Trigger**, wait 20-30 seconds.
Repeat process 2-3 times. No foam should be seen.
Remove Can of cleaner from gun.
Spray outside surfaces, **Can Adapter** and **Nozzle** with cleaner.
Wipe off residue.

Follow all application, safety and disposal instructions on Foam Can. Wear proper safety attire: goggles, gloves and protective clothing

AWarehouseFull * 140 Central Avenue, Farmingdale, NJ 07727 * Tel (888) 223-3050 * customerservice@awarehousefull.com

AWF Pro® Pro Foam Gun - INSTRUCCIONES DE USO Para ser utilizado con Lata de Sellado de Espuma Aislante

PASO 1: ADJUNTAR LATA

Remueva la tapa de la lata de espuma. Agitar lata vigorosamente por un minuto.
Enroskar lata a el **adaptador de lata**.
Es posible que al enroskar llegue a un punto, donde se encuentre con resistencia, de ser así, continúe enroscando la lata hasta que este ajustado y no tenga gas o espuma escapando. No sobre apriete.

PASO 2: APLICACION DE ESPUMA

Gire la perilla del **regulador** hacia la derecha para cerrar el flujo.
Apunte la **boquilla** al lugar deseado.
Apriete el **gatillo** para aplicar espuma.
Gire la perilla del **regulador** para ajustar el flujo de la espuma.
Suelte el **gatillo** para parar el flujo

Cuando termine, gire la perilla del **regulador** hacia la izquierda para abrir el flujo.
Rosee la **boquilla** con limpiador de espuma. Limpie residuos de espuma.
Almacene la pistola con lata parcialmente llena adjunta.
No es recomendable almacenar pistola con lata vacía o sin lata adjunta.

BOQUILLA



ADAPTADOR DE



REGULADOR



GATILLO



ALMACENAMIENTO DE PISTOLA SIN LATA

Realice los siguientes pasos en un area con buena ventilación.
Desatornille y remueva la lata vacía.
Inmediatamente, adjunte la lata de limpiador de espuma al **adaptador de lata**
Con la perilla del **regulador** abierta, apriete el **gatillo** hasta que solo la solución del limpiador de espuma salga por la **boquilla**.
Suelte el **gatillo** y espere de 20-30 segundos.
Repita el proceso 2-3 veces, o hasta que no haya espuma visible.
Remueva la lata de limpiador de espuma de la pistola.
Rosee superficies externas, **adaptador de lata** y **boquilla** con limpiador.

Siga las instrucciones de seguridad y eliminación apropiadas, impresas en la lata de espuma. Utilice vestimenta de seguridad adecuada: lentes, guantes y ropa de protección

AWarehouseFull * 140 Central Avenue, Farmingdale, NJ 07727 * Tel (888) 223-3050 * customerservice@awarehousefull.com