OPERATING TIPS

1. Start the cordless snow shovel. Push the shovel forward at a comfortable forward speed, and slow enough to clear the path completely. The clearing width of the snow shovel and the depth of snowfall should dictate your forward speed.
2. Direct the snow discharge to the right or to the left by adjusting the snow throwing angle.
3. To remove snow most efficiently, throw the snow downwind and slightly overlap each swath.
4. When clearing deeper drifts, hold the cordless snow shovel by the upper and lower handles and use a swinging or sweeping motion. Remove up to 6"/16cm.
5. Remove the battery after using the cordless snow shovel. Hang the shovel so it will not be misplaced or damaged.

MAINTENANCE AND STORAGE

1. Check all fasteners at frequent intervals for proper tightness to ensure that the equipment is In safe working condition.
2. Always refer to the operators' manual for important details, such as how to properly store your cordless snow shovel for an extended period of time.
3. Maintain or replace safety and instruction labels as needed.
4. Run the machine a few minutes after throwing snow to prevent the rotor blades from freezing.

WARRANTY

Twelve (12) months for workmanship of the product, except for wearing parts. Warranty period starts from the product purchase date.
Warranty covers material quality and workmanship only.
Warranty does not cover product for issues caused by improper usage or any operation not in accordance with the specifications of this manual. Any modification or tampering with the product in any way voids the warranty.