ASSEMBLY INSTRUCTIONS

1. Remove all the parts from carton.
2. Unscrew the cover for the battery compartment and insert 3 AA batteries (not included) into the battery compartment. Align "+" and "-" as marked inside the battery compartment.
3. Screw the battery compartment cover tightly closed.
4. Move the switch to "ON" position to turn on the lights.
5. Move the switch to the "OFF" position to turn off the lights.

DO NOT CONNECT THE POWER SUPPLY TO THE DECOR WHILE IN PACKAGING.

TROUBLESHOOTING

If the product does not light:

1. Make sure batteries are inserted correctly. Make sure to align the "+" and "-" as marked inside the battery compartment.
2. Switch is in "OFF" position. Move the switch to the "ON" position.
3. Batteries are exhausted. Replace them with new batteries.

BATTERY INSTRUCTIONS:

1. Do not dispose of batteries into a fire. Batteries may explode or leak.
2. Do not mix old and new batteries.
3. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
4. Replace all batteries with the same brand and type.
5. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
6. Remove fully discharged batteries immediately.
7. Remove all the batteries for storage of the unit to avoid battery leakage.
8. Batteries should be recycled or disposed of as per state and local guidelines.

SAVE THESE INSTRUCTIONS!