Congratulations on purchasing this item. Your item has been carefully packaged for transit, however due to the nature of the materials used, some debris may appear in the bottom of the packaging or while unpacking. We have designed the item so its beauty will not be diminished by this.

Three AA type batteries are required for light function. Please open battery pack, insert batteries, and securely close pack.

MODE – 9 Functions

1) Combination
2) In wave
3) Sequential
4) Slo glo
5) Chasing/Flash
6) Slow fade
7) Twinkle/Flash
8) Steady on
9) OFF

Do not mix old and new batteries.

Do not mix alkaline, standard(carbon-zinc), or rechargeable(nickel-cadmium) batteries.

