IMPORTANT SAFETY INSTRUCTIONS:

- This product is intended for both indoor and outdoor use.
- Do not mount or place the product near gas or electric heaters, fireplaces, candles, or other heat sources.
- Do not cover the product with cloth, paper, or any material not included as part of the product while in use.
- Do not leave the product unattended when children are present. This product is not a toy.
- Set the timer or turn off the product before leaving the house, going to bed, or leaving it unattended.
- Never operate the product if the battery compartment is damaged.
- Do not use the product in extreme weather conditions unless specifically recommended.
- This product is not intended for permanent installation.

CARE AND MAINTENANCE:

Before using or reusing, inspect product carefully. Discard any product that has cut, damaged or frayed wire insulation or battery compartment. When not in use, store neatly in a cool, dry location protected from sunlight. Clean the product with a cloth before storing after season's use.

ASSEMBLY INSTRUCTIONS

1. Remove all the parts from carton including blow mold figurine and mounting hardware.





2. Drill a hole in the wall using a drill bit that is slightly smaller than the diameter of the rubber plug.
3. Insert the rubber plug into the hole. Then screw the screw into the plug, leaving approximately 1/4 inch exposed.

Inserting the batteries:

1. Unscrew the battery compartment cover.
2. Insert AA batteries (not included) into the battery compartment.
3. Align the "+" and "−" symbols as marked inside the compartment.
4. Securely tighten the battery compartment cover.

Operating Instructions:

1. Move the switch to the "ON" position to turn on the lights.
2. Move the switch to the "OFF" position to turn off the lights.
3. Move the switch to the "TIMER" position for automatic operation: 6 hours ON / 18 hours OFF.

TROUBLESHOOTING

If the product does not light:

1. Make sure the batteries are inserted correctly. Make sure to align the "+" and "-" as marked inside the battery compartment.
2. Switch is in "OFF" position. Move the switch to the "ON" position. Timer switch is activated and the item is in the off time.
3. Batteries are exhausted. Change to new batteries.

BATTERY INSTRUCTIONS:

1. Do not dispose of batteries into a fire as they may explode or leak.
 - Do not mix old and new batteries.
 - Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
 - Always replace batteries with the same type and brand.
 - Remove fully discharged batteries immediately.
2. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
3. Remove all the batteries for storage of the unit to avoid battery leakage.
4. Batteries should be recycled or disposed of as per state and local guidelines.