ITEM: HTK1700
SKU:89017

Gas Stove Installation Instruction

Thank you for choosing our gas stove! To ensure safe and normal operation of this product, please read this manual thoroughly before use.

1) Installation Instructions:

1. Check whether the gas type compatible with this stove matches your household gas supply.

2. Connect the gas hose to the stove's gas inlet and tighten the hose clamp. Make sure the stove control knob is in the OFF position, then use a soap solution to check all connections for leaks. (Leak detection by the soap bubble method.)

3. Keep the stove at least 1 meter (3.3 ft) away from the gas source. The rubber hose must not touch the stove body or pass underneath the stove.

4. Check whether the burner, gas inlet pipe, valve body, and other components have been damaged or deformed during transportation due to vibration or compression, as this may affect safe operation. If any damage is found, immediately contact your dealer or our company for assistance.

2) Safe Use and Precautions:

1. Before using the stove, make sure the gas type indicated on the rating plate matches your gas supply. Do not use the stove if the gas types do not match.

2. Ensure adequate ventilation during use. The kitchen should be equipped with a ventilation fan or range hood.

3. If you detect a gas leak or smell gas, immediately turn off the main gas supply. Open all doors and windows to ventilate the area naturally. Do not operate any electrical appliances or switches, as doing so may cause a gas explosion.

4. Keep all flammable and explosive materials away from the stove.

3) Cleaning and Maintenance:

1. Clean the stove regularly to keep it clean and in good condition.

2. Regularly clean the burner ports to prevent clogging.

3. Replace the gas hose at least once a year to prevent gas leaks caused by aging or cracking and to ensure safe operation.

4) Usage Method:









Special Attention:

A. The gas inlet is designed for a Ø9.5 mm hose connection. Product dimensions and weight are provided on the packaging.

B. Install and operate the stove only in a well-ventilated area.

C. Product specifications may vary by model. Please refer to the rating plate on the stove for the applicable technical information.

D. For models without an automatic ignition system, light a match or gas lighter before opening the gas valve to prevent gas accumulation, which may result in fire or explosion.

(1.1) Low-Pressure Valve Operation:

1. Light a match or gas lighter and place the flame near the burner ports. Slowly open the gas valve. Once the burner is lit, remove the ignition source.

2. When there is air in the intake pipe that leads to unsuccessful ignition, the above actions must be repeated, exhaust the air in the pipe before ignition can be started.

3. Air Adjustment: If the flame is unstable or lifts away from the burner, adjust the air shutter to reduce the air intake. The air shutter is typically located near the valve body and may be a metal plate or an adjustment screw, depending on the model. If the flame is yellow, increase the air intake by opening the air shutter. A properly adjusted flame should be steady and light blue.

4. To turn off the burner, simply close the gas valve completely.

（1.2）Medium pressure valve

1. When using an industrial or commercial LPG stove, use a medium-pressure gas regulator that is compatible with the appliance.

2. The operating procedure is the same as that for the low-pressure regulator. Please refer to **Section (1.1)**.

3. For high-output stoves, a 50 kg LPG cylinder is recommended. Avoid operating the stove continuously for extended periods, as prolonged use may reduce the vaporization rate of the LPG cylinder, resulting in poor combustion performance.

Notice

As part of our commitment to continuous product improvement, the product you receive may differ slightly from the illustrations or descriptions in this manual. However, the product's functions, installation procedures, and operating methods remain the same. We reserve the right to make changes without prior notice and apologize for any inconvenience.

Toll Free Number: 1-800-719-8199

Email: service@nuukusa.com