材质：157g铜版纸
尺寸：140X140MM
装订方式:骑形折
颜色:四色印刷

Petory

User Manual

Automatic Pet Feeder

Wi-Fi Pet Feeder

F01

Please read this manual careful before using.

IMPORTANT SAFETY INFORMATION

Thank you for choosing Petory F01 Pet Feeder. We hope this product will be useful and enjoyable for you and your pets.

WARNING

- Dispose of all packaging materials properly. Some items may be packed in plastic bags. These bags could be dangerous to children and animals if they suffocate.
- Do NOT allow small children to play with, or around the pet feeder.
- To reduce the risk of injury, please keep close supervision when an appliance is used near children.
- Do NOT use the pet feeder for anything other than its intended use. Misuse may cause injury.
- Do NOT immerse the base pet in water at any time as it may damage electronic components like the control panel.
- Do NOT place any foreign object in the pet feeder.
- Do NOT use substance, Etherr operation frequently to lose the unit is dissipating properly.
- Do NOT use wet, canned or moist food.
- Do NOT use accessories that are not recommended or sold by Petory in this User Guide.
- Do NOT use the pet feeder for anything other than its intended use.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do not modify the pet feeder.
- Do NOT use the pet feeder if the power cord or plug is damaged or if the pet feeder malfunctions or has been dropped, damaged, or left outdoor. Contact our customer service immediately for further instructions.
- Examine the feeder after installation. Do not plug in if there is water on the power cord or plug.
- To avoid tripping, always position power cord out of the way of foot traffic.

CAUTION

- Do NOT allow pets to chew on or swallow any parts. If you are concerned about the power cord, purchase a cord protector or hard plastic protection or any hardware store to protect the power cord.
- For extended use is necessary one unit with a power rating should be used.
- Do not place the pet feeder in direct sunlight or in extreme cold or high temperatures below 0°C/40°F, or less above 5 tolerance to power. Do NOT use rechargeable batteries.
- Check the batteries regularly. Before Leaving for extended time, always replace batteries with new ones, remove batteries if the pet feeder will not be used for a long time. Never buy LR1 and Sony Carbon batteries. Use alkaline keeping the unit in upright position.
- Suitable for dry food (Kibs), with shelle size ranging from 5-8mm(0.2)(0.31 in diameter. Larger kibbs may jam the food outlet.
- Do not put your fingers into the food outlet or let your fingers touch the kibs.
- Read and observe all important notices listed on the pet feeder and in the packaging.

Product Description

Product Specifications

Product Model	F01
Power	DC5V
Dimensions	L:320*W:197*H:334mm, 12kg
Food Container	Type:CUP,3.5liters
Capacity	4L(only dry food)
Programmable	1-10 portions, 15s per portion & meals per day

How to Install

1. Assemble the bowl, Plug in power adaptor, turn on the power switch.

2. Recommended to install batteries to ensure that the feeder works properly when the power is off.

3. Press inward at the same time to open the lids.

Operation Interface

Icon Quick Guide

Icon	Meaning
10:08	Current Time/Feeding Time/ Initial setting time is 10:08
5F 00	Slow feeding mode, The interval time per portion can be set from 0-59min
F - 00	Set the portion of each meal, up to 10 portions
1 2 3 4 5 6	Number of meals Setting mode: The slot flashing Feeding: The slot goes in sequence Not feeding: The slot flashes
	Set to 12 hour format
	Solid: Batteries installed / flashing: No batteries
	Red Light: Low battery
	Light up when all buttons are locked

Made in China
Version 1.0

If the power supplies by the adaptor only, the display will always be lit. If it's supported by 3*D batteries only without operation for 2 mins, the screen will turn off automatically. Press any button can enable it.

Button Quick Guide

Button	Description	Operating Mode Function
	Setting	Long press 2s to set current time, short press to set feeding parameters, long press set setting mode
	Next Step	Setting mode: short press to next step
	Recording	Standby: Long press=Play recording Long press+Record voice or cancel recording
	Down	Setting mode: Short press = Decrease value Long press = Decrease the value quickly
	Manual Feeding Up	Standby: Short press = Manual feeding Setting mode: Short press = Increase value Long press = Increase the value quickly
	Lock/Unlock	Press and hold for 2s at the same time to lock/unlock

The screen will be locked automatically without operation for 90 sec.

Quick Programming Guide

1. Ensure the panel is unlocked

Press and hold Lock/Unlock button for 2s, until you hear two beeps.

2). Voice recording and playback

Start voice recording

Long press Record button for 2s until you hear a "beep" and continue to hold while recording up to 10 seconds. Release the button when you hear a second beep to end recording.

Play the recording

Quickly press Record button to hear the recorded message.

Cancel recording

In standby, long press Record button, you will hear a "beep" sound and release immediately to cancel the recording.

3. Manual Feeding

Short Press the Up button, the feeder instantly release one portion, Repeat this step for 3 times to make sure the food is enough.

NOTE: If you will find the food level in the food container is less than the ex-out amount, and the Bigportion is available.

4. Set Current time

Long press Set button until the digits start flashing, Press Up or Down button to set the correct hour and then short press Set button, Repeat to set the minute. Long press Set button to exit setting.

Example: set current time to 08:10 AM

5. Slow Feed Setting

Short press Set button, enter feeding parameters setting, Press Up or Down button to set the interval time per portion, can be set from 0min-59min.

6. Meal Time Setting

Short press Set button, enter first meal setting, When "1" starts flashing, Press Up or Down button to adjust to the meal you need to set, If you just want to change 3rd meal only, Press Set button until "3" flashing, you can press Set button to set 3rd meal parameters.

Short press Set button to the time step, Short press Up or Down button to set feeding time.

7. Feeding Portion Setting

Once feeding time is set and saved, the feeder will switch to portion mode, the screen will display "F-01" (1st for the number of 10g increments).
(For a 50g portion, choose F-5). Then press Set button and then press Up or Down button to adjust the portion.

8. Repeat for meals 2 through 6 (step press ⏎) to save once you set all meals.

Intelligent Detection Function

As shown, E-01 appears on the screen to indicate that the food outlet is blocked. Please clean the food outlet. Once, E-02 appears on the screen to indicate that the hopper is empty. You can adjust the sensitivity of the portions according to your pet's habits.

About Cleaning

(1). Open the lid and take out the desiccant.
(2). Remove the feeding bowl and empty the grain in the hopper.
(3). Pinch the hopper to separate the hopper from the base.

The base unit cannot be submerged in water.

Food bowl, stainless steel bowl, hopper and lid can be washed in the sink.

Warranty

We provide **1 year warranty** for this appliance, Please email our support team at **support@petory.net** if you have any questions and attach your order ID in your email, We will get back to you within 24 hours.

@PetoryStore
support@petory.net
Petory Official

Made in China

Scan to Download App

Please read this manual careful before using.