High Speed RC Race Car

Instruction Manual | **Item: TOY-RCRACER**

Please read this instruction manual carefully before using.

For Ages 6+

CONTENTS:

1 x High Speed RC Race Car
1 x 2.4GHZ Remote Control
1 x Rechargeable 500mAh, 3.7V Li-ion Battery
1 x USB-A Charging Cable





BATTERY INSTALLATION & CHARGING

Fully Charge your car's battery using ONLY the included USB-A charging cable.

Charging the Car Battery

1. Remove the rechargeable battery from the accessory bag.
2. Plug the battery wire connector on the battery pack into the wire connector on charging the cable.
3. Plug the other end of the charging cable into a USB port or an adapter to use an AC plug.
4. The red indicator light on the charging cable will light when charging.
5. When charging is complete the light will turn off.
6. Disconnect the battery wire connector from charging cable wire connector.
7. Locate and open the battery compartment on the underside of the car.
8. Loosen the screw and remove the compartment cover.
9. Connect the battery wire connector to the wire connector in the battery compartment.
10. Place battery into the compartment.
11. Replace the compartment cover and tighten screw until snug.

Installing Remote Control Batteries

1. Locate the battery compartment on the back of the remote control.
2. Loosen the screw and remove the battery compartment cover.
3. Insert 2 AA batteries according to the polarity graphic on the inside of the compartment.
4. Replace the cover and tighten the screw until snug.

OPERATION

1. Locate the power switch on the underside of the car and move it to the ON position.
2. The car and the remote control will link automatically when the car is turned ON.
3. Use the forward and reverse arrows on the left side of the remote control to move the car in the corresponding directions.
4. Use the right and left arrow buttons on the right side of the remote control to rotate the front axle in the corresponding direction.

Your High-Speed RC Race Car is capable of any number of spins, turns and other stunts. To do so, simply move your Race Car backwards and forwards while also pushing one of the buttons on the right side of the remote control that makes the front axle twist. Different combinations of pushing these buttons will create different tricks!

⚠ CARE, MAINTENANCE & SAFETY

- Wipe the product clean with a soft, dry cloth when needed.
- Store the product in a cool, dry place when not in use.
- Turn the product off when not in use to conserve battery life, if applicable.
- Keep the product away from heat sources, open flame, and direct prolonged sunlight.
- Do not use near water or in wet conditions unless specifically designed for water use.
- Do not modify, disassemble, or otherwise alter the product.
- Discontinue use if the product becomes damaged, overheats, or malfunctions.
- Keep fingers, hair, loose clothing, and small objects away from moving parts, where applicable.
- Adult supervision is recommended during setup, charging, and battery installation, where applicable.
- Use only the included or recommended accessories and charging components, where applicable.
- Follow all operating instructions before use.
- Keep packaging materials away from children and dispose of properly.
- Not suitable for children under the recommended age listed on packaging.

BATTERY SAFETY

- Insert batteries according to the correct polarity (+ / –).
- Do not mix old and new batteries.
- Do not mix different types of batteries (alkaline, standard carbon-zinc, or rechargeable).
- Use only the recommended battery type specified for the product.
- Remove exhausted batteries promptly.
- Remove batteries if the product will not be used for an extended period, where applicable.
- Rechargeable batteries should only be charged under adult supervision.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit battery terminals.
- Do not dispose of batteries in fire.
- Recycle or dispose of batteries properly according to local regulations.

FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."
Instruction manual shall include,
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

FCC Radiation Exposure Statement:The device has been evaluated to meet general RF exposure requirement.The device can be used in the portable exposure condition without restriction.

30 DAYS LIMITED WARRANTY:

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.
During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorization Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorization Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

Flipo Group
613 First Street
La Salle, IL 61301

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Manufactured by Flipo Group Limited La Salle, IL
Questions or Comments? Call: (815) 223-9942 • Email: info@flipo.com
MADE IN CHINA