



# TERMINALS

## MALE & FEMALE DISCONNECTS

ITEM #	AWG	SIZE SPEC	MATERIAL	QTY/PACK	PACKS/CASE	COLOR
TFDP-R187-B	22-16	0.187	PVC	1,000	10	Red
TFDP-R25-B	22-16	0.25	PVC	1,000	10	Red
T13725 / TFDP-B25	16-14	0.25	PVC	20	120	Blue
TFDP-B187-B	16-14	0.187	PVC	1,000	10	Blue
TFDP-B25-B	16-14	0.25	PVC	1,000	10	Blue
TFDP-Y25-B	12-10	0.25	PVC	1,000	10	Yellow
TFDP-Y375-B	12-10	0.375	PVC	1,000	10	Yellow
T12844 /	TFDP-R25	22-16	PVC	6	120	Red
	TFDP-B25	16-14		6		Blue
	TFDP-Y25	12-10		6		Yellow
TMDP-R187-B	22-16	0.187	PVC	500	20	Red
TMDP-R25-B	22-16	0.25	PVC	500	20	Red
TMDP-B187-B	16-14	0.187	PVC	500	20	Blue
T13749 / TMDP-B25	16-14	0.25	PVC	20	120	Blue
TMDP-B25-B	16-14	0.25	PVC	500	20	Blue
TMDP-Y25-B	12-10	0.25	PVC	500	20	Yellow
T13736 /	TMDP-R25	22-18	PVC	2	120	Red (M)
	TFDP-R25	22-18		2		Red (F)
	TMDP-B25	16-14		4		Blue (M)
	TFDP-B25	16-14		6		Blue (F)
	TMDP-Y25	12-10		2		Yellow (M)
	TFDP-Y25	12-10		2		Yellow (F)

### Installation Instructions

- 1) Strip wire insulation 1/4"
  - 2) Insert stripped wire into terminal
  - 3) Crimp tightly using crimping tool
- Stranded copper wire only

### PVC Insulation

600V  
75°C

### UL Listed

**premium.  
industrial.  
products.**