

30,000 LB RECOVERY STRAP WITH LOOP ENDS

INSTALLATION INSTRUCTIONS

⚠ WARNING: Read and observe all warnings, instructions, and capacity limitations before using this product. Failure to comply with this warning and the associated instructions and capacity limitations may result in serious personal injury and/or significant property damage.

INSTRUCTIONS:

1. Select a Recovery Strap with a Minimum Break Strength roughly 3 times the weight of your stuck vehicle.
2. Choose a suitable place of to attach the Recovery Strap end loop onto the towing vehicle. Frame mounted tow loops, hooks or a towing hitch are best. These should be of sufficient strength to hold the load while in use.
3. Attach other end of the Recovery Strap to the vehicle needing towing. Ideal places to attach Recovery Straps are designated towing points such as tow hooks or tow loops that are of sufficient strength to hold the load while in use. If not available find a part of frame that will not interfere with the wheels, axles, steering and suspension systems, etc. You can also refer to vehicle service manual for recommended points.
4. Clear away any debris, ice or snow that may be restricting free wheel movement of stuck vehicle.
5. To start the recovery process, drivers should be in both vehicles.
6. The stuck vehicle should be in neutral.
7. Start by moving towing vehicle away slowly to pick up slack in the Recovery Strap. The Recovery Strap should be taught to start the process and as much as possible during the entire recovery.
8. As the stuck vehicle begins to free, the driver should begin to steer the vehicle to safety.
9. When towing is complete, inspect Recovery Strap for signs of wear and tear, and safely store in dark dry place.



IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR SMARTSTRAPS PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9218 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT SMARTSTRAPS.COM.