

Note: Do not set concrete in the corners until the entire greenhouse frame is complete. You may need some play to install the uprights.