Installation Instructions Jeep Liberty				t Numbers: 51054	
		Do Not Exceed Lower of Towing Vehicle Manufacturer's Rating or			
Fascia	Hitch typ		lax Gross ler WT (LB)	Max Tongue WT (LB)	
	Weight Distrib	uting 7500) (3405 Kg)	750 (341 Kg)	
Hitch Shown In Proper Position	Weight Carry Ball Mour) (2270 Kg)	500 (227 Kg)	
Equipment Required: Wiring Access Location: SUV1, SUV2					
Fastener Kit: F51054 Wrenches: 18mm, 19mm Drill Bits: None Fuel tank skid shiel Existing weldnuts in vehicle frame (3) places each side Update and side frame (3) places of the skid shiel Update and side frame (3) places of the skid shiel Update and side Update and side					
Note: Fasteners typical both sides					
① Qty. (6) Hex Bolt M12 X 1.75 X 40	② Qty. (6)	Conical Washer 1	/2		
 If vehicle is equipped with a fuel tank skid shield, remove six (6) M12 fasteners holding skid shield to vehicle frame rails and discard bolts. Raise hitch into position and install fasteners as shown above. Fuel tank skid shield will be sandwiched between hitch and vehicle frame rails. 					
Tighten all M12 CL8.8 fas Note: check hitch frequently, making sure all fasteners and ball are p prevent entry of water and exhaust fumes. A hitch or ball which has beneath a vehicle and wear eye protection. Do not cut access or atta This product complies with safety specifications and requirements f and SAE J684.	properly tightened. If hitch been damaged should be re chment holes with a torch.	is removed, plug all hole moved and replaced. Of	s in trunk pan or other oserve safety precaution		
© 2001, 2002, 2003, 2004, 2006, 2009 Cequent Performance Products	Sheet 1 of 1	N51054	10-16-09	Rev. C	