



LAWN PRO™ LAWN MOWER HI-HITCH MODEL: LNPHH650

⚠ WARNING

READ ALL INSTRUCTIONS BEFORE USING THE LAWN PRO LAWN MOWER HI-HITCH
NOTE: DO NOT EXCEED TRAILER CAPACITY OF LAWN MOWER. FAILURE TO READ INSTRUCTIONS COULD RESULT IN INJURY OR DEATH.

Instructions for Installation and Use:



FIG. 1

CONTENTS-SEE FIG. 1

- 1- HI-HITCH BODY
- 4- BRACE ARMS (ONLY 1 SET WILL BE USED)
- 1- 5/8" LOCKNUT
- 2- 5/8" FLAT WASHERS
- 1- 5/8" X 2 1/2" BOLT
- 1- 1/4" X 2 3/4" BOLT
- 2- 1/4" X 1" BOLTS
- 6- FLAT WASHERS
- 3- 1/4" LOCK NUTS

****NOTE**** 2- FLAT WASHERS & 1- 1/4" X 2 1/2" BOLT ARE SHOWN IN FIGURE 1 ATTACHING 2 OF THE BRACES TO THE HI-HITCH BODY. ****2- 5/8" FLAT WASHERS ARE NOT PICTURED. ****

****NOTE**** THE LNPHH650 WILL ACCEPT TRAILER BALLS WITH A 3/4" SHANK OR SMALLER.

STEP 1-

ATTACH BRACE ARMS TO HI-HITCH BODY USING 1/4" X 2 3/4" BOLT, FLAT WASHERS AND LOCK NUT. TIGHTEN UNTIL SLIGHTLY SNUG. BRACE ARMS SHOULD BE ABLE TO PIVOT.

STEP 2-

CONNECT HI-HITCH BODY TO LAWN MOWER TRAILER MOUNTING HOLE WITH 5/8" X 2 1/2" BOLT, FLAT WASHERS AND LOCK NUT. TIGHTEN ONLY UNTIL SNUG. HI-HITCH SHOULD BE ABLE TO PIVOT SIDE TO SIDE.

STEP 3-

POSITION BRACE ARMS AGAINST BACK OF LAWN MOWER AND MARK FOR DRILLING. SWING BRACE ARMS OUT OF THE WAY. DRILL MARKED HOLES WITH A 5/16" DRILL BIT. ****NOTE**** MAKE SURE THERE ARE NO OBSTRUCTIONS BEHIND BACK PLATE OF LAWN MOWER BEFORE DRILLING.

STEP 4-SEE FIGURE 5

ALIGN HOLES IN BRACE ARMS WITH DRILLED HOLES IN LAWN MOWER AND FASTEN WITH THE 1/4"X" 1" BOLTS, FLAT WASHERS & LOCK NUTS. TIGHTEN SECURELY.

**STEP 5-**

TIGHTEN REMAINING HARDWARE SECURELY.

⚠ WARNING

NEVER EXCEED THE TRAILER CAPACITY OF THE LAWN MOWER.

⚠ WARNING

PLEASE READ ALL INSTRUCTIONS & WARNINGS INCLUDED WITH THIS PRODUCT.

For more information about this or other products, contact us at:

Great Day, Inc.

604 Kimbrough Dr. * Tallulah, LA 71282 * (866) 649-1918 * www.greatdayinc.com