



ATV /UTV Powerloader & PLUT1; PLUT-G Adapter Seller Sheet

Powerloader Model# PL250

- The Powerloader must have a winch installed in the front winchplate mounting area in order to function properly as the Powerloader itself is powered by the winch.
- Any ATV must have front metal rack or front metal brush guard for fitment. (ATV w/ front plastic front rack must have a front metal Grill guard for mounting)
- Notes for fitment to UTV: The PLUT-1 Adapter Bracket is needed to mount the Powerloader to the front Of most UTV's. Applicable models include: Polaris Ranger; Mule FXT; Yamaha Viking; Defender
- The PLUT-G Adapter Bracket is needed to mount the Powerloader to the front of the John Deere Gator UTV. (The Gator UTV must have a front brush guard for mounting to)

Power loader (PL250) Installed on an ATV



PL250 & PLUT-1 Installed On a UTV



PLUT1 Adapter Bracket (only) below for Ranger



PLUT-G Adapter Bracket (only) For Gator UTV

