

SETTING UP YOUR SMALL OVEREZ WIRE CHICKEN COOP PANELS

You will need a drill to install these panels

You will notice that each panel is about a half inch less in height than the chicken coop legs. This is to allow for easy installation should there be any obstacles or uneven ground. You may want to fill in the spaces between the panels and the ground with dirt or gravel.

STEP 1:



Install front and back panel first. These panels have excess wire, which goes towards the chicken coop door gable. (The excess wire sticks out past the chicken coop to tie into the chicken run)

Place the panel against the chicken coop legs on the outside. (Make sure to divide them between the 2 legs. Should be even on both sides). Then fasten the panels into the chicken coop with pre-started screws.

STEP 2:



Install the man door gable panel.

Repeat step 1 except this panel will be even with the outside of the front and back panel.

STEP 3:



(Optional)

If you attach a chicken run to the chicken coop, remove the bottom panel of the chicken run to open it to the underside of the chicken coop. After chicken run is placed, wire tie the excess wire to the chicken run.

NOTE: If you purchased the OverEZ Chicken Coop Wheels, you will need to remove the front and back panels in order to operate the wheels. See OverEZ Chicken Coop Wheels Instructions for information on how to remove the wheels.

*for more information about
all our products visit:*

www.OverEZchickencoop.com

