



## B-WDK • XPOWER WALL DRYING KIT

The wall drying kit includes:

- (A) Adapter (1pc)
- (B) 100 feet hose (1pc)
- (C) 8 inch short hose for blocking connector hole (3pcs)



(A)



(B)



(C)



- 1) Connect the adapter to the air outlet of XPOWER 2-IN-1 Forced air pet dryer.



- 2) Cut the hose to the desired length and then attach the hoses into the connector of adapter.



- 3) Fold short hoses to block the available connector holes in less hoses needed.  
(Warning: The blocking holes must be no more than 6 pcs to prevent motor from overheating.)



- 4) Insert the hoses inside walls or under cabinets.

---

XPOWER MANUFACTURE, INC. • 220 CLARY AVENUE, SAN GABRIEL, CA 91776

**[www.xpower.ws](http://www.xpower.ws)**

PHONE: (626) 285-3301 • FAX: (626) 285-3302

EMAIL: [info@xpower.ws](mailto:info@xpower.ws)