

# HOW TO MEASURE FOR YOUR FREEZEPRO® WRAP

Selecting the right size FreezePro® Wrap for your equipment is a lot easier than you might think. All you need is a tape measure, and you are ready to go!

CLICK HERE FOR VIDEO TUTORIAL: HOW TO MEASURE FREEZEPRO® WRAP

**WARNING:** When installing or measuring for FreezePro® Wrap, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

# 1. MEASURE FOR EITHER THE (1) CIRCUMFERENCE OR (2) DIAMETER:



<u>OR</u>



DIAMETER

**NOTE:** It does not matter which method of measurement you decide to use. Just remember that you only need to find your measurement using one of the two ways described above.

#### 2. MEASURE FOR THE DESIRED WIDTH:



**WIDTH** 

**NOTE:** After finding either the circumference or diameter, measure for the desired width to determine the width measurement of the application you want to insulate.

3.31.16



# 3. FIND THE RIGHT FREEZEPRO® WRAP:

The CIRCUMFERENCE (length) is 20in and the desired width is 12in = FPW 3012.

**FOR EXAMPLE:** 

<u>OR</u>

The DIAMETER (length) is 6in and the desired width is 12in = FPW 3012.

# **WIDTH**

| CIRCUMFERENCE                       | DIAMETER                        | <b>6in</b><br>(152mm) | 12in<br>(305mm) | 18in<br>(457mm) | <b>24in</b><br>(610mm) |
|-------------------------------------|---------------------------------|-----------------------|-----------------|-----------------|------------------------|
| 0in - 6in<br>(0mm-152mm)            | <b>0in-2in</b><br>(0mm-51mm)    | FPW 1206              | FPW 1212        | FPW 1218        | FPW 1224               |
| 6in-13in<br>(152mm-330mm)           | <b>2in-4in</b><br>(51mm-102mm)  | FPW 1806              | FPW 1812        | FPW 1818        | FPW 1824               |
| 13in-19in<br>(330mm-483mm)          | <b>4in-6in</b><br>(102mm-152mm) | FPW 2406              | FPW 2412        | FPW 2418        | FPW 2424               |
| 19in-25in<br>(483mm-635mm)          | 6in-8in<br>(152mm-203mm)        | FPW 3006              | FPW 3012        | FPW 3018        | FPW 3024               |
| <b>25in-31in</b><br>(635mm-787mm)   | 8in-10in<br>(203mm-254mm)       | FPW 3606              | FPW 3612        | FPW 3618        | FPW 3624               |
| 31in-38in<br>(787mm-965mm)          | 10in-12in<br>(254mm-305mm)      | FPW 4206              | FPW 4212        | FPW 4218        | FPW 4224               |
| <b>38in-44in</b><br>(965mm-1118mm)  | 12in-14in<br>(305mm-356mm)      | FPW 4806              | FPW 4812        | FPW 4818        | FPW 4824               |
| <b>44in-53in</b><br>(1118mm-1346mm) | 14in-17in<br>(356mm-432mm)      | FPW 6006              | FPW 6012        | FPW 6018        | FPW 6024               |

**NOTE:** Now that you have your measurements, you can use the graph above to help you find the appropriate FreezePro® Wrap part number. Diameter and circumference (length) measurements are listed in the table rows vertically (Y axis) and width measurements are listed in the column rows horizontally (X axis).

CLICK HERE FOR VIDEO TUTORIAL: HOW TO INSTALL FREEZEPRO® WRAP

3.31.16