

Don't let a flat ruin your day!

When man invented the wheel, I don't think he intended it to flat so often! But it never fails that you enter the garage only to find your trusty bicycle tires have gone flat. Fortunately, man also invented the solution. Slime up your bike tires before hitting the road and make flat tires a thing of the past.

HOW MUCH PER TIRE?

www.slime.com/calculator



- Instantly Seals Tread Area Punctures Up to 1/8" (3mm) in Size
- Works Continuously for 2 Years
- Compatible with Schrader and Removable Presta Valves
- Works in Extreme Temperatures
- Non-Flammable & Non-Toxic
- Cleans Up with Water

HOW DO I INSTALL SLIME?



1 Position valve in upper half of tire.



2 Slowly remove valve core with tool in cap.



3 Allow tire to fully deflate.



4 Remove object (if possible).



5 Attach hose and squeeze in Slime.



6 Reinstall valve core.



7 Just add air.



8 Spin tire to distribute sealant.

FIRRO-SEAL® TECHNOLOGY is our patented formula to plug punctures and stop air loss.

WARNING: Not recommended on passenger vehicles. Use Slime Emergency Flat Tire Repair sealant for passenger vehicles. Eye protection must be worn during installation. Inspect tires regularly for perforating objects and punctures. **Slime will not seal punctures outside the tread area.** Keep out of reach of children.

WARRANTY INFORMATION
www.slime.com/warranty
U.S. Patent # 7,388,041

ITW GLOBAL TIRE REPAIR
125 Venture Drive, Suite 210,
San Luis Obispo, CA 93401 USA
WWW.SLIME.COM

