

ASSEMBLY INSTRUCTION

ITEM# CVAP1990

1. Remove lamp parts from carton.
2. Remove plastic covering from lamp parts.
3. Place lamp body (A) upright on stable working surface.
4. Pull the cord from the bottom of lamp base, screw the (B) until touched top of lamp base.
5. Insert the (C) onto the saddle.
6. Unscrew the (E) from the (C), put the (D) onto the (C), then screw the (E) .
8. Screw the bulb into the socket.

NOTE: Turn the power off (unplug from electrical outlet) before replacing the bulb (E) , making sure the bulb has sufficient time to cool down. Do not subject the lamp to shock while lit as shattering of lamp may result.

