

PREMIUM SAFE ANCHORING KIT

INSTRUCTIONS:

- Place the safe in the desired location and use the shims to level.

Note: *The floor needs to be close to level as the leveling shims are intended to fine tune the leveling of your safe.*

- Use the holes in the bottom of your safe to mark the anchor locations.
- Use hammer drill and the included concrete bit to drill each hole at least 3" deep into the concrete floor. Follow all instructions for your particular hammer drill.

Note: *Use a minimum of two anchor bolts to secure your safe.*

- Insert the anchor bolts through the safe floor and into the drilled holes. A hammer may be needed to tap the anchor bolts into the holes.
- Tighten the nuts using a 3/8" drive socket wrench and the included socket until the anchors expand snugly into place.
- Use the included dusting cloth to keep your safe looking new for many years.

PREMIUM SAFE ANCHORING KIT

The Hornady Security® Premium Safe Anchoring Kit makes it easy to securely anchor your safe into concrete floors for maximum security.

INCLUDES:

- Four (4) 3/8" concrete anchor bolts, nuts, and washers
- One (1) 3/8" carbide concrete drill bit
- One (1) 9/16" deep socket
- Four (4) polymer leveling shims
- One (1) dusting cloth

TOOLS NEEDED:

- Hammer
- 3/8" Drive Socket Wrench
- Hammer Drill

Hornady Manufacturing Company
P.O. Box 1848
Grand Island, NE 68802-1848
HornadySecurity.com

Made in China.



01/2021

788067



WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov