

MODEL # RC169612PTRE


#### **DIMENSIONS**

16in. wide x 8ft. long x 11in. high

# PREMIUM CEDAR RAISED GARDEN BED WITH TRELLIS ASSEMBLY INSTRUCTIONS

Questions? Email info@greenesfence.com or call 800-622-5510 Monday - Friday 8am-5pm EST

#### **PACKAGE CONTENTS + (6) Screws**





Hold a 16in. Board on the ground so it's standing on edge with the notched ends to the left and right. Slide a Trellis Post down over one notched end of the Board. Next, slide another Trellis Post over the other notched end. This forms the Trellis wall.



- **BUILD TWO SHORT WALLS**Repeat Step One using Tall Posts to complete two more walls.
- BUILD A FRAME WITH TRELLIS ON ONE SIDE

  Place the Trellis wall and one short wall parallel to each other and connect them into a rectangle with two 4ft. Boards. This forms the frame of a 16in. x 4ft. Garden Bed with Trellis on one side.

## 4. DECIDE WHERE YOU WANT THE TRELLIS AND BUILD THE SECOND FRAME

The Trellis can go on either end of the Garden Bed, or in the center, depending on where you attach the second 16in. x 4ft. frame. Once you decide, place the other short wall from Step Two parallel to the correct wall and connect them into a rectangle with two more 4ft. Boards, completing a 16in. x 8ft. rectangle.



- FINISH GARDEN BED WALLS

  Add one more Board, one at a time, directly on top of each existing Board in the frame. Push the Boards down evenly between the tops of the Posts. If needed, tap snugly into place with a rubber mallet.
- BUILD THE TRELLIS

  Slide one Spacer into the top of each Trellis Post, then add one Slat on top of the Spacers and push them down directly on top of the existing wall.

  Repeat Step Six using all the Spacers and Slats to complete the Trellis.





### ATTACH DECORATIVE CAPS

When the Trellis is completed, attach each Decorative Cap to a Tall Post and Trellis Post with a screwdriver and Screw. We recommend drilling a pilot hole in each Cap first.



