

MODEL # RC164812PTRE DIMENSIONS 16in. wide x 4ft. long x 11in. high

PREMIUM CEDAR RAISED GARDEN BED WITH TRELLIS ASSEMBLY INSTRUCTIONS

Questions? Email info@greenesfence.com or call 800-622-5510 Monday - Friday 8am-5pm EST





BUILD THE TRELLIS WALL

Hold a 16in. Board on the ground so it's standing on edge with the notched ends to the left and right. Slide a Trellis Post down over one notched end of the Board. Next, slide another Trellis Post over the other notched end. This forms the Trellis wall.



BUILD A SHORT WALL

Repeat Step One using two Tall Posts to complete a second wall.



BUILD A FRAME

Place the walls parallel to each other and connect them into a rectangle with two 4ft. Boards. This forms the frame of a 4ft. x 4ft. Garden Bed with Trellis on one side.





5.

FINISH GARDEN BED WALLS

Add one more Board, one at a time, directly on top of each existing Board in the frame. Push the Boards down evenly between the tops of the Posts. If needed, tap snugly into place with a rubber mallet.

BUILD THE TRELLIS

Slide one Spacer into the top of each Trellis Post, then add one Slat on top of the Spacers and push them down directly on top of the existing wall. *Repeat Step Four using all the Spacers and Slats to complete the Trellis.*



6. ATTACH DECORATIVE CAPS

When the Trellis is completed, attach each Decorative Cap to a Tall Post and Trellis Post with a screwdriver and Screw. We recommend drilling a pilot hole in each Cap first.



INSTALLATION SUPPORT

youtube.com/greenesfence

NEED HELP? Contact customer service instead of returing item to store 800-622-5510 M-F 8-5

info@greenesfence.com



ATTACH DECORATIVE CAPS

When the Trellis is completed, attach each Decorative Cap to a Corner Post or Trellis Post with a screwdriver and Screw. We recommend drilling a pilot hole in each Cap first.





INSTALLATION SUPPORT

youtube.com/greenesfence

NEED HELP?

Contact customer service instead of returing item to store. 800-622-5510 M-F 8-5 info@greenesfence.com