

INSTALLATION INSTRUCTIONS

SB1034D, SB1034D6, SB1034D8

DSB40203D, DSB40203DMC, DSB41034D, DSB41034DMC

RB1034D, RB1034D6, RB1034D8

DRB0317D, DRB0317DMC, DRB1034D, DRB1034DMC

TOOLS NEEDED:

RATCHET	18MM SOCKET
1/2" COMBO WRENCH	1/2" SOCKET
GRINDER	

INSTALLATION INSTRUCTIONS:

1. USING 18MM SOCKET, REMOVE FRONT AND REAR CAB MOUNT BOLTS.
2. USING GRINDER, REMOVER SHOULDER ON BOLT RETAINING LARGE WASHER AND REMOVE WASHER FROM THE BOLT. **(THIS WILL HAVE TO BE DONE TO ALL 4 CAB MOUNT BOLTS)**
3. INSTALL RUNNING BOARDS USING CAB MOUNT BOLTS THROUGH THE BRACKET INTO CAB MOUNT AND TIGHTEN SECURELY.
4. INSERT PROVIDED TABS INTO INNER BODY PANEL AND TWIST ALLOWING TAB TO CATCH ON EACH SIDE OF BODY PANEL SLOT.
5. **SUPPORT BRACKET INSTALLATION:** DRIVER AND PASSENGER SIDE SHOWN BELOW.



DRIVERS SIDE



PASSENGER SIDE

6. WITH SUPPLIED HARDWARE, INSTALL SUPPORT BRACKETS WITH 90 DEGREE BEND ON THE WELDED STUD PROVIDED NEXT TO MOUNTING BRACKET AND TIGHTEN SECURELY.

7 BRACKETS MAY VARY IN SIZE AND SHAPE BY YEAR MODELS

THANK YOU FOR CHOOSING TOUGH COUNTRY PRODUCTS