

EMP P/N - 14475

KAWASAKI MULE PRO-MX

Hard Coated Polycarbonate Windshield

Fits: 2019-2022 MULE® PRO-MX

**Installation should be performed
by a certified technician.**

Includes:

1. (1) 14475-01 Windshield
2. (2) 13750-03 Slide Vents

Hardware Kit:

1. (8) Rubber Fast Strap (11651)
2. (4) 1/4" x 1-1/4" Fender Washer-
Black (used between vents and
windshield as a spacer)
3. (4) Female Thumbscrew, 1.72" Dia.
(BR-F4-B-21)
4. (4) 1/4-20 x 3/4" Carriage Bolt
(must be 3/4")
5. (2) 3/16" x 48" Bubble Edge Trim
(13623-TIM)
6. (1) EMP® Logo Decal

Tools Needed:

1. Phillips screw driver
2. 7/16" Wrench

**NOTE: Once the protective film
is removed this item can not be
returned. Check for fitment
before removing film.**

Installation:

1. Peel back the film along the top,
bottom and along the sides
exposing the slots.
2. Attach the rubber fast straps to
the slots as shown. The big
washer goes in the front.
Do not fully tighten yet.
3. Slide the bubble edge trim over
the top and bottom.
4. Remove the film from both sides
of the slide vents and around the
vent hole pattern in the
windshield.
5. Attach the slide vents using the
carriage bolts, large washers and
thumbscrews. The washers will
go between the vent and the
windshield. Insert the carriage
bolt in from the front, then the
washers, then the vent and
finally the thumbscrews.
6. Once assembled place on your
Mule and fully tighten the
hardware.
7. Your installation is complete.

