

EMP P/N - 13601

Kawasaki MULE SX Windshield

Fits: 2017-18 Mule SX

Installation Instructions:

Includes:

1. (1) Windshield (13601-01)
2. (2) Metal Stiffeners (13601-02)

Hardware Kit:

1. (4) Plastic Rivet (12148)
2. (8) Rubber Fast Strap (11651)
3. (1) 1/8" x 22-1/2" Long Bubble Edge Trim (ball on end)
4. (1) EMP® Logo Decal

Tools Needed:

1. 7/16" Wrench
2. Phillips Screw Driver

Installation should be performed by a certified technician.

Installation:

1. Inspect your windshield for shipping damage and fitment. Once you remove the protective film, this item can not be returned.
2. Peel back the plastic protective film to expose the slots and holes. There is plastic on both sides.
3. Attach the stiffeners to the windshield using the hardware supplied with the fast straps. The stiffeners will line up with the slots toward the center of the windshield. The large washers will go on the front. Do not tighten yet.
4. Attach the remaining (4) fast straps to the slots along the edge of the windshield. Do not tighten yet.
5. Slide the edge bubble trim over the center of the bottom of the windshield. This will protect your hood.
6. Set the windshield in place and wrap the straps around the cage tubes.
7. Install the plastic push rivets into the holes in the stiffener and into the plastic windshield.
8. Tighten all the hardware.
9. Your installation is complete.

