



## INSTALLATION INSTRUCTIONS

*Tough Country Products*  
1101 N. Blue Creek Rd.  
El Campo, TX 77437



**2019-2022 DODGE 2500-3500**

**Brush Guard- BG1934DE-GLOSS**

### **Tools Required:**

½" Drive Ratchet	13mm Socket
¾" Drive Ratchet	10mm Socket
18mm Deep Socket	18mm Wrench
19mm Socket	16mm Socket
19mm Wrench	15/16" Socket

### **Factory Bumper Removal:**

1. Open hood and disconnect the negative terminal from the battery using 10mm socket.
  - a. If equipped, disconnect the negative terminal from the auxiliary battery.
  - b. If applicable, disconnect the factory wiring harness.
2. Using 15/16" socket remove two bolts from tow hooks and remove from frame.
3. Using 18mm wrench and socket, remove the two factory bumper bolts that hold the factory bumper to the frame rail from each side and remove bumper.

### **Brush Guard Installation:**

1. Using 13mm and 18mm socket, install top two brackets to bumper. (reference picture 1)
2. Reinstall bumper onto vehicle.
3. Install lower brackets and reinstall the factory tow loops back into frame using the factory bolt in the rear and the provided bolt in the front. (reference picture 2)
4. Install lower support bracket using the lower bumper mounting bolt and the provided bolt to brackets. (picture 3)
5. Reinstall top bumper bolts.
6. Install brush guard to truck using the brackets that are protruding from the front of the factory bumper. (picture 4)
7. Align brush guard and tighten all bolts.

*\*\*\*If tow loops are not equipped on your model, trim the plastic around the two locations where the tow loops would be.*

**THANK YOU FOR CHOOSING TOUGH COUNTRY PRODUCTS**

Picture 1



Picture 2





Picture 3



Picture 4

