

**INSTALLATION INSTRUCTIONS
2017 FORD SUPERDUTY
BRUSH GUARD PART# BG2017F**

TOOLS REQUIRED:

| | |
|--------------------------|--------------|
| 1/2" DRIVE IMPACT WRENCH | 18MM SOCKET |
| 3/4" SOCKET | 3/4 WRENCH |
| CUTTING TOOL | MARKING TOOL |

1. **(IF EQUIPPED WITH SNOW PLOW BRACKETS) WITH A 18MM FROM UNDERNEATH TRUCK REMOVE OEM BRACKETS; SET BOLTS AND NUTS ASIDE FOR BRUSH GUARD INSTALL**
2. ALIGN BOTTOM BRACKET USING FACTORY HOLES IN FRAME, WERE 18MM BOLTS WERE REMOVED. MARK A LINE ON PLASTIC VALANCE.USE 1ST PHOTO TO DETERMINE LEFT AND RIGHT
3. WITH A CUTTING TOOL; CUT OUT A SLOT TO INSERT BRACKET IN VALANCE.ASSURE PROPER CLEARANCE FOR BRACKET.INSTALL BRACKET WITH FACTORY BOLTS
4. **(IN FRONT OF BUMPER) REMOVE TOW HOOK COVERS BY PULLING DOWN ON PLASTIC COVERS.**
5. USING 18MM SOCKET, REMOVE 2 OUTSIDE BUMPER MOUNTING BOLTS FROM EACH SIDE.
6. INSTALL TOP BRACKET ONTO BRUSH GUARD HAND TIGHTEN BOLTS.USE 2ND PHOTO FOR BRACKET INSTALL
7. INSTALL BRUSH GUARD USING FACTORY BOLTS AND NUT PLATE.
8. **MAKE SURE THAT THE BRUSH GUARD IS PROPERLY ALIGNED AND TIGHTEN ALL BOLTS STARTING WITH SUPPORT BRACKET TO THE FRAME.**

DRIVER SIDE

PASSENGER SIDE



Thank you for using Tough Country Products