

# BG2515G, BG3415C

## TOOLS REQUIRED

RATCHET	LONG EXTENSION	10MM SOCKET
3/4 SOCKET	15MM SOCKET	21MM SOCKET
3/4 WRENCH	18MM WRENCH	18MM SOCKET

1] OPEN HOOD AND REMOVE 12 PLASTIC POP RIVETS OF RADIATOR COVER. SET ASIDE FOR LATER USE.

2] WITH A 10MM SOCKET REMOVE THE 4 BOLTS HOLDING THE GRILL ON.REMOVE GRILL BY GENTILLY PULLING OUT FROM EVERY CORNER ONCE THE GRILL CLIPS COME OUT ON TOP PULL UP AND OUT.REMOVE GRILL.

3] WITH A 15MMSOCKET REMOVE THE TOP BOLTS ON EACH SIDE AND DISCARD. INSTALL TOP BRACKET WITH SUPPLIED 10MM X 30MM BOLT WITH WASHER ON BOTTOM SIDE AND BRACKET STANDING UP.LEAVE BOLT SNUG. ( **SEE Illustration 1** )

4] INSTALL GRILL ON TO TRUCK. STARTING WITH THE BOTTOM FIRST.SNAP ALL CLIP IN AND INSTALL THE 4 10MM BOLTS.

5] INSTALL THE TOP BRACKET TROUGH GRILL CONNECTING WITH LOWER BUMPER BRACKET. USING SUPPLIED 1/2" X 2 BOLT AND HARDWARE (**SEE ILLUSTRATION 2**)

5] FROM UNDERNEATH TRUCK REMOVE THE FACTORY TOW HOOKS USING THE 18MM SOCKET AND WRENCH.

6] WITH A 21MM SOCKET REMOVE THE BUMPER BOLT ON EACH SIDE.STARTING WITH THE DRIVER SIDE INSERT SUPPLIED LOWER BRACKET ON TO BOLTS ON OUTSIDE OF THE FRAME.INSTALL 21MM

# BG2515G, BG3415C

NUTS ON TO BOLTS.ON PASSENGER SIDE REMOVE BOLT OUT OF FRAME AND INSTALL LOWER BRACKET ON THE OUTSIDE OF FRAME .INSTALL BOLTS BACK TROUGH BRACKET AND FRAME INSTALL NUTS ON OPPOSITE SIDE LEAVE LOOSE. REINSTALL TOW HOOKS.

7] INSTALL BRUSH GUARD ONTO BRACKETS USING SUPPLIED 1/2 " X 2 BOLTS AND HARDWARE.TIGHTEN BOLTS HAND TIGHT .

8] ADJUST BRUSH GUARD, TIGHTEN BOLTS ON BOTTOM FIRST AND WORK YOUR WAY UP.

9] REINSTALL RADIATOR COVER AND POP RIVETS.



ILLUSTATION 1