

## **4 X 6 EZ Hunting Blind Assembly Instructions**

### **NO TOOLS NEEDED**

- 1. Lay out all parts and inspect.**
- 2. Set the base on a level surface.**
- 3. Attach the front wall to the base. (Open wings on wall and set wall onto base aligning pins with holes in floor.) Do not Fasten latches at this point.**
- 4. Attach either side wall to the front wall and base. (The front edge of the side wall will slide just behind the corner trim of the front wall. Then drop the pins into the holes on the floor.) At this point fasten the inside wall latch and then the 3 outside latches.**
- 5. Repeat #4 for other side wall and fasten latches inside and outside.**
- 6. Attach back wall with door. (Open wings and lift wall onto base sliding corner trim over side wall edges and drop pins into holes on floor.) Fasten latches inside and outside.**
- 7. Attach top to the blind. (Open door to 90 degrees. Lift and slide top to the top of the blind, rest the top on the door. Move to the inside and finish sliding top into place. Make sure the top frame is resting inside the blind and the top is laying flat on all four sides.) Fasten all top latches.**
- 8. Remove protective covering from windows.**