

EMP P/N - 13081

Honda Pioneer 500 Full Windshield Fits: 2015-2018 Honda Pioneer 500 & 2021-2022 Honda Pioneer 520

Tools needed:

1. Phillips Screwdriver
2. 7/16" Socket or wrench

Includes:

1. (1) Hard Coated Windshield P/N 13081-01
2. (6) Rubber Fast Straps (P/N 11651)
3. (1) 3/16" x 41-1/2" Long Bubble Trim
4. (1) EMP® Logo Decal

Installation:

1. Peel back the PVC coating along the bottom and sides. **NOTE:** Once the PVC coating is removed, this item can not be returned.
2. Center the rubber along the bottom and slide in over the bottom edge.
3. Attach the rubber straps to the (6) slots with the hardware provided. Do not tighten the hardware yet.
4. Place your windshield on your Pioneer. Wrap the straps around the tube and hook them on the plastic pins. Once you have it in the correct location in the slots, tighten all the screws.
5. Peel the remaining protective film off of both sides.
6. Your installation is complete.

