

Screen Door Installation Instructions

(FOR VENTILATION ONLY)



Happy
with our product?

Please help us spread the word
by leaving a review at:

www.OverEZchickencoop.com



Made in the U.S.A.

For more information about all our products, visit: www.OverEZchickencoop.com

Tools Required

- 1/8" drill bit and drill.
- Number 2 square bit.

Screen Door Installation

1. Open the man door and place the screen door in the man door opening.

Center screen door from top to bottom and butt hinged side to the left side opening. Hang screen door with provided screws. If correctly hung the screen door should not scrub the top, right side or the bottom of man door opening.



2. Attach the eye hook to the corner trim. With the screen door open use the hook latch to mark the location for the eye hook. Pre-drill hole with 1/8-inch drill bit. Screw the eye hook into the pre-drilled hole.

NOTE: Both doors will not close at the same time.



3. Attach eye hook to the right side of the man door trim using the same method as step #2.

You did it!

