



Cord Hook

Instruction Manual

contents:

- 1 - hook
- 2 - #10 2" black screws, #2 sq dr

Setting Up Your Cord Hook

CONFIRM THAT ALL PARTS ARE PRESENT BEFORE BEGINNING ASSEMBLY.

1. Find the stud. You can put these hooks at whatever height you want.
2. Put the screws in the holes and fasten, ensuring the screws hit the studs.

Not to exceed 75 pounds.

happy with our products?

Please help us spread the word by leaving a review at: www.SHEDorize.com



SHEDorize

SHEDorize.com

(866) 548-1625

info@amishland.com