

Installation Instructions:

- ▶ Remove existing weatherstrip from door frame
- ▶ Clean door jamb with wet cloth
- ▶ Measure area of door jamb to be replaced
- ▶ Cut replacement weatherstrip to size
- ▶ Insert weatherstrip by pressing the tail firmly into the slot in the door jamb
- ▶ Close door to ensure proper seal

Instrucciones para la instalación:

- ▶ Retire el burlete existente del marco de la puerta
- ▶ Limpie la jamba de la puerta con un paño mojado
- ▶ Mida el área de la jamba de la puerta que va a reemplazar
- ▶ Corte el burlete de reemplazo al tamaño deseado
- ▶ Inserte el burlete presionando el extremo firmemente en la ranura de la jamba de la puerta
- ▶ Cierre la puerta para comprobar que sella adecuadamente



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

