

# QUICK-CONNECT FITTING



## AQC150K 1-1/2 inch

FITS MOST SUMP & EFFLUENT PUMPS

## AQC200K 2 inch

FITS MOST SEWAGE PUMPS

### 3 STEP INSTALLATION



**1.** Insert the Quick-Connect fitting into the pump discharge outlet and tighten.



**2.** Insert the PVC pipe into the fitting as far as possible.



**3.** Hand-tighten the fitting around the PVC pipe.



For assistance call: **1-844-242-2475** or visit **[www.K2pumps.com](http://www.K2pumps.com)**