

POST **proservative**

Post Size	Stick Qty	Boring Depth	# of Borings
4x4, 4" Round	1	4"	1
4x6, 6x6, 6" Round	2	4"	2
3 & 4 Ply 2x6, 3 Ply 2x8	2	4"	2
8x8, 4 Ply 2x8	3	4"	3

1. Drill 3/8" x 4" hole on 45 degree angle – extended length drill bits work best
2. On smaller posts, drill steeper angle so the hole terminates at the center of the post
3. Start first boring just above the grade line
4. Start the second boring on the opposite side of the post, 6" below grade

(Note: If desired, 2 sticks can be used on 4x4 and 4" round)
5. For posts in concrete, start borings just above grade line & slightly off center so holes don't meet
6. For 3 stick posts, start 3rd boring just above grade on any additional side
7. Laminated posts: for best results, drill borings holes through the plys
8. Insert Post Proservative sticks, tapered end down
9. Cap all boring holes with provided orange plugs
10. Install date tag with provided nail and punch out year of treatment
11. Sticks easily reloaded in original boring holes. Plug removal with 3/16" flat screwdriver

Questions? Call 1-877-WONT-ROT (966-8768)