

3 EASY STEPS

MEASURE

CUT

INSTALL

TOOLS NEEDED / HERRAMIENTAS

NECESARIAS:



INSTRUCTIONS / INSTRUCCIONES:

MEASURE

1. Measure the width of door.

CUT

2. Cut door seal to length with hacksaw.

INSTALL

3. Slide the door seal under the base of door with the taller side facing inside. Vinyl fins should compress approximately 1/8" against threshold.

If the door seal becomes too snug to slide on easily, gently tap the door seal in place using a wood block and rubber mallet. Raise or lower the door seal so the vinyl fins come into contact with the threshold.

MEDIDA

1. Mida el ancho de la puerta.

CORTAR

2. Utilizando una segueta, corte la junta de la puerta para adaptarla al largo.

INSTALAR EN PC

3. Deslice el sello de la puerta debajo de la base de la puerta con el lado más alto orientado hacia adentro. Las aletas de vinilo deben comprimirse aproximadamente 1/8" (3 mm) contra el umbral.

Si la junta de la puerta queda demasiado apretada y no permite deslizarla fácilmente, golpee suavemente la junta en su lugar con un bloque de madera y un mazo de goma. Suba o baje la junta de la puerta para que las aletas de vinilo hagan contacto con el umbral.



QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

