

TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



INSTRUCTIONS:

1. Measure width of door and cut door seal to length with hacksaw.
2. With door closed, position door seal so vinyl fins compress approximately 1/8" against threshold. Drill pilot holes in center of screw slots and attach door seal with enclosed screws.
3. Final adjustment of door seal may be made just prior to tightening of screws.

INSTRUCCIONES:

1. Misurez la largeur de la porte et utilisez une scie à métaux ou des ciseaux pour couper le coupe-froid en conséquence.
2. Alors que la porte est fermée, placez le coupe-froid de manière à ce que la bande de vinyle se comprime d'environ 3.2 mm contre le seuil. Percez des avant-trous au centre des fentes de vis et fixez le coupe-froid à l'aide des vis comprises.
3. Réglez le coupe-froid de manière définitive avant de serrer les vis.



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

