

# S-TINE CULTIVATOR SET MODEL NUMBER – STA/A003/0023/A

**UNIPART ITEM CODE - 53STAA003** 

Assembly Manual:-A00-RD-AM-53STAA003-A-00







## \*\*\*Caution\*\*\*

Please Read and Follow all instructions before installation and operation of S-TINE CULTIVATOR SET



- Read and follow ATV/UTV and implement manual instructions.
- Attachments change machine handling characteristics. Slow down. Do not exceed a safe travel speed when implement is attached.
- Add ballast on the front frame to keep at least 20% of machine weight on front wheels to maintain steering control.
- Never carry passengers on power unit or implement.
- Keep hands, arms and feet away from frame and implement components.
- Use 2 people when attaching and unhooking implement.
- Do not drive across steep slopes to prevent tipping over.
- Stop power unit, remove ignition key and wait for all moving parts to stop before adjusting or repairing.
- Always use retainers on mounting pins to prevent unexpected separation.
- Do not exceed engine power capacity. Stop to allow engine to cool if overheating. Adjust implement to reduce load before resuming work.



29DCLA001




## List of Kit Assembly (53STAA003)

S.NO.	DESCRIPTION	ITEM NUMBER	ORDER ITEM NUMBER	QTY.	IMAGES
1	S-TINE BAR	53MISA031S	53MISA031S	6	
2	S-TINE CLAMP	53MISA033S	53MISA033S	6	
3	CULTIVATOR SWEEP 1"	53MISA032S	53MISA032S	6	
4.1	NYLOCK NUT 3/8" – 16	22NYTA538S	22KITA467	6	
4.2	FLAT HEAD SQ. NECK BOLT 3/8"-16 L 1-9/16"	22HHBA581S		6	
4.3	WASHER 3/8"	22FLWA593S		6	
4.4	NYLOCK NUT ½"-13	22NYTA533S		6	
4.5	WASHER 1/2"	22FLWA594S		6	
4.6	HEX BOLT 1/2"-13 L 3-11/16"	22HHBA582S		6	



## **EXPLODED VIEW – S-TINE CULTIVATOR SET (53STAA001)**

#### Parts Identification:



#### **Use and Care Information:**

- "S" tines can be spaced as needed. Can also be used individually for trenching or spaced to cultivate row crops.
- o Check the accessory mounts frequently and retighten hardware if necessary.
- Replace this accessory with a new one if it is damaged.



### **Cultivator installation Instructions:**

- 1. Install (#3) CULTIVATOR SWEEP 1" onto (#1) S-TINE BAR using (#4.2) FLAT HEAD SQ. NECK BOLT 3/8"-16 L 1-9/16" and fastening with (#4.3) WASHER 3/8" and (#4.1) NYLOCK NUT 3/8" 16. Provide proper torque with the help of tightening tools.
- 2. Place "S" tine assembly on both side of the vertical tube of the Uniparts toolbar equally. After providing equal space, secure using (#2) S-TINE CLAMP. Fasten to toolbar with (#4.6) HEX BOLT 1/2"-13 L 3-11/16", (#4.5) WASHER 1/2" and (#4.4) NYLOCK NUT ½"-13. Provide proper torque with the help of tightening tools.
- 3. Leave enough room so that you are able to slide the Toolbar draw pins on and off, of the lift arms of the Uniparts 3-Point Hitch unit.
- 4. Final setup should look Similar to the picture below.



WARNING: - Do not over tighten hardware, or damage can occur.



Uniparts USA Ltd. 1431, Marvin Griffin Road, Augusta, GA-30906, USA

Phone: 1-706-868-2388

Fax: 1-706-868-4168

technicalsupport@usa.unipartsgroup.com

