



## Fitting Instructions WA300 and WA500 Wall/Ground anchors

### Pack includes

- 1 x WA300 or WA500 anchor
- 2 x M10 x 70mm long CSK Bolts
- 2 x M10 bolt shields
- 2 x 6.35 diameter ball bearings.



**Please note: The wall/ground anchor must  
be secured into good solid concrete or brick surfaces**

1. Using the WA300/WA500 as a template, drill through the two holes with a 12mm diameter concrete drill to a depth of 10mm.
2. Remove the WA300/WA500 and then re-drill the two holes with a 16mm diameter concrete drill to a depth of 90mm.
3. Drop the bolt shields into the drilled holes, place the WA300/WA500 over the holes and put the bolts through the WA300/WA500 and tighten the bolts evenly to a torque of 20NM.
4. Once the unit has been fitted satisfactorily it is recommended for total security the two steel balls are hammered into the top of the socket heads.

### Henry Squire & Sons Limited

Hilton Cross Business Park, Cannock Road, Featherstone, Wolverhampton, WV10 7QZ

Tel: 01902 308050

Fax: 01902 308051

E-Mail: [info@henry-squire.co.uk](mailto:info@henry-squire.co.uk)

Website: [www.squirelocks.co.uk](http://www.squirelocks.co.uk)