

How to Install Peel & Stick Decals

1. Before installation, make sure that your surface is clean, dry and smooth. RoomMates will stick to most smooth flat, non-porous surfaces, including walls, appliances, doors, and some furniture. Our decals are for indoor use only and should be installed in a room of moderate temperature.
2. Slowly peel the RoomMate from its backing.
3. Working from the center outward, smooth the decal onto the wall with a smoother (like a credit card) or your hands.
4. If you need to reposition your RoomMate, slowly peel it away starting from a top corner and stick it in a new spot.
5. If you are moving and would like to take your RoomMates with you, it is best to stick them back on their original backing. If you forgot to save the backing, you can also use wax paper or a vinyl shower liner. This will protect the adhesive and keep the RoomMate from creasing during transport. Gently roll the backing with the RoomMates, never fold.