

IMPORTANT

READ ALL INSTRUCTIONS BEFORE STARTING

PREPARING THE SURFACE

- Clean your windshield to make sure that there is no contamination on the glass.
- Ensure that no streaks, smears, or water spots remain before application.
- Dry the glass **completely**, as any remaining moisture will negatively affect the coating.

CERAMIC GLASS COAT APPLICATION

- Application must be done out of direct sunlight and in a clean environment.
- Apply the Ceramic Glass Coating to your windshield using a crosshatch pattern. This will require two of the Cerakote Ceramic Glass Coating Wipes.

Set a timer for five minutes to allow the coating to flash - you may see the coating start to sweat or bead. This is a normal visual indicator that the coating is ready to be buffed.

- After five minutes, begin buffing the coating using the high - quality microfiber cloth included with your kit. Use one side of the microfiber cloth to level the coating, and then switch to the other side to completely buff the glass to a brilliant shine.
- Let the coating fully cure for **two hours** before driving and wait at least one day before exposing it to moisture.

Congratulations!

You have achieved ultimate protection with maximum water shedding and hydrophobicity.



LOVE IT? LET US KNOW BY POSTING
YOUR REVIEW & PHOTOS ONLINE.

CERAKOTE[®]
CERAMIC COATINGS

CERAMIC GLASS COAT

WE STRONGLY RECOMMEND WATCHING THE INSTRUCTIONAL
VIDEO, WHICH SHOWS THIS PROCESS VISUALLY

SCAN WITH YOUR PHONE
FOR A HELPFUL
INSTRUCTIONAL VIDEO



We're here to help. Give us a call at **866.774.7628** or email us at technicalsupport@cerakoteceramics.com

V12042023