

DIY Bat House Instructions

Congratulations on your new Prime Retreat Bat House! We hope this house brings you and your loved one(s) many hours of enjoyment.

NOTE: PLEASE READ ALL DIRECTIONS BEFORE STARTING ASSEMBLY. Leave the rough portion of the wood facing the inside of the house. If you paint or stain your house, do the **OUTSIDE ONLY**.

Parts list:

- Back panel
- Left panel
- Front panel
- Right panel
- Roof
- Screws

Tools:

- Screwdriver
- Clamps (house can be assembled without them)

STEP 1:

Lay the back panel (long, solid rectangular piece with grooves) on a level surface with the grooved side facing toward the inside of the house and tab with nail holes at the top. Refer to Figure A.



Figure A

STEP 2:

Align the 2 side panels (pieces with angled top edges) with the edges of the back panel. Ensure the angled edge of each is facing upward, and the rough hewn side is facing inward.

STEP 3:

The predrilled holes on this back panel will align with the pilot holes on the edge of each side panel. If desired, clamp each side to the back of the item for ease of assembly. Once clamped, insert the included screws into these pilot holes and tighten using a screwdriver. Repeat for the second side panel. Refer to Figure A.

STEP 4:

Place the front panel (short rectangular piece that has Prime Retreat on front and grooves on back) atop the installed sides and floor. Align its predrilled holes with the pilot holes on the sides and ensure the groove side is facing toward the inside of the house. Secure the front of the house by inserting the screws into the holes.



Figure B

STEP 5:

Place the roof over the slanted edges of the side panel and align them. Ensure the predrilled holes on this roof align with the pilot holes on the side panels and secure with the included screws. Refer to Figure C.

The 2 predrilled holes on the top lip and single one on the base are for mounting the home against a wall or post.



Figure C