

ALUMINUM ROCKER RUNNER ASSEMBLY INSTRUCTION

PARTS:

SCREW

- 5 PCS.

ALUMINUM ROCKER RUNNER

- 2 PCS.

ASSEMBLY:

- 1.) PLACE THE CHAIR IN THE REVERSE POSITION
- 2.) INSERT THE FRONT LBG FIRST
(HOLE ON THE ALUMINUM RUNNER WHICH NEAR THE
END IS FOR THE FRONT LEG)
- 3.) INSERT THE BACK LEG SOMETIMES NEED EXTRA
SLIGHT FORCE AND THEN ALIGN)
- 4.) ATTACHED ALL THE SCREW AND TIGHTEN

