

For installation of the following items:  
V73M • V73/3M • V75M • V75/2M • V76M

## INDOOR

### Window Insulation Kit

**Preparation:** Be sure surface is clean, dry and grease-free. Install only on metal, painted wood or vinyl. DO NOT APPLY to wallpaper, wallboard, plaster or veneer surfaces.

#### Installation:

1. Apply tape firmly around window frame and along bottom sill. Remove backing paper.
2. Apply film slightly taut first across top, then bottom and both sides, leaving at least 1" overhang around edge. Pull and stretch film to smooth out any wrinkles.
3. Smooth and eliminate remaining wrinkles with hair dryer set at highest setting (hold dryer 4-6" away from film). Trim excess film from around frame.



**Do Not Touch Plastic with Hot Dryer!**  
*¡No toque el plástico con la secadora caliente!*

## Kit de aislamiento para ventana

### INTERIOR

Asegúrese que la superficie esté limpia, seca y libre de grasa. Instále solo sobre marcos de metal, madera pintada ó con revestimiento de vinilo. NO APLIQUE sobre papel tapiz, tablaroca, yeso o paneles de chapa.

#### Instalación:

1. Aplique la cinta de doble cara alrededor del marco de la ventana y la repisa inferior. Remueva el papel de reverso.
2. Aplique la película levemente estirada a lo largo del tope, la parte inferior, y los lados, dejando al menos 1 pulgada (2,54 cm) extra alrededor. Jale y estire la película para alisar cualquier arruga.
3. Alise y elimine las arrugas restantes con una secadora de mano en temperatura máxima (sostenga la secadora aprox. 4-6" [10-15 cm] de la película).

#### TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



Follow Us @FrostKing  
or [www.frostking.com](http://www.frostking.com)



Thermwell Products Co., Inc.  
Mahwah NJ 07430 | Sparks NV 89431

Need help or information  
about any Frost King product?

Call **1-877-FROST 20**  
3 7 6 7 8

For videos, instructions, hints and tips  
visit [www.frostking.com/instructions](http://www.frostking.com/instructions)